

USER MANUAL

GPS APPLICATION

Table of Contents

- 1 Setting up to run DCGPS.....2
- 1.1 Running in Linux2
- 2 How to use DCGPS.....2

1 Setting up to run DCGPS

Dcgps requires a number of libraries to be installed before executing. The libraries that are required to be already installed include:

- gpsd
- gpsd-clients
- python-gps
- libncurses5-dev
- libgps-dev

1.1 Running in Linux

1. Assuming all libraries are correctly installed.

2. Open **terminal** and type in

```
sudo killall gpsd
```

```
sudo gpsd /dev/ttyUSB0 -F /var/run/gpsd.sock
```

3. **Run** dcgps by typing in


```
./dcgps
```

2 How to use DCGPS

1. Make sure **GPS dongle** is properly connected into laptop / raspberry pi.


2. Wait until the program displays a fix in the **Status** field

- If the program displays **NO FIX**, this may mean that there are simply not enough satellites to determine your location. Wait for several minutes to see if the program can acquire more satellites.



Status: NO FIX

3. If a fix is acquired, your screen should be similar to the following screenshot.



DCGPS		PRN	Elevation	Azimuth	SNR	Used
Time:	Nov 08 2015. 21:54:00 UTC	14	38	178	15	Y
Latitude:	49.19° N	24	19	82	28	Y
Longitude:	-123.12° W	18	59	69	17	Y
Speed:	0.00	27	49	252	21	Y
Status:	3D FIX	21	38	124	14	Y
		8	36	298	14	Y
		15	16	45	19	Y
		22	76	265	23	Y