

SESAM TUTORIAL

GeniE

Parametric Semisub Panel Modelling

Valid from program version 8.2





Sesam Tutorial

GeniE – Parametric Semisub Panel Modelling

Date: August 2021

Valid from GeniE version 8.2

Prepared by: Digital Solutions at DNV

E-mail support: software.support@dnv.com

E-mail sales: digital@dnv.com

© DNV AS. All rights reserved


This publication or parts thereof may not be reproduced or transmitted in any form or by any means, including copying or recording, without the prior written consent of DNV AS.

TABLE OF CONTENTS

1. Introduction	Page 4
2. Variables of the Parametric Input	Page 5
3. Wet Surface and Dummy Hydro Pressure	Page 7
4. Alternative Models by Editing the Dimension Variables	Page 9


1 INTRODUCTION

- This tutorial shows how to establish and use a parametric input file (js file) for creating panel models of simple eight-column semi-submersibles of alternative sizes.
- The tutorial is based on the input file `Parametric_Semisub_Panel_Model_Input.js` that accompanies this tutorial.
 - The input file includes the semi-submersible main dimensions as variables. Editing these variables in the input file creates panel models of different sizes.
 - The semisubmersible panel model is stored as `Semisub_Panel_T1.FEM`. This file may be used in HydroD for stability or hydrodynamic analysis.
- This tutorial assumes basic knowledge in GeniE and the JavaScript command language. With knowledge in simple programming in JavaScript (logical tests and do-loops) even more advanced parametric input files may be created.




2 VARIABLES OF THE PARAMETRIC INPUT


- The dimension variables seen from the side:




- The dimension variables seen from the front:



- In addition to the dimension variables there are two mesh variables for controlling the panel mesh:
 - Md_Line – A *Number of Elements* property assigned to feature edges in the model. This controls the number of elements over the height of the pontoons and around the circumference of the columns as shown below.
 - Mesh_Length – A value assigned to a *Mesh Density* property that is set as default mesh property. I.e. this property is assigned to all surfaces.




- Below the panel mesh is shown when Md_Line is set to 2 and Mesh_Length to 5 m.




3 WET SURFACE AND DUMMY HYDRO PRESSURE


- Since this is a panel model for use in HydroD, a wet surface property is defined for the outer surfaces:




- Wet surface properties are also defined for four tanks:



- Dummy hydro pressure for the outer surface:




- Dummy hydro pressure in one of the four tanks:



4 ALTERNATIVE MODELS BY EDITING THE DIMENSION VARIABLES

➤ Below are shown two alternative models created by editing the dimension variables.





About DNV

We are the independent expert in risk management and quality assurance. Driven by our purpose, to safeguard life, property and the environment, we empower our customers and their stakeholders with facts and reliable insights so that critical decisions can be made with confidence. As a trusted voice for many of the world's most successful organizations, we use our knowledge to advance safety and performance, set industry benchmarks, and inspire and invent solutions to tackle global transformations.

Digital Solutions

DNV is a world-leading provider of digital solutions and software applications with focus on the energy, maritime and healthcare markets. Our solutions are used worldwide to manage risk and performance for wind turbines, electric grids, pipelines, processing plants, offshore structures, ships, and more. Supported by our domain knowledge and Veracity assurance platform, we enable companies to digitize and manage business critical activities in a sustainable, cost-efficient, safe and secure way.