

DO NOT use this machine unless you are authorised and have been instructed in its safe use and operation.



Be aware of burns, scalding from hot surface or hot food



Be aware of electrocution –
Never place metallic objects in a toaster

POTENTIAL HAZARDS:

- Include burns from hot surfaces, electrocution and sources of ignition from hot surfaces and hot foods.

PRE-OPERATIONAL SAFETY CHECKS

- Visually inspect the unit for cracks or defects
- Do not operate if cord/plug or unit is damaged or after the appliance has malfunctioned
- Familiarise yourself with and check all appliance operations and controls.
- Ensure no power trip hazards are present for example, only one appliance plugged into the PowerPoint.
- Immediately report suspect equipment.

OPERATIONAL SAFETY

- Do not place any metallic objects (of any kind) into toasters.
- Turn device off at the power point if any metallic or plastic smells occur
- Use caution in removing heated foods from the appliance.
- Be aware of other people in the immediate vicinity when handling hot foods.
- Before cleaning switch off and allow the appliance to completely cool.

POST-OPERATION:

- Switch off the appliance when cooking is completed.
- Leave the appliance and work area in a safe, clean and tidy state.
- Wipe up any spills on floor or counter immediately

