

Scale and Normalize Instructions in PLC

by Editorial Staff

Scale Instruction

SCALE_X scales the normalized real parameter VALUE where (0.0 <= VALUE <= 1.0) in the data type and value range specified by the MIN and MAX parameters:

$$OUT = VALUE (MAX - MIN) + MIN$$

For SCALE_X, parameters MIN, MAX, and OUT must be the same data type. NORM_X normalizes the parameter VALUE inside the value range specified by the MIN and MAX parameters:

$$OUT = (VALUE - MIN) / (MAX - MIN), \text{ where } (0.0 <= OUT <= 1.0)$$

Normalize Instruction

For **NORM_X**, parameters MIN, VALUE, and MAX must be the same data type.

Note: SCALE_X parameter VALUE should be restricted to (0.0 <= VALUE <= 1.0)


If parameter VALUE is less than 0.0 or greater than 1.0:

The **linear scaling** operation can produce OUT values that are less than the parameter MIN value or above the parameter MAX value for OUT values that fit within the value range of the OUT data type. SCALE_X execution sets ENO = TRUE for these cases.

It is possible to generate scaled numbers that are not within the range of the OUT data type. For these cases, the parameter OUT value is set to an intermediate value equal to the least-significant portion of the scaled real number prior to final conversion to the OUT data type. SCALE_X execution sets ENO = FALSE in this case.

If parameter VALUE is less than MIN or greater than MAX, the **linear scaling** operation can produce normalized OUT values that are less than 0.0 or greater than 1.0. NORM_X execution sets ENO = TRUE in this case.

NORM_X and SCALE_X instructions. Explain the instructions with example.



PLC ladder program explanation

General **NORM_X** and **SCALE_X** instructions are used for scaling the value or we can use this instruction in analog value scaling.

By using NORM_X instruction we can normalize the actual value in leaner scale within the value range.

For example, here the input value is 0 to 27648 and this value needs to be normalized in linear scaled value range from 0.0 to 1.0.


After this normalization of the value we can use this output as input value of the SCALE_X instruction. This instruction maps the value in required range (here 0 to 100). This instructions generally used in Siemens **S7-1200 PLC**.

List of Inputs/Outputs

- Register A :- For analog value (0 to 27648).
- Register B :- Out of NORM_X
- Register C :- Output value of SCALE_X instruction.

PLC Ladder Programming

NETWORK 1 :-



Here define MIN value and MAX value of the actual input.

For example if analog sensor is connected in the analog channel, MIN value is 0 and MAX value is 27648.

The instruction will scale the actual input value into normalized value (0.0 to 1.0).

NETWORK 2 :-

Here SCALE_X instruction is used. After normalization of the actual value, we can convert it into desired value range (0 to 100).

For example purpose, we have taken here 0 to 100 range but we can take other value also.

Note :- Above application may be different from actual application. This example is only for explanation and educational purpose only. We can implement this logic in other PLC also. This is the simple concept of NORM_X and SCALE_X, we can use this concept in other examples also.

All parameters and graphical representations considered in this example are for explanation purpose only, parameters or representation may be different in actual applications. Also all interlocks are not considered in the application.

If you liked this article, then please subscribe to our [YouTube Channel](#) for PLC and SCADA video tutorials.

You can also follow us on [Facebook](#) and [Twitter](#) to receive daily updates.

Read Next:

[Siemens Comparator Logic](#)

[How scaling works in PLC ?](#)

[Motor Logic with Push buttons](#)

[Basics of Interlocking in PLC](#)

[Ladder Logic with Timers](#)

Share With Your Friends



Don't Miss Our Updates

Be the first to get exclusive content straight to your email.

Enter your name here...

Enter your email here...

We promise not to spam you. You can unsubscribe at any time.

Subscribe Now

- PLC Tutorials
- > How to use Master Control Reset (MCR) Instruction in PLC
- > What is PID Controller?

Recommended Articles

- PLC Motor Logic with START, STOP, TEST Push buttons
- Auto Tiffin Box Filling Station
- Always ON and OFF Bit using Ladder Logic and Statement List
- PLC Motor Control Ladder Logic Programming
- Motor Control Circuits
- #15 PLC Best Practices – Safe State when PLC Restarts
- Commissioning Checklists for Industrial Automation Systems
- Face Mask Making Machine using PLC and HMI
- Create User-Defined Data Types and Function Blocks in Studio 5000
- PLC Sinking and Sourcing Explanation

Leave a Comment

Name *

Email *

Website

Post Comment

Categories

Select Category

Recent Comments

mercy Mbiaji on [Chromatography Questions & Answers](#)

Syed Warsi on [7 OSI Layers of Communication](#)

Dimas on [How to Size a Cable for Industrial AC Motors?](#)

Shashank G on [How to Size a Cable for Industrial AC Motors?](#)

Mr. Okezie Collington on [Free Instrumentation Course for Trainee Engineers](#)

Kavi on [Single Push button to ON and OFF a Bulb using Ladder Logic](#)

Patrick Wanton on [Instrumentation System Architecture](#)

More Articles

- D Flip Flop PLC Ladder Logic
- PLC Analog Input Sampling Ladder Logic
- PLC Automatic Control of Two Outputs with one Input
- Compare Online and Offline PLC Programs
- How to Connect a Solenoid Valve with PLC?
- PLC Program to Separate Different Size Objects
- PLC Program for Latching and unlatching Circuit
- Check Block Consistency Tools in Simatic Manager
- Program Flow Control Instructions in PLC Programming
- Configuration of InTouch Scada Trends