


QuarkPi-CA2 Start-up

Logo Custom Reference manual

V1.0



1. Shopping:TMALL: <https://zhengdianyuanzi.tmall.com>TAOBAO: <https://openedv.taobao.com>**2. Download**Address: <http://www.openedv.com/docs/index.html>**3. FAE**Website : www.alientek.comForum : <http://www.openedv.com/forum.php>Videos : www.yuanzige.com

Fax : +86 - 20 - 36773971

Phone : +86 - 20 - 38271790



Disclaimer

The product specifications and instructions mentioned in this document are for reference only and subject to update without prior notice; Unless otherwise agreed, this document is intended as a product guide only, and none of the representations made herein constitutes a warranty of any kind. The copyright of this document belongs to Guangzhou Xingyi Electronic Technology Co., LTD. Without the written permission of the company, any unit or individual shall not be used for profit-making purposes in any way of dissemination.

In order to get the latest version of product information, please regularly visit the download center or contact the customer service of Taobao ALIENTEK flagship store. Thank you for your tolerance and support.

Revision History:

Version	Version Update Notes	Responsible person	Proofreading	Date
V1.0	release officially	ALIENTEK	ALIENTEK	2025.04.07

Catalogue

Brief	1
Chapter 1. Customization of Boot Logo	2
1.1 Replacing the logo	3
1.2 Rotating Logo	4
1.3 Disable Logo Display.....	8

Brief

The Debian system has no logo!!!

Chapter 1. Customization of Boot Logo

This chapter introduces how to change the boot logo, how to rotate the boot logo, and how to disable the display of the logo.

1.1 Replacing the logo

The boot-up logo includes the u-boot stage logo and the kernel stage logo. Both of these logo files are stored in the kernel source code directory:

```
tgg@tgg-virtual-machine:~/rk3568_android_sdk/kernel$  
tgg@tgg-virtual-machine:~/rk3568_android_sdk/kernel$ pwd  
/home/tgg/rk3568_android_sdk/kernel  
tgg@tgg-virtual-machine:~/rk3568_android_sdk/kernel$  
tgg@tgg-virtual-machine:~/rk3568_android_sdk/kernel$ ls -l *.bmp  
-rw-rw-r-- 1 tgg tgg 177700 4月 28 15:24 logo.bmp  
-rw-rw-r-- 1 tgg tgg 177764 4月 28 15:24 logo_kernel.bmp  
tgg@tgg-virtual-machine:~/rk3568_android_sdk/kernel$
```

Figure 1.1-1 Logo image files

It can be seen that both of these logo files are in BMP format. The default logo is as follows: U-Boot logo:



Figure 1.1-2 U-Boot logo

Kernel logo:



Figure 1.1-3 Kernel logo

If you need to change the startup logo, you first need to rename the U-Boot logo file (bmp image) you provided to "logo.bmp", and rename the kernel logo file (bmp image) you provided to "logo_kernel.bmp". Then, copy these two logos to the Linux kernel source code directory and replace the old logos!

Next, in the root directory of the SDK, execute the following command to recompile the Linux kernel and generate the boot.img image:

```
# If using the Linux SDK, the following command should be executed:
# The generated image is stored in the directory "output/firmware/"
./build.sh alientek_quarkpi_ca2_defconfig
./build.sh kernel

# If it is the Android SDK, then execute the following command:
# The generated image is stored in the directory rockdev/Image-atk_quarkpi_ca2/
source build/envsetup.sh
lunch atk_quarkpi_ca2-userdebug
./build.sh -KA -J12
```

When compiling the Linux kernel, the logo.bmp and logo_kernel.bmp files as well as other necessary resources will be packaged into a resource image named resource.img. Eventually, this resource.img image will be merged into the boot.img image.

After burning the compiled boot.img onto the development board and powering it on, the logo will have been changed at this point.

When the U-Boot code is running, it will load the two bmp files into memory. The logo.bmp will start to display at the beginning of the U-Boot stage, while the address of logo_kernel.bmp in the memory will be passed to the Linux Kernel by U-Boot, and it will be displayed during the initialization stage of the DRM driver in the Linux Kernel.

1.2 Rotating Logo

The RK platform U-Boot does not support the logo rotation function by default. ALIENTEK has implemented the logo rotation function based on the RK U-Boot. The usage is very simple. You can directly configure the rotation angle of the logo through the kernel device tree.

Enter the Linux kernel source code directory, open the device tree file arch/arm64/boot/dts/rockchip/rk3588s-atk-lcds.dtsi. For example, if you want to modify the display direction of the MIPI screen logo, you need to add the "logo,rotate" attribute in the route_dsi0 node (the board has two MIPI screen interfaces, MIPI_DSI0 corresponds to route_dsi0, and MIPI_DSI1 corresponds to route_dsi1). As shown below:

```
194 /***** MIPI DSI TX0 *****/
195 &dsi0 {
196     status = "disabled";
197 };
198
199 &dsi0_in_vp2 {
200     status = "disabled";
201 };
202
203 &dsi0_in_vp3 {
204     status = "disabled";
205 };
206
207 &route_dsi0 {
208     status = "disabled";
209     logo,rotate = <1>;
210 };
211
```

Figure 1.2-1 Modify the display direction of the MIPI DSI0 logo

```
241 /***** MIPI DSI TX1 *****/
242 &dsi1 {
243     status = "disabled";
244 };
245
246 &dsi1_in_vp2 {
247     status = "disabled";
248 };
249
250 &dsi1_in_vp3 {
251     status = "disabled";
252 };
253
254 &route_dsi1 {
255     status = "disabled";
256     logo,rotate = <1>;
257 };
258
259
260 //&mipi_dcphy1 {
261 //     status = "disabled";
262 //};
263
```

Figure 1.2-2 Modify the display direction of the MIPI DSI1 logo

The "logo,rotate" attribute can take values of 0, 1, 2, and 3, respectively indicating that the logo is rotated 0 degrees, 90 degrees, 180 degrees, and 270 degrees in a clockwise direction.

If you need to modify the display direction of the HDMI screen logo, then you need to add the "logo,rotate" attribute in the route_hdmi0 interface node, as shown below:

```

282 /***** HDMI TX0 *****/
283 //<!-- HDMI TX0与EDP TX0不可同时使能 -->
284 &hdmio {
285     enable-gpios = <&gpio4 RK_PB1 GPIO_ACTIVE_HIGH>;
286     status = "disabled";
287 };
288
289 &hdmio_in_vp0 {
290     status = "disabled";
291 };
292
293 &hdmio_in_vp1 {
294     status = "disabled";
295 };
296
297 &hdmio_in_vp2 {
298     status = "disabled";
299 };
300
301 &route_hdmio {
302     status = "disabled";
303     logo,rotate = <1>;
304 };
305
306
307 &hdptxphy_hdmio {
308     status = "disabled";
309 };
310
311 &hdmio_sound { //i2s5_8ch
312     status = "disabled";
313 };
314 /***** END *****/

```

Figure 1.2-3 Modify the display direction of the HDMI_TX0 logo

The meaning of the "logo,rotate" attribute is the same as above.

After the modification is completed, save and exit. Return to the root directory of the SDK, and execute the following command to recompile the Linux kernel and generate the boot.img image:

If using the Linux SDK, the following command should be executed::

The generated image is stored in the directory "output/firmware/"

./build.sh alientek_quarkpi_ca2_defconfig

./build.sh kernel

If it is the Android SDK, then execute the following command:

The generated image is stored in the directory rockdev/Image-atk_quarkpi_ca2/

source build/envsetup.sh

lunch atk_quarkpi_ca2-userdebug

./build.sh -KA -J12

Burn the compiled boot.img onto the development board, then power on the development board. At this point, you will notice that the display direction of the logo has changed as follows:




Figure 1.2-4 Effect when not rotating (default)



Figure 1.2-5 Rotate clockwise by 90 degrees



Figure 1.2-6 Rotate clockwise by 180 degrees



Figure 1.2-7 Rotate clockwise by 270 degrees

1.3 Disable Logo Display

For example, to disable the MIPI screen logo display, you need to disable the route_dsi0 (corresponding to route_dsi1 for MIPI_DSI1) node. Enter the Linux kernel source code directory, open the device tree file rk3588s-atk-quarkpi-ca2.dts in the arch/arm64/boot/dts/rockchip directory (if it is an Android system, open rk3588s-atk-quarkpi-ca2.dts in the arch/arm64/boot/dts/rockchip directory), and add the following content at the end of the file:

```
// Disable the logo display of the MIPI DSI0 interface
```

```
&route_dsi0 {
    status = "disabled";
};

// Disable the logo display of the MIPI DSI1 interface
&route_dsi1 {
    status = "disabled";
};
```

```
6
7 /dts-v1/;
8
9 #include "rk3588s-atk-quarkpi-ca2.dtsi"
10 #include "rk3588s-atk-camera.dtsi"
11 #include "rk3588s-atk-screen_choose.dtsi"
12 #include "rk3588s-atk-lcds.dtsi"
13 #include "rk3588-linux.dtsi"
14
15 / {
16     model = "Rockchip RK3588S EVB8 LP4X V10 Board";
17     compatible = "rockchip,rk3588s-evb8-lp4x-v10", "rockchip,rk3588";
18 };
19
20 &route_dsi0 {
21     status = "disabled";
22 };
```

To disable the display of the HDMI screen logo, the route_hdmi0 node needs to be disabled as follows:

```
// Disable the logo display of the HDMI TX0 interface
&route_hdmi0 {
    status = "disabled";
};
```

After the modification is completed, save and exit. Return to the root directory of the SDK, and execute the following command to recompile the Linux kernel and generate the boot.img image:

```
# If using the Linux SDK, the following command should be executed:
# The generated image is stored in the directory "output/firmware/"
./build.sh alientek_quarkpi_ca2_defconfig
./build.sh kernel

# If it is the Android SDK, then execute the following command:
# The generated image is stored in the directory rockdev/Image-atk_quarkpi_ca2/
source build/envsetup.sh
lunch atk_quarkpi_ca2-userdebug
./build.sh -KA -J12
```

Burn the compiled boot.img onto the development board, then power on the board and start it. At this point, you will notice that the logo is no longer displayed.