

## SPARE PARTS / Parrot Disco / Camera

To replace the camera of the Parrot Disco, you need a T5 screwdriver, a T6 screwdriver, a PH2 screwdriver and a box cutter.

It is recommended to use the [Parrot Toolbox](#) for this operation.

# Parrot DISCO

DIFFICULTY  
LEVEL

