

**DisableIdle**                      Disable the Idle state

#include <Power.h>

**Power Manager**

void                      **DisableIdle**( void );  
                             **returns**            nothing

The **DisableIdle** procedure disables the idle state, even if the user has used the Portable control panel to enable the idle state. Every call to the **DisableIdle** procedure must be balanced by a call to the **EnableIdle** procedure before the idle state is reenabled.