

GetCPUSpeed

Return the current effective clock speed of the CPU

#include <Power.h>**Power Manager**long**GetCPUSpeed**(*void*);***returns*** Number of Ticks global variable

The **GetCPUSpeed** function returns the current effective clock speed of the CPU. The only values that are returned by this function are 1 and 16, indicating the clock speed in megahertz.