

GetWUTime

Get the current wakeup time settings

#include <Power.h>

Power Manager

OSErr **GetWUTime**(*WUTime*, *WUflag*);
long **WUTime* current wakeup timer setting
Byte **WUFlag* Timer flag (see below)
 returns

The **GetWUTime** function returns the current setting of the wakeup timer and indicates whether the wakeup timer is enabled.

The value returned by the *WUTime* parameter is the current setting of the wakeup timer specified as the number of seconds since midnight, January 1, 1904. If the low-order bit (bit 0) of the *WUFlag* parameter is set to 1, the wakeup timer is enabled. The other bits in the *WUFlag* parameter are reserved.