

EnableIdle Enable the Idle state

#include <Power.h>

Power Manager

void **EnableIdle**(void);
 returns nothing

The **EnableIdle** procedure cancels the effect of a call to the **DisableIdle** procedure. A call to the **EnableIdle** procedure enables the idle state only if the user has not used the Portable control panel to disable the idle state and if every call to the **DisableIdle** procedure has been balanced by a call to the **EnableIdle** procedure.