

Manual: Trial user limits

From MikroTik Wiki

Contents

- 1 Trial user bandwidth limitations
- 2 Configuration examples
- 3 Example in cli
- 4 Side notes
- 5 Example in cli

Applies
to
RouterOS: v6.34+



Trial user bandwidth limitations

Starting with RouterOS v6.34rc12 additional options for hotspot trial user bandwidth limitation are now added. The trial user now have it's own entry in user table: "default-trial". Same as for standard user entry you can apply bandwidth limitations for it:

- Limit uptime (Used if trial-uptime-limit in server profile is set to "0")
- Limit Bytes in
- Limit Bytes out
- Limit Bytes total

If only this one default-trial user entry is there. Then limits applied in it will be used for all of hotspot servers on this device. However if you have multiple hotspot servers running on the device and you want different trial user limits for each of them. Then what you need to do is to create individual user named "default-trial" each assigned to required server.

One additional field that is allowed for modification on this user is:

- Routes








Note: Rest of the fields default-trial user entry are read only and are not modifiable.

Configuration examples

Two "default-trial" users added in addition with one that is already added by system, which stays unmodified and dormant.

Static entries which you added will contain combined stats from all dynamically created trial users under them. And each dynamic user entry will only contain it own stats by mac-address to which it is assigned.

Hotspot

Servers	Server Profiles	Users	User Profiles	Active	Hosts	IP Bindings	Service Ports	Walled Garden	Walled Garden IP List	Cookies
<div><div><div><div></div><div></div><div></div><div></div><div></div><div></div></div><div><div>Reset Counters</div><div>00 Reset All Counters</div></div></div></div>										
Server	Name	...	MA...	Profile	Uptime	Bytes In	Packets In	Bytes Out	Packets Out	
;;; counters and limits for trial users										
 all	default-trial			default	00:00:00	0 B	0	0 B	0	
 all	test			default	00:00:00	0 B	0	0 B	0	
;;; counters and limits for trial users										
hotspot1.lan	default-trial			default	00:02:59	138.7 MiB	168 686	195.1 MiB	187 216	
D  hotspot1.lan	T-E8:50:8B:1C:95:7D	E8:...		default	00:02:30	137.8 MiB	150 786	148.3 MiB	154 342	
;;; counters and limits for trial users										
 hotspot2.lan	default-trial			default	00:00:36	46.0 MiB	49 958	49.4 MiB	48 374	
D  hotspot2.lan	T-E8:50:8B:1C:95:7D	E8:...		default	00:00:36	46.0 MiB	49 958	49.4 MiB	48 374	

6 items



Note: You can also type in limit values as "10M", "100M", etc.

Hotspot

Servers	Server Profiles	Users	User Profiles	Active
<div><div><div><div></div><div></div><div></div><div></div><div></div><div></div></div><div><div>Reset Counters</div><div>00 Reset All Counters</div></div></div></div>				
Server	Name	Address		
;;; counters and limits for trial users				
all	default-trial			
all	test			
;;; counters and limits for trial users				
hotspot1....	default-trial			
D hotspot1....	T-E8:50:8B:1C:95:7D			
;;; counters and limits for trial users				
hotspot2....	default-trial			
D hotspot2....	T-E8:50:8B:1C:95:7D			

6 items (1 selected)

Hotspot User <default-trial>

GeneralLimitsStatistics

Limit Uptime:

Limit Bytes In:

Limit Bytes Out:

Limit Bytes Total: 3000000000

OK

Cancel

Apply

Disable

Comment

Copy

Remove

Reset Counters

Reset All Counters

enabled

Example in cli



Note: You can also type in limit values as "10M", "100M", etc.

```
/ip hotspot user
add comment="counters and limits for trial users" limit-bytes-total=100000000 name=default-trial server=hotspot2.lan
add comment="counters and limits for trial users" limit-bytes-total=300000000 name=default-trial server=hotspot1.lan
```

```
[admin@LOW-hotspot] > /ip hotspot user print detail
Flags: * - default, X - disabled, D - dynamic
0 * ;;; counters and limits for trial users
   name="default-trial" limit-bytes-total=500000 uptime=0s bytes-in=0 bytes-out=0 packets-in=0 packets-out=0

1  name="test" password="test" profile=default uptime=0s bytes-in=0 bytes-out=0 packets-in=0 packets-out=0

2  ;;; counters and limits for trial users
   server=hotspot2.lan name="default-trial" password="" profile=default limit-bytes-total=100000000 uptime=36s
   bytes-in=48198739 bytes-out=51814030 packets-in=49958 packets-out=48374

3  ;;; counters and limits for trial users
   server=hotspot1.lan name="default-trial" password="" profile=default limit-bytes-total=300000000 uptime=2m59s
   bytes-in=145477719 bytes-out=204557092 packets-in=168686 packets-out=187216

4 D server=hotspot2.lan name="T-E8:50:8B:1C:95:7D" password="" mac-address=E8:50:8B:1C:95:7D profile=default limit-upt
   limit-bytes-total=100000000 uptime=36s bytes-in=48198739 bytes-out=51814030 packets-in=49958 packets-out=48374


5 D server=hotspot1.lan name="T-E8:50:8B:1C:95:7D" password="" mac-address=E8:50:8B:1C:95:7D profile=default limit-upt
   limit-bytes-total=300000000 uptime=2m30s bytes-in=144501472 bytes-out=155509849 packets-in=150786 packets-out=1543
```

Side notes

such settings for trial user as:

- Trial uptime limit
- Trial uptime reset
- Trial user profile

You still configure in each of specific hotspot server profile entries under which you will be using this trial profile.



Example in cli

```
/ip hotspot profile set (number or profile-name) trial-uptime-limit=00:30:00 trial-uptime-reset=1d trial-user-profile=
```

[\[Top | Back to Content \]](#)

Retrieved from "https://wiki.mikrotik.com/index.php?title=Manual:Trial_user_limits&oldid=27628"

Categories: [Manual](#) | [Hotspot](#) | [IP](#) | [Examples](#)

- This page was last edited on 2 December 2015, at 13:33.