

TI81XX PSP UBOOT User Guide



TI81XX PSP UBOOT User Guide

Linux PSP

IMPORTANT

TI81XX refers to TI816X, TI814X and TI813X.

Read This First

This section show the major updates since last release, please review this section before any SW activities.

TI816X& TI814X

- If the previous Uboot used a different ECC scheme from the default ECC present in the current release, erase all images (and the environment if applicable) that were flashed on to NAND and re-flash the images with the new ECC scheme.

TI813X

If the previous Uboot used a different ECC scheme from the default ECC present in the current release, erase all images (and the environment if applicable) that were flashed on to NAND and re-flash the images with the new ECC scheme.

U-Boot

On TI81XX platform, the ROM code serves as the first stage bootloader while the U-Boot^[1] serves as the 2nd stage bootloader. The bootloader does the bare minimum configuration needed to boot the kernel and in the process relocates itself to DDR.

TI816X In case of NAND/SPI/SD boot mode, the ROM code loads the U-Boot image from the flash memory into OCMC RAM. In case of NOR boot mode, the ROM code passes the control to the U-Boot image in NOR memory after some basic initialization and starts execution(Xecute In Place).

Size of U-Boot (TEXT + BSS section) cannot exceed 255KB

Note

To avoid over-writing U-Boot when it is executing make sure that an address greater than 0x80800000 is used when downloading the kernel and/or filesystem images

TI814X/TI813X The ROM code loads the U-Boot-MIN image from the flash memory/SD card into OCMC RAM0. U-Boot-MIN does the basic configuration like setting up the clocks, initializing the necessary peripherals and then loads the U-Boot image from NAND,SPI/SD or UART.

Note

1. Please note the difference in the U-Boot prompt for the 2 stages. The 1st stage prompt is TI-MIN# while that for the 2nd stage is TI8148_EVM#. The prompt specified in the commands is meant to serve as an indication of which stage it should be executed from. Most of the commands mentioned in the doc are meant to be executed from the 2nd stage.

2. NOR boot has only two stages of bootloader. ROM code serves as the 1st stage bootloader and the u-boot serves as the second stage boot loader. U-boot min is not required here as the NOR is XIP and hence the complete u-boot binary can be placed in the NOR flash.

Two stage U-Boot design

This section gives an overview of the two stage U-Boot approach adopted for TI814X and TI813X.

The size of the internal RAM in TI814X is 128KB out of which 18KB at the end is used by the ROM code. This placed a limit of 110KB on the size of the U-Boot binary which the ROM code can transfer to the internal RAM.

U-Boot also requires some space for the stack, heap and global data during executing and this region currently needs to be setup **before** the TEXT_BASE of U-Boot.

Since it is not possible to squeeze in all the functionality that is normally expected from U-Boot in < 110KB (after setting aside some space for stack, heap etc) a two stage approach has been adopted.

The first stage (or rather the 2nd stage if the ROM code is also considered) is built using a minimal configuration and has an embedded ENV. The purpose of this stage is to initialize the necessary peripherals, especially DDR, so that a full fledged U-Boot can be transferred to DDR from NAND/SPI/SD/UART/NOR and then control passed to it.

The boot command that the minimal U-Boot uses for fetching the larger U-Boot will not change for a particular boot mode as long as the same layout is used and is hence fixed. If any other behavior required then the minimal U-Boot stage can be interrupted and a different command issued.

The minimal U-Boot binary also has a hole at the top which is used as the space for stack, heap and global data. After some analysis the size of the hole has currently been set as 12KB.

Note

To avoid over-writing U-Boot when it is executing make sure that an address greater than 0x80800000 is used when downloading the kernel and/or filesystem images

U-Boot Support for DDR2/DDR3 Boards

TI814X/TI813X

The u-boot will automatically select the DDR2/DDR3 configurations at run-time. TI813X only supports DDR3 EVM's.

Automatic DDR2/DDR3 Selection

U-Boot will detect the PG version at run-time and will select DDR2/DDR3 automatically. We will assume that all PG1.0 Version uses DDR2 and PG2.1 will use DDR3.

Note

To use PG2.1 with DDR2 support, un-comment the macro "#define CONFIG_TI814X_EVM_DDR2" in file "include/configs/ti8148_evm.h" that will forcefully select DDR2 support.

TI816X

The pre-built U-Boot binaries that comes in the release package has been built for DDR3 based EVM and the configuration is for **DDR3@400MHz** I/O clk. The binaries MLO and u-boot.bin are meant for SD boot and u-boot.noxip.bin is for flashing to NAND. If you have a DDR3 based EVM and wish to use the pre-built U-Boot image for flashing to NAND or if you want to use SD boot proceed to the Flashing U-Boot section

Modifying U-Boot for DDR2

This section described how to modify the U-Boot source to enable DDR2 support.

- Open the file *arch/arm/include/asm/arch-ti81xx/clocks_ti816x.h* and modify the #define as shown below

```
#define DDR_PLL_400      /* Values supported 400,531,675,796 */
```

- Open the file *include/configs/ti8168_evm.h* and make sure that the config option for DDR2 is not commented and that for DDR3 is commented out as shown below

```
[...]
//#define CONFIG_TI816X_EVM_DDR3          /* Configure DDR3 in U-Boot */
#define CONFIG_TI816X_EVM_DDR2          /* Configure DDR2 in U-Boot */
[...]
```

Modifying U-Boot DDR3 frequency

This section described how to modify the U-Boot source to change the DDR3 frequency on TI816X EVMs. Currently the following are the supported frequencies on the TI816X EVM.

- 400MHz
- 531MHz
- 675MHz
- 796MHz

The default configuration is for DDR3@796MHz.

- Open the file *arch/arm/include/asm/arch-ti81xx/ddr_defs.h* and modify the number in the #define shown below to the required frequency.

```
#define CONFIG_TI8168_DDR3_796      /* Values supported 400,531,675,796 */
```

- Open the file *arch/arm/include/asm/arch-ti81xx/clocks_ti816x.h* and modify the number in the #define shown below to the required frequency. The number used here should be the same as the that in the previous step.

```
#define DDR_PLL_796      /* Values supported 400,531,675,796 */
```

- Open the file *include/configs/ti8168_evm.h* and make sure that the config option for DDR3 is not commented and that for DDR2 is commented out as shown below

```
[...]
#define CONFIG_TI816X_EVM_DDR3          /* Configure DDR3 in U-Boot */
//#define CONFIG_TI816X_EVM_DDR2          /* Configure DDR2 in U-Boot */
[...]
```

Once these changes are done, recompile U-Boot as described in this User-Guide.

Changing ARM core Frequency

TI816X

The ARM core is configured to run at 1 GHz by default in the u-boot. TI816X support ARM running at 1GHz and 1.2 GHz The selection can be done by modifying the macro **ARM_PLL_987/1200** based on the Frequency required defined in arch/arm/include/asm/arch-ti81xx/clocks_ti816x.h

Building U-Boot

U-Boot Configurations

1st stage u-boot configurations

Boot Modes	Output File	TI816x	TI814x	TI813x(DM385)
NAND	u-boot.min.nand	single stage*	ti8148_evm_min_nand	ti813x_evm_min_nand
SPI	u-boot.min.spi	single stage*	ti8148_evm_min_spi	ti813x_evm_min_spi
NOR	NA	single stage*	NA	NA
SD	u-boot.min.sd***	ti8168_evm_min_sd	ti8148_evm_min_sd	ti813x_evm_min_sd
UART	u-boot.min.uart	Not supported	ti8148_evm_min_uart	ti813x_evm_min_uart
EMAC	u-boot.min.eth	single stage*	ti8148_evm_min_eth	ti813x_evm_min_eth

* Single stage u-boot support, Please refer 2nd stage configs

** use dm385_ instead of ti813x_ as prefix for PSP_04.04.00.01 and older release versions

*** The file u-boot.min.sd for SD boot needs to be renamed to MLO.

2nd stage u-boot configurations

Boot Modes	Output File	TI816x	TI814x	TI813x(DM385)
NAND	u-boot.nohip.bin (TI816x)	ti8168_evm_config_nand	ti8148_evm_config_nand	ti813x_evm_config_nand
	u-boot.bin (TI814x/Ti813x)			
SPI	u-boot.nohip.bin.spi (TI816x)	ti8168_evm_config_spi	ti8148_evm_config_spi	ti813x_evm_config_spi
	u-boot.bin (TI814X/Ti813X)			
NOR	u-boot.bin	ti8168_evm_config_nor	ti8148_evm_config_nor	ti813x_evm_config_nor
SD**	u-boot.bin	ti8168_evm_config_sd	ti8148_evm_config_sd	ti813x_evm_config_sd
UART	NA	Not supported	use NAND/SPI/SD	use NAND/SPI/SD
EMAC	u-boot.bin	use NAND/SPI/SD	use NAND/SPI/SD	use NAND/SPI/SD

** use dm385_ instead of ti813x_ as prefix for PSP_04.04.00.01 and older release versions

** Environment variable in MMC/SD support and the build configurations is only applicable to

PSP_04.01.00.07/PSP_04.00.02.13 or higher Release.Older versions of u-boot must use NAND or SPI images for 2nd stage SD.

U-Boot supports saving environment variables to NAND, SPI, NOR or MMC. The media to be used for saving the ENV variables needs to be decided before building U-Boot. The environment variables will be saved in the media for which the second stage u-boot is built.

Building 1st stage u-boot

The first stage u-boot images except SD boot are only applicable to TI814X series .

Different boot modes have different requirements for the U-Boot-MIN stage.

- When using memory boot (NAND/SPI) a header needs to be attached to the U-Boot binary indicating the the load address and the size of the image. SPI boot also requires endian conversion before flashing the image.
- When using peripheral boot (UART,EMAC) there can be no header as the load address is fixed.
- Header is not required in case of XIP (NOR)

For easy generation of the different images, different target names have been provided in the Makefile. The different target names take care of building the appropriate image (with or without the header and with or without endian conversion).

Please note that the U-Boot-MIN stage uses a pre-defined command to load the 2nd stage and does not support commands such as dhcp, tftp, saveenv etc. All the commands are available only from the 2nd stage of U-Boot which the 1st stage U-Boot autoloads (if present).

```
$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm distclean
$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm <1st stage config from table *>
$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm u-boot.ti
```

- example ti8148_evm_min_nand , dm385_evm_min_sd

Note: The first stage binary(u-boot.min.sd) generated for the SD boot mode needs to be renamed to "MLO" before copying to the SD card.

Building 2nd stage u-boot

NOR boot mode is only applicable for TI816X

The 2nd stage of U-Boot supports saving environment variables to NAND, SPI or SD Card. The media to be used stored for saving the ENV variables needs to be decided before building the 2nd stage of U-Boot.

```
$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm distclean
$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm <2nd stage config from the table*>
$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm u-boot.ti
```

- example ti8168_evm_config_nand , ti813x_evm_config_sd

U-Boot quick-boot configurations for SD

Quick boot configurations

Boot Modes	Output File	TI816x	TI814x	TI813x(DM385)
1st stage SD	u-boot.min.sd	ti8168_evm_config_quick_mmc_min	ti8148_evm_config_quick_mmc_min	NA
2nd stage SD	u-boot.bin	ti8168_evm_config_quick_mmc	ti8148_evm_config_quick_mmc	NA

```
$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm distclean
$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm <1/2nd stage config from table>
$ make CROSS_COMPILE=arm-none-linux-gnueabi- ARCH=arm u-boot.ti
```

Quick-boot enable a faster booting using the SD card images . Quick boot removed the boot delay and suppress the console message from the u-boot. It uses a separate configuration file "include/configs/ti8168_evm_quick_mmc.h" for building the quick-boot images.Please follow the steps to build 1st stage quick-boot images for mmc and rename

it to "MLO".

The 2nd stage quick-boot images for mmc is generated from the same quick-boot config file "include/configs/ti8168_evm_quick_mmc.h". The u-boot image will load the kernel from the sd card. The env "quite" is passed by default from the u-boot. Normal messages about hardware detection at boot are suppressed, only important and system critical kernel messages are printed to the console. It also avoids the boot delay by setting it to 0.

This will generate binaries named **u-boot.nohip.bin** and **u-boot.bin**. Use u-boot.bin for boot from mmc.

Refer this DM81XX_Quick_Boot_Measurements for more information.

Serial port configuration

Connect a serial cable from the serial port of the EVM (there are two serial ports on the EVM, use the one which is next to the MMC/SD slot) to the COM port on either the Windows machine or Linux host depending on where you'll be running the serial terminal software.

For correct operation the serial terminal software should be configured with the following settings:

```
* Baud rate: 115,200
* Data bits: 8
* Parity: None
* Stop bits: 1
* Flow control: None
* Transmit delay: 0 msec/char, 100 msec/line
```

If Teraterm is being used ensure that the latest version (4.67) of Teraterm is installed. The implementation of the kermit protocol in Teraterm is not reliable in older versions. The latest version of Teraterm 4.67 can be downloaded from here ^[2]

EVM Switch Settings

	SW-1/SW-3					SW-2/SW-4/SW-5*				
Boot Mode	BTM 4	BTM 3	BTM 2	BTM 1	BTM 0	NAND	SPI			
NAND	1	0	0	1	0	1	X			
SPI	1	0	1	1	0	X	1			
UART	0	0	0	0	1	X	X			
SD	1	0	1	1	1	X	X			
NOR	1	0	0	0	0	0	X			
EMAC	0	0	1	0	0	X	X			

Note: * NAND/SPI enable switch TI8168 SW4 [1:2] TI8148 SW2 [1:2] TI813X SW5 [1:2]

EMAC ROM Phy Mode selection SW9---> BTM[9:8]

BTMODE[9:8]	PHY Mode
00b	MII/GMII
01b	RMII
10b	RGMII
11b	reserved

Note: **TI816X NOR** Daughter Card (RevA) SW1---->SW1[3:0] ==> 0001 IODC (RevA) and other Daughter Cards (RevB) SW1---->SW1[3:0] ==> 0011

TI816X

The picture below captures the boot mode configuration switch SW3 on the TI8168 EVM. **NOTE** : The bootmode setting in this picture is for NAND boot.

NAND BOOT MODE SW-3[9:0] 0000010010 SW-4[1:0] 10 [NAND/SPI]

TI814x/TI813X

The picture below captures the boot mode configuration switch SW1 on the TI8148 EVM. **NOTE** : The bootmode setting in this picture is for NAND boot.

NAND BOOT MODE SW-1[11:0] 000000010010 SW-2[1:0] 10 [NAND/SPI]

Make sure that the EVM boot switch settings are set to the required boot mode and then power on the board.

Flashing U-Boot using CCS

PLEASE NOTE: BOTH THE STAGES OF U-BOOT NEED TO BE FLASHED ON THE SAME MEDIA

You can flash the **1st stage** of U-Boot onto NAND (for NAND boot) or to SPI (SPI Boot) using the Flashing Tools provided in the PSP releases.

Refer to Flashing to NAND Flash using CCS wiki page for instructions on how to flash the pre-built (or compiled) binary of the 1st stage for NAND boot i.e. u-boot.min.nand (or the recompiled one) with the help of the NAND flash writer.

Refer to Flashing to SPI Flash using CCS wiki page for instructions on how to flash the pre-built (or compiled) binary of the 1st stage for SPI boot i.e. u-boot.min.spi (or the recompiled one) with the help of the SPI flash writer.

Refer to Flashing to NOR Flash using CCS wiki page for instructions on how to flash the pre-built (or compiled) binary for NOR boot i.e. u-boot.bin (or the recompiled one) with the help of the NOR flash writer.

Note

NOR boot has only two stages of boot loader - ROM boot loader and u-boot. There is no u-boot min binary for NOR as in the case of other boot modes.

Once the 1st stage U-Boot has been flashed using the flashing tool

1. Load the 2nd stage U-Boot over UART as described here.
2. Flash the 2nd stage of U-Boot to either NAND using the steps over here or to SPI using the steps over here.
3. After flashing the 2 stages use the appropriate switch settings to boot from NAND or from SPI.

Flashing U-Boot without CCS

PLEASE NOTE: BOTH THE STAGES OF U-BOOT NEED TO BE FLASHED ON THE SAME MEDIA

It is possible to flash U-Boot from a U-Boot binary already loaded into RAM. This technique can be used for flashing U-Boot in case CCS is not available.

A couple of ways in which this can be achieved is mentioned below.

TI816X

TI816X support SD Flash and EMAC Flash. Please follow the steps.

SD-Flash-Method

This method involves booting from SD card and then flashing the U-Boot image to NAND or SPI as required.

1. Boot from the SD card using the steps described here
2. Flash the U-Boot binary either to NAND using the steps over here or to SPI using the steps over here.
3. After flashing use the appropriate switch settings to boot from Boot Pin.

EMAC-Flash-Method

This method involves using EMAC boot mode to get to the U-Boot prompt and then flashing the U-Boot image to NAND or SPI as required.

1. Boot over network using the steps described here.
2. Make sure the network configuration has been done as described over here.
3. Flash the U-Boot binary either to NAND using the steps over here or to SPI using the steps over here.
4. After flashing use the appropriate switch settings to boot from Boot Pin.

TI814X/TI813X

TI814X supports Flashing over UART and SD methods. Please follow the steps.

UART-Flash-Method

1. Boot over UART to load the 1st stage of U-Boot as described over here. Make sure that you interrupt the countdown in the 1st stage i.e. at the **TI-MIN#** prompt.
2. Load the 2nd stage of U-Boot over UART as described over here.
3. Flash the 1st stage of U-Boot to either NAND using the steps over here or to SPI using the steps over here.
4. Flash the 2nd stage of U-Boot to either NAND using the steps over here or to SPI using the steps over here.
5. After flashing the 2 stages use the appropriate switch settings to boot from NAND or from SPI.

SD-Flash-Method

Make sure the two binaries for NAND boot (u-boot.min.nand and u-boot.bin) or for SPI boot (u-boot.min.spi and u-boot.bin) which are required for flashing are present on the SD. Please refer to the section of building U-Boot to generate the images.

1. Boot using SD card to load both the 1st stage and the 2nd stage as described over here. Do not interrupt the countdown till the **TI8148_EVM#** prompt comes.
 2. Flash the 1st stage of U-Boot to either NAND using the steps over here or to SPI using the steps over here.
 3. Flash the 2nd stage of U-Boot to either NAND using the steps over here or to SPI using the steps over here.
 4. After flashing the 2 stages use the appropriate switch settings to boot from NAND or from SPI.
-

U-Boot NAND Support

Before proceeding with any of the commands given in this section please make sure that NAND is enabled on the EVM. The switch for enabling NAND is shown over here.

This section gives an *overview* of the NAND support in U-Boot. It also describe how to store the kernel image, RAMDISK or the JFFS2/UBIFS filesystem to NAND so as to have a network-free boot right from powering on the board to getting the kernel up and running.

Overview

Micron Nand parts (page size 2KB, block size 128KB) are supported on TI81XX EVM platforms.

Note

- The following sub-sections illustrate the usage of NAND specific commands on TI816X, TI814X and TI813X EVMs.
- If u-boot is built with NAND support and if NAND is disabled in the EVM (or NOR is enabled) then u-boot will crash immediately after displaying the banner. Refer to EVM Switch Settings section for more info on enabling/disabling different boot devices.

NAND Layout

The NAND part on the EVM has been configured in the following manner. The addresses mentioned here are used in the subsequent NAND related commands.

TI816X

```
+-----+-->0x00000000-> U-Boot start
|
|
|
|
|
|    |-->0x0025FFFF-> U-Boot end
|    |-->0x00260000-> ENV start
|
|
|    |-->0x0027FFFF-> ENV end
|    |-->0x00280000-> Linux Kernel start
|
|
|
|
|    |-->0x006BFFFF-> Linux Kernel end
|    |-->0x006C0000-> Filesystem start
|
|
|
|
|
|
|
|
|
|
```

```

|
|
|      |-->0x0CEDFFFF-> Filesystem end
|      |-->0x0CEE0000-> Free start
|
|
|
|
+-----+-->0x10000000-> NAND end (Free end)

```

TI814X/TI813X

```

+-----+-->0x00000000-> U-Boot 1st stage start
|
|
|      |-->0x0001FFFF-> U-Boot 1st stage end
|      |-->0x00020000-> U-Boot 2nd stage start
|
|
|      |-->0x0025FFFF-> U-Boot 2nd stage end
|      |-->0x00260000-> ENV start
|
|
|
|      |-->0x0027FFFF-> ENV end
|      |-->0x00280000-> Linux Kernel start
|
|
|
|
|
|      |-->0x006BFFFF-> Linux Kernel end
|      |-->0x006C0000-> Filesystem start
|
|
|
|
|
|
|
|
|
|      |-->0x0CEDFFFF-> Filesystem end
|      |-->0x0CEE0000-> Free start
|
|
|
+-----+-->0x10000000-> NAND end (Free end)

```

Writing to Nand

To write len bytes of data from a memory buffer located at addr to the NAND block offset:

```
TI8168_EVM# nand write <addr> <offset> <len>
```

If a bad block is encountered during the write operation, it is skipped and the write operation continues from next 'good' block.

For example, to write 0x40000 bytes from memory buffer at address 0x80000000 to NAND - starting at block 32 (offset 0x400000):

```
TI8168_EVM# nand write 0x80000000 0x400000 0x40000
```

Reading from Nand

To read len bytes of data from NAND block at a particular offset to the memory buffer in DDR located at addr:

```
TI8168_EVM# nand read <addr> <offset> <len>
```

If a bad block is encountered during the read operation, it is skipped and the read operation continues from next 'good' block.

For example, to read 0x40000 bytes from NAND - starting at block 32 (offset 0x400000) to memory buffer at address 0x80000000:

```
TI8168_EVM# nand read 0x80000000 0x400000 0x40000
```

Marking a bad block

Some of the blocks in the NAND may get corrupted over a period of time. In such cases you should explicitly mark such blocks as bad so that the image that you are writing to NAND does not end up getting corrupted.

To forcefully mark a block as bad:

```
TI8168_EVM # nand markbad <offset>
```

For example, to mark block 32 (assuming erase block size of 128Kbytes) as bad block - offset = blocknum * 128 * 1024:

```
TI8168_EVM# nand markbad 0x400000
```

Viewing bad blocks

To view the list of bad blocks:

```
TI8168_EVM# nand bad
```

Note

The user marked bad blocks can be viewed by using this command only after a reset.

Erasing Nand

To erase NAND blocks in a particular the address range or using block numbers:

```
TI8168_EVM# nand erase <stoffsaddr> <len>
```

This commands skips bad blocks (both factory or user marked) encountered within the specified range.

For example, to erase blocks 32 through 34:

```
TI8168_EVM# nand erase 0x00400000 0x40000
```

NAND ECC algorithm selection

NAND flash memory, although cheap, suffers from problems like bit flipping which lead to data corruption. However by making use of some error correction coding (ECC) techniques it is possible to workaround this problem.

For the data stored in NAND flash, U-Boot supports following NAND ECC schemes

1. S/W ECC (Hamming code)
2. H/W ECC (Hamming code, BCH4, BCH8, BCH16)

NOTE: Current releases do not support BCH4 and BCH16.

BCH Flash OOB Layout

For any ECC scheme we need to add some extra data while writing so as to detect and correct (if possible) the errors introduced by the NAND part. In case of BCH scheme some bytes are needed to store the ECC related info.

The section of NAND memory where addition info like ECC data is stored is referred to as Out Of Band or OOB section.

The first 2 bytes are used for Bad block marker – 0xFFFF => Good block

The next 'N' bytes is used for BCH bytes

$N = B * \text{<Number of 512-byte sectors in a page>}$

B = 8 bytes per 512 byte sector in BCH4

B = 14 bytes per 512 byte sector in BCH8

B = 26 bytes per 512 byte sector in BCH16

So for a 2k page-size NAND flash with 64-byte OOB size, we will use BCH8. This will consume $2 + (14*4) = 58$ bytes out of 64 bytes available.

The NAND flash part used in EVM does not have enough spare area to support BCH16.

ECC Schemes and their context of usage

ECC type	Usage
S/W ECC	Not used
H/W ECC - Hamming Code	Not used by default. Switch back to this only if using JFFS2 file system.
H/W ECC – BCH8	Used by default to flash any image from the Uboot. Environment variables are also stored in this ECC scheme.

To select ECC algorithm for NAND:

```
TI8168_EVM# nandecc [sw | hw <hw_type>]
```

Usage:

```
sw - Set software ECC for NAND
hw <hw_type> - Set hardware ECC for NAND
<hw_type> - 0 for Hamming code
             1 for bch4
             2 for bch8
             3 for bch16
```

Currently we support only Software, Hamming Code and BCH8. We do not support BCH4 and BCH16

Transferring images to NAND via U-Boot

Note

When updating any partition in NAND, please erase the complete partition and not just the space needed by the image which will be transferred onto NAND

Make sure the EVM is connected to network. This is required to get Linux Image from a tftp server. If there is no DHCPserver in the network then use static ip. The section on U-Boot network configuration gives commands for doing this.

Make sure tftp server is running in a windows PC and the home directory for the tftp server has Linux kernel uImage. This windows PC should be accessible from the EVM.

Flashing U-Boot from U-Boot

TI816X

To flash u-boot image (u-boot.noxip.bin) to NAND execute the commands listed below:

```
TI8168_EVM# mw.b 0x81000000 0xFF 0x260000
TI8168_EVM# tftp 0x81000000 u-boot.noxip.bin
TI8168_EVM# nand erase 0x0 0x260000      <=== Erasing the whole partition before flashing the image
TI8168_EVM# nand write.i 0x81000000 0x0 0x260000
```

The above set to commands, fill in the section of memory starting from 0x81000000 with size 0x260000 with 0xFF. In TI816X EVM this memory region is a part of the DDR memory.

Next we download the U-Boot image (u-boot.noxip.bin) to the DDR memory.

To have persistent storage we then transfer the downloaded U-Boot image to NAND with the help of the NAND commands described earlier.

TI814X and TI813X

1st Stage:

```
TI8148_EVM# nand erase 0x0 0x20000      <=== Erasing the whole partition before flashing the image
TI8148_EVM# tftp 0x81000000 u-boot.min.nand
TI8148_EVM# nand write.i 0x81000000 0x0 0x20000
```

2nd Stage:

```
TI8148_EVM# nand erase 0x20000 0x60000  <=== Erasing the whole partition before flashing the image
TI8148_EVM# tftp 0x81000000 u-boot.bin
TI8148_EVM# nand write.i 0x81000000 0x20000 0x60000
```

Flashing Linux Kernel from U-Boot

TFTP the kernel uImage to DDR.

TI816X

```
TI8168_EVM# mw.b 0x81000000 0xFF 0x440000
TI8168_EVM# tftp 0x81000000 <kernel_image>
```

Now flash the kernel image to NAND at the appropriate offset (refer to NAND layout section for the offsets)

```
TI8168_EVM# nand erase 0x00280000 0x00440000 <== Erasing the whole partition before flashing the image
TI8168_EVM# nand write 0x81000000 0x00280000 <image_size> (example, 0x200000)
```

TI814X and TI813X

```
TI8148_EVM# tftp 81000000 <kernel_image>
```

Now flash the kernel image to NAND at the appropriate offset (refer to NAND layout section for the offsets)

```
TI8148_EVM# nand erase 0x00280000 0x00440000
TI8148_EVM# nand write 0x81000000 0x00280000 <image_size> (example, 0x200000)
```

Creating UBIFS File-System

Refer to UBIFS Support guide

Creating JFFS2 File-system

Since jffs2 is used only on flash devices, a standard Linux distribution does not have the tools to make a jffs2 file system. Refer MTD_Uutilities wiki page for instructions on how to create JFFS2. mkfs.jffs2 is the tool needed to build a jffs2 file system and the source is in this code. All of the MTD code will be downloaded but only the code to build mkfs.jffs2 is built.

With the mkfs.jffs2 utility built and in place it is now time to make the jffs2 file system from of the target directory. Change to the /home/user directory and enter the mkfs.jffs2 command below. Probably the most important argument to the utility is the erase block size. For the NAND part on the TI8168 EVM board the erase block is 128k Consult either u-boot, the kernel, or the data manual for the flash part used to find the erase block size.

```
[root@localhost util]# cd /home/user
[root@localhost util]# mkfs.jffs2 -lqn -e 128 -r target -o /tftpboot/rd-jffs2.bin
```

By building the file in the /tftpboot directory, the step of copying it over is eliminated. The file must now be written into flash at a specific location. In u-boot, the flash file system will get flashed to the physical address 0x6c0000 and will be mounted by the kernel from /dev/mtdblock<partition-number>, partition-number starts from 0, refer flash layout for individual flash devices and partition creation order for exact number. Use 'cat /proc/partitions' at Linux prompt for the list of partitions.

After identifying the partition, unprotect the flash area where the file system will reside, erase that area. Download the rd-jffs2.bin file. Write it to flash. Modify bootargs to support a JFFS2 file system as root on /dev/mtdblock<partition-number>. Save the environment variables.

Flashing File-system from U-Boot

First TFTP the filesystem image (example - rootfs-base.jffs2 or ubi.img) to DDR.

TI816X

```
TI8168_EVM# mw.b 0x81000000 0xFF 0x0C820000 <=== Required to get rid of "Empty Flash" JFFS2 warnings while booting.
TI8168_EVM# tftp 0x81000000 <filesystem_image>
```

Flash the file system image to NAND using the appropriate offsets

```
For UBIFS file system:
TI8168_EVM# nand erase 0x006C0000 0x0C820000 <=== Erasing the whole partition before flashing the image

For JFFS2 file system:
TI8168_EVM# nand erase clean 0x006C0000 0x0C820000 <=== Erasing the whole partition before flashing the image

TI8168_EVM# nand write 0x81000000 0x006C0000 <image_size> <=== Example, 0x01040000
NOTE: The image size should be upward aligned to NAND page size which is 2KiB (i.e. 0x800).
For example, if the image size is 0x19B8004 the size to be passed to the NAND write
command should be 0x19B8800.
```

TI814X and TI813X

TI8148_EVM# mw.b 0x81000000 0xFF 0x0C820000 <=== This is required to get rid of "Empty Flash" JFFS2 during kernel boot.

```
TI8148_EVM# tftp 0x81000000 <filesystem_image>
```

Flash the file system image to NAND using the appropriate offsets

```
For JFFS2 file system:
TI8148_EVM# nand erase clean 0x006C0000 0x0C820000 <=== Erasing the whole partition before flashing the image

For UBIFS file system:
TI8148_EVM# nand erase 0x006C0000 0x0C820000 <=== Erasing the whole partition before flashing the image

TI8148_EVM# nand write 0x81000000 0x006C0000 <image_size> <=== Example, 0x01040000
NOTE: The image size should be upward aligned to NAND page size which is 2KiB (i.e. 0x800).
For example, if the image size is 0x19B8004 the size to be passed to the NAND write
command should be 0x19B8800.
```

Also, refer [[3]] for information on JFFS2 error/warning messages.

U-Boot NOR Support

This section gives an *overview* of the NOR support in U-Boot. It also describe how to store the kernel image, RAMDISK or the JFFS2 filesystem to NOR so as to have a network-free boot right from powering on the board to getting the kernel up and running.

Overview

Important

Please note that the U-Boot commands used in this section is applicable only from a U-Boot which is already running from NOR. Please refer to the [Flashing Tools](#) page for flashing the U-Boot image to NOR using CCS for the first time.

- This section details on the NOR support available in TI816X & TI814X
- ROM Code always uses XIP for NOR boot.
- ROM Code initializes only 12 GPMC address lines (gpmc_a0 - gpmc_a11) hence it can access only first 4KBytes of the NOR.

NOR Porting guide

Refer to **NOR Porting guide** for interfacing NOR on various daughter boards to DM81xx

Board Modification

Following board modifications have to be done in the Catalogue board (CATA_x) / Base Board for NOR to work.

1. catalog board: Replace the resistor R230 in the with 0-ohm

This is required for NOR XIP (Execute in place) to work.

NOTE:

Without the above board modification(1), NOR boot will not work.

2. TI8148 Base board: Remove the resistors R410, R248 and populate R242,R229(Both values are 22 ohms)

This is required to access the entire NOR memory. NOR address lines (A22 and A23) and HDMI lines are shared.

- Populating the resistors R410, R248 (Both are 22 ohms) will enable HDMI
- Populating the resistors R242, R229 (Both are 22 ohms) will enable NOR

2. TI813X Base board: Remove the resistors R527, R302and populate R242,R229(Both values are 22 ohms)

This is required to access the entire NOR memory. NOR address lines (A22 and A23) and HDMI lines are shared.

- Populating the resistors R527, R302(Both are 22 ohms) will enable HDMI
- Populating the resistors R297, R286(Both are 22 ohms) will enable NOR

By default, resistors are populated for HDMI and CE_REMOTE enabled. This puts limitation on the size of NOR memory that can be accessed. With HDMI and CE_REMOTE enabled, NOR device lines A22 and A23 cannot be used and hence the maximum addressable memory is $2^{22} = 4$ MB. Hence, if the entire NOR memory has to be accessed, then the above modification (2) has to be done.

NOTE: HDMI and CE_REMOTE will not work after this modification(2).

NOR Pin Muxing Info for EVM

TI816x

- Pin muxing is done only for lines gpmc_a12 to gpmc_a25 using the following lines

```
gpmc_a12 -----> tim7_out
gpmc_a13 -----> uart1_ctsn
gpmc_a14 -----> uart1_rtsn
gpmc_a15 -----> uart2_rtsn
gpmc_a16 -----> uart2_ctsn
gpmc_a17 -----> uart0_rin
gpmc_a18 -----> uart0_dcdn
gpmc_a19 -----> uart0_dsrn
gpmc_a20 -----> uart0_dtrn
gpmc_a21 -----> spi_scs3
gpmc_a22 -----> spi_scs2
gpmc_a23 -----> gpo_io6
gpmc_a24 -----> tim6_out
gpmc_a25 -----> sc0_data
gpio0_20 -----> gpmc_a27
```

- gpmc_a27 should be configured as gpio0_20 and its output should be set low.
- For the above pad configuration we cannot use below mentioned modules
 - Smart Card 0
 - Advanced features of uart0/1/2
 - spi cs 2/3
 - timer 6/7 output

TI814x

- Pin muxing for remaining address lines are done by u-boot as given below

```
gpmc_a12 -----> vout0_fid_mux1
gpmc_a13 -----> vout1_g_y_yc2
gpmc_a14 -----> vout1_r_cr3
gpmc_a15 -----> vout1_r_cr2
gpmc_a16 -----> gpmc_a16
gpmc_a17 -----> gpmc_a17
gpmc_a18 -----> gpmc_a18
gpmc_a19 -----> gpmc_a19
gpmc_a20 -----> gpmc_a_20_mux0
gpmc_a21 -----> gpmc_a_21_mux0
gpmc_a22 -----> gpmc_a_22_mux0
gpmc_a23 -----> gpmc_a_23_mux0
gpmc_a24 -----> gpmc_cs2
gpmc_a25 -----> gpmc_cs1
gpio1_22 -----> mmc2_dat4
```


- gpmc_a27 should be configured as gpio1_22 and its output should be set low.
- For the above pad configuration we cannot use the following modules
 - video

NOR Support

- The NOR boot logic is handled in **arch/arm/cpu/arm_cortexa8/ti81xx/lowlevel_init.S**
- Since ROM code does not initialize all 25 address lines required for accessing 64MBytes, u-boot should first initialize GPMC to continue with the XIP beyond 4KBytes.
- u-boot should also configure pin muxing for the remaining 13 address lines (gpmc_a12 - gpmc_a24) based on board schematics
- In case of NOR boot and XIP, we cannot initialize GPMC while running from NOR, hence we have to relocate the tiny GPMC init code to SRAM and then transfer control to SRAM and then come back to NOR XIP.
- Also, the relocatable GPMC init code should be placed in the first 4KBytes of the u-boot. This is achieved by adding lowlevel_init.o just below start.o in the u-boot linker script **board/ti8168_evm/u-boot.lds** as shown below.

```
SECTIONS
{
    . = 0x00000000;
    . = ALIGN(4);
    .text :
    {
        arch/arm/cpu/arm_cortexa8/start.o  (.text)
        arch/arm/cpu/arm_cortexa8/ti81xx/lowlevel_init.o  (.text)
        *(.text)
    }
    ...
    ...
    ...
}
```

- Before relocating any code to SRAM we have to first enable the SRAM.
- All the above steps have to be done only if we are not already running from SRAM (or DDR)
- The diagram below explains the above discussed steps



Config Macros

```

#define CONFIG_SYS_FLASH_CFI
    #define CONFIG_MTD_DEVICE
    #define CONFIG_FLASH_CFI_DRIVER
    #define CONFIG_FLASH_CFI_MTD
    #define CONFIG_SYS_MAX_FLASH_SECT    512
    #define CONFIG_SYS_MAX_FLASH_BANKS    1
    #define CONFIG_ENV_IS_IN_FLASH        1
    #define CONFIG_SYS_FLASH_BASE          (0x08000000)
    #define CONFIG_SYS_MONITOR_BASE        CONFIG_SYS_FLASH_BASE
    #define NOR_SECT_SIZE                   (128 * 1024)
    #define CONFIG_SYS_ENV_SECT_SIZE       (NOR_SECT_SIZE)
    #define CONFIG_ENV_OFFSET               (2 * NOR_SECT_SIZE)
    #define CONFIG_ENV_ADDR                 (CONFIG_ENV_OFFSET)
  
```

- These macros assume spanion flash being used in the EVM. For any other flash part, the sector size macro (NOR_SECT_SIZE) has to be modified.

Spanion NOR parts are supported on DM81xx platforms.

Note

- The following sub-sections illustrate the usage of NOR specific commands on DM81XXEVM.
- If U-Boot is built with NOR support and if NOR is disabled in the EVM (or NAND is enabled) and if you try loading U-Boot through CCS then U-Boot will crash. Refer to EVM Switch Settings section for more info on enabling/disabling different boot devices.

NOR Layout

The NOR part on the EVM has been configured in the following manner. Please note the addresses mentioned here carefully as they are used in the subsequent NOR related commands.

```

-----+-----> 0x08000000 (u-boot Start) Flash Start
|
|
|
|
|-----> 0x0803FFFF (u-boot End)
|-----> 0x08040000 (ENV Start)
|
|
|
|-----> 0x0805FFFF (ENV End)
|-----> 0x08060000 (Linux Start)
|
|
|
|
|-----> 0x0845FFFF (Linux End)
|-----> 0x08460000 (FS Start)
|
|
|
|
|
|
|
|-----> 0x0B65FFFF (FS End)
|-----> 0x0B660000 (Reserved Start)
|
|
|
|-----+-----> 0x0C000000 (Reserved End) Flash End

```

Writing to NOR

To write len bytes of data from a memory buffer located at addr to the NOR block offset (here <len> is always in 16-bit word count and not bytes):

```
TI8168_EVM# cp.w <src> <dest> <len>
```

For example, to write 0x40000 bytes (i.e. 0x20000 16-bit words) from memory buffer at address 0x81000000 to NOR - starting at offset 0x0B660000:

```
TI8168_EVM# cp.w 0x81000000 0x0B660000 0x20000
```

Reading from NOR

To read len bytes of data from NOR block at offset to memory buffer located at addr (here <len> is always in 16-bit word count and not bytes):

```
TI8168_EVM# cp.w <src> <dest> <len>
```

For example, to read 0x40000 bytes (i.e. 0x20000 16-bit words) from NOR - starting at offset 0x0B660000 to memory buffer at address 0x81000000:

```
TI8168_EVM# cp.w 0x0B660000 0x81000000 0x20000
```

Erasing NOR

To erase NOR in the address range (start and end should align to block size):

```
TI8168_EVM# erase <start> <end>
```

For example, to erase from 0x0B660000 to 0x0BFFFFFF:

```
TI8168_EVM# erase 0x0B660000 0x0BFFFFFF
```

Transferring images to NOR via U-Boot

Make sure the EVM is connected to network. This is required to get Linux Image from a tftp server. If there is no DHCPserver in the network then use static ip. The section on U-Boot network configuration gives the commands for doing this.

Make sure tftp server is running in a windows PC and the home directory for the tftp server has Linux kernel uImage. This windows PC should be accessible from board.

Flashing U-Boot from U-Boot

To flash u-boot image (u-boot.bin) to the NOR execute the commands listed below:

```
TI8168_EVM# mw.b 0x81000000 0xFF 0x100000
TI8168_EVM# tftp 0x81000000 u-boot.bin
TI8168_EVM# protect off 0x08000000 0x0803FFFF
TI8168_EVM# erase 0x08000000 0x0803FFFF
TI8168_EVM# cp.w 0x81000000 0x08000000 0x20000 (NOTE: 0x20000 is size of uboot.bin / 2)
```

Please note that the above steps can only be used from U-Boot already running out of NOR.

The above set of commands fill in the section of memory starting from 0x81000000 with size 0x100000 with 0xFF. In TI816X EVM this memory region is a part of the DDR memory. Next we download the U-Boot image to the DDR memory. To have persistent storage we then transfer the downloaded U-Boot image to NOR with the help of the NOR commands described earlier.

Flashing Linux Kernel from U-Boot

TFTP the kernel uImage to DDR.

```
TI8168_EVM# tftp 81000000 <kernel_image>
```

Flash the kernel image to NOR

```
TI8168_EVM# protect off 0x08060000 0x0845FFFF
TI8168_EVM# erase 0x08060000 0x0845FFFF
TI8168_EVM# cp.w 0x81000000 0x08060000 <image_size / 2>
```

Creating JFFS2 File-system

Refer Creating JFFS2 File-system

Flashing File-system from U-Boot

TFTP filesystem image (example - rootfs-816x.jffs2) to DDR.

```
TI8168_EVM# tftp 81000000 <filesystem_image>
```

Flash the file system image to NOR

```
TI8168_EVM# protect off 0x08460000 0x0B65FFFF
TI8168_EVM# erase 0x08460000 0x0B65FFFF
TI8168_EVM# cp.w 0x81000000 0x08460000 <filesystem size / 2>
```

U-Boot SPI Support

Before proceeding with any of the commands given in this section please make sure that SPI is enabled on the EVM. The switch for enabling SPI is shown over here.

This section gives an *overview* of the SPI support in U-Boot. It also describe how to store the kernel image, RAMDISK or the JFFS2 filesystem to SPI flash so as to have a network-free boot right from powering on the board to getting the kernel up and running.

Overview

Winbond SPI Flash part W25X32 is supported on DM8168EVM. Refer <http://www.mail-archive.com/u-boot@lists.denx.de/msg35376.html> ^[4] for information on supporting new Winbond SPI flashes. This mail thread discusses on adding support for W25Q64 SPI flash part.

Note

- The following sub-sections illustrate the usage of SPI specific commands on DM8168EVM.
- Refer to EVM Switch Settings section for more info on enabling/disabling different boot devices.

SPI Flash Layout

The SPI flash part on the EVM has been configured in the following manner. The addresses mentioned here are used in the subsequent SPI related commands.

TI816X

```
+-----+--->0x00000000-> U-Boot start
|
|
|
```

```

|
|
|      |-->0x0003FFFF-> U-Boot end
|      |-->0x00040000-> ENV start
|
|
|
|      |-->0x00041FFF-> ENV end
|      |-->0x00042000-> Linux Kernel start
|
|
|
|
|
|      |-->0x002C1FFF-> Linux Kernel end
|      |-->0x002C2000-> Filesystem start
|
|
|
+-----+-->0x00400000-> Filesystem end

```

TI814X/TI813X

```

+-----+-->0x00000000-> U-Boot 1st stage start
|
|      |-->0x0001FFFF-> U-Boot 1st stage end
|      |-->0x00020000-> U-Boot 2nd stage Start
|
|
|      |-->0x0005FFFF-> U-Boot 2nd stage end
|      |-->0x00060000-> ENV start
|
|
|
|      |-->0x00061FFF-> ENV end
|      |-->0x00062000-> Linux Kernel start
|
|
|
|
|
|      |-->0x002E1FFF-> Linux Kernel end
|      |-->0x002E2000-> Filesystem start
|
|
|
+-----+-->0x00400000-> Filesystem end

```

NOTE :

- Type **sf** in u-boot prompt to get help on SPI flash commands
- Before using any SPI command, first the SPI flash has to be probed using the **sf probe 0** command. Here 0 is the SPI flash chip select number

Writing to SPI Flash

To write **len** bytes of data from a memory buffer located at **addr** to **offset** in SPI flash:

```
TI8168_EVM# sf write addr offset len
```

For example, to write 0x1000 bytes from memory buffer at address 0x80000000 to SPI flash - starting at offset 0x4000:

```
TI8168_EVM# sf write 0x80000000 0x4000 0x1000
```

Reading from SPI Flash

To read **len** bytes of data from SPI flash at a particular **offset** to the memory buffer located at **addr**:

```
TI8168_EVM# sf read addr offset len
```

For example, to read 0x1000 bytes from flash - starting at offset 0x4000 to memory buffer at address 0x80000000:

```
TI8168_EVM# sf write 0x80000000 0x4000 0x1000
```

Erasing SPI Flash

To erase **len** bytes from 'offset' in a SPI flash:

```
TI8168_EVM# sf erase offset len
```

For example, to erase 0x1000 bytes from offset 0x4000:

```
TI8168_EVM# sf erase 0x4000 0x1000
```

Transferring images to SPI flash via U-Boot

Make sure the EVM is connected to network. This is required to get Linux Image from a tftp server. If there is no DHCPserver in the network then use static ip. The section on U-Boot network configuration gives commands for doing this.

Make sure tftp server is running in a windows PC and the home directory for the tftp server has Linux kernel uImage. This windows PC should be accessible from the EVM.

Flashing U-Boot from U-Boot

TI816X

To flash u-boot image (u-boot.noxip.bin.spi) to the Winbond SPI flash execute the commands listed below:

```
TI8168_EVM# mw.b 0x81000000 0xFF 0x100000
TI8168_EVM# tftp 0x81000000 u-boot.noxip.bin.spi
TI8168_EVM# sf probe 0:0
TI8168_EVM# sf erase 0x0 0x40000
TI8168_EVM# sf write 0x81000000 0x0 0x40000
```

The above set to commands, fill in the section of memory starting from 0x81000000 with size 0x100000 with 0xFF. In TI816X EVM this memory region is a part of the DDR memory.

TI814X and TI813X

Flash U-Boot-MIN for SPI (**u-boot.min.spi**) to SPI flash by executing the following commands:

```
TI8148_EVM# tftp 0x81000000 u-boot.min.spi
TI8148_EVM# sf probe 0:0
TI8148_EVM# sf erase 0x0 0x20000
TI8148_EVM# sf write 0x81000000 0x0 0x20000
```

If no error messages are displayed then the 1st stage for SPI boot is successfully flashed to SPI.

Flashing 2nd stage to SPI from 2nd stage in SD boot

Flash 2nd stage u-boot image (**u-boot.bin**) to SPI flash by executing the following commands:

```
TI8148_EVM# mw.b 0x81000000 0xFF 0x40000
TI8148_EVM# tftp 0x81000000 u-boot.bin
TI8148_EVM# sf probe 0:0
TI8148_EVM# sf erase 0x20000 0x40000
TI8148_EVM# sf write 0x81000000 0x20000 0x40000
```

Flashing Linux Kernel from U-Boot

TFTP the kernel uImage to DDR.

TI816X

```
TI8168_EVM# tftp 81000000 <kernel_image>
```

Now flash the kernel image to flash at the appropriate offset (refer to SPI layout section for the offsets)

```
TI8168_EVM# sf probe 0
TI8168_EVM# sf erase 0x42000 0x280000
TI8168_EVM# sf write 0x81000000 0x42000 <image_size> (example, 0x200000)
```

TI814X and TI813X

```
TI8148_EVM# tftp 81000000 <kernel_image>
```

Now flash the kernel image to flash at the appropriate offset (refer to SPI layout section for the offsets)

```
TI8148_EVM# sf probe 0:0
TI8148_EVM# sf erase 0x62000 0x280000
TI8148_EVM# sf write 0x81000000 0x62000 <image_size> (example, 0x200000)
```

Creating JFFS2 File-system

NOTE: JFFS2 cannot be supported on the SPI flash available on DM8168 EVM due to erase size restrictions. The erase sector size of W25X32 is 4KiB but JFFS2 requires it be minimum 8KiB. Hence JFFS2 filesystem cannot be used on this flash part. For help on JFFS2 filesystem creation (for other SPI flash parts) refer Creating JFFS2 File-system

Flashing File-system from U-Boot

TI816X

```
TI8168_EVM# tftp 81000000 <filesystem_image>
TI8168_EVM#
```

Flash the file system image to flash using the appropriate offsets

```
TI8168_EVM# sf probe 0
TI8168_EVM# sf erase 0x2c2000 0x13E000
TI8168_EVM# sf write 0x81000000 0x2c2000 0x13E000
TI8168_EVM#
```

TI814X/TI813X

```
TI8148_EVM# tftp 81000000 <filesystem_image>
TI8148_EVM#
```

Flash the file system image to flash using the appropriate offsets

```
TI8148_EVM# sf probe 0:0
TI8148_EVM# sf erase 0x2e2000 0x11E000
TI8148_EVM# sf write 0x81000000 0x2e2000 0x11E000
TI8148_EVM#
```

U-Boot UART support

Note: UART Flash is only supported on TI814X.

This section describes how to use UART boot mode using TeraTerm.

Ensure that you have the latest version 4.67 of the Teraterm installed. The kermit protocol implementation in Teraterm is not reliable in older versions. The latest version of Teraterm 4.67 can be downloaded from here ^[2]

Boot Over UART

Note

The release package does not contain the binary for UART boot. Please follow the steps mentioned [#U-Boot_UART_support](#) for UART boot for compiling u-boot.min.uart

1. Switch ON EVM with switch settings for UART boot. When “CCCC” characters appear on TeraTerm window, from the File Menu select Transfer --> XMODEM --> Send (1K mode)
2. Select “u-boot.min.uart” for the transfer
3. Press “Reset button” to initiate image download
4. After image is successfully downloaded, the ROM code will boot it.
5. Hit enter and get to u-boot prompt “TI-MIN#”

```
TI_MIN#
```

Loading 2nd stage over UART

- From the U-Boot-MIN prompt

```
TI_MIN# loadb 0x81000000
```

- From TeraTerm Menu click "File -> Transfer -> Kermit -> Send".
- Select the 2nd stage u-boot image "u-boot.bin" built earlier and click "OPEN" button
- Wait for download to complete

```
TI_MIN# go 0x81000000
```

- You should get 2nd Stage u-boot prompt

```
TI8148_EVM#
```

Flashing images to NAND

Before proceeding with any of the commands given in this section please make sure that NAND is enabled on the EVM. The switch for enabling NAND is shown over here.

TI814X and TI813X

After the 2nd stage prompt **TI8148_EVM#** comes up, the images for the 1st stage and 2nd stage can be flashed to NAND for persistent storage.

Before proceeding with flashing of the images please make sure that NAND is enabled on the EVM.

Flashing 1st stage to NAND from 2nd stage

Flash U-Boot-MIN for NAND (**u-boot.min.nand**) to NAND by executing the following commands:

```
TI8148_EVM# mw.b 0x81000000 0xFF 0x20000
TI8148_EVM# loadb 0x81000000
```

- From TeraTerm Menu click "File -> Transfer -> Kermit -> Send".
- Select the 1st stage u-boot image "**u-boot.min.nand**" and click "OPEN" button
- Wait for download to complete and then run following commands in u-boot prompt

```
TI8148_EVM# nand erase 0x0 0x20000
TI8148_EVM# nand write.i 0x81000000 0x0 0x20000
```

If no error messages are displayed the 1st stage of NAND boot has been successfully transferred to NAND.

Flashing 2nd stage to NAND from 2nd stage

Flash the 2nd stage U-Boot (**u-boot.bin**) to NAND by executing the following commands:

```
TI8148_EVM# mw.b 0x81000000 0xFF 0x60000
TI8148_EVM# loadb 0x81000000
```

- From TeraTerm Menu click "File -> Transfer -> Kermit -> Send".
- Select the 2nd stage u-boot image "**u-boot.bin**" and click "OPEN" button
- Wait for download to complete and then run following commands in u-boot prompt

```
TI8148_EVM# nand erase 0x20000 0x60000
TI8148_EVM# nand write.i 0x81000000 0x20000 0x60000
```

If no error messages are displayed the 2nd stage of NAND boot has been successfully transferred to NAND.

Flashing images to SPI

Before proceeding with any of the commands given in this section please make sure that SPI is enabled on the EVM. The switch for enabling SPI is shown over here.

After the 2nd stage prompt TI8148_EVM# comes up the images for the 1st stage and 2nd stage can be flashed to SPI for persistent storage.

Flashing 1st stage to SPI from 2nd stage

Flash U-Boot-MIN for SPI (**u-boot.min.spi**) to SPI flash by executing the following commands:

```
TI8148_EVM# mw.b 0x81000000 0xFF 0x20000
TI8148_EVM# loadb 0x81000000
```

- From TeraTerm Menu click “File -> Transfer -> Kermit -> Send”.
- Select the 1st stage u-boot image “**u-boot.min.spi**” and click “OPEN” button
- Wait for download to complete and then run following commands in u-boot prompt

```
TI8148_EVM# sf probe 0:0
TI8148_EVM# sf erase 0x0 0x20000
TI8148_EVM# sf write 0x81000000 0x0 0x20000
```

If no error messages are displayed then the 1st stage for SPI boot is successfully flashed to SPI.

Flashing 2nd stage to SPI from 2nd stage

Flash 2nd stage u-boot image (**u-boot.bin**) to SPI flash by executing the following commands:

```
TI8148_EVM# mw.b 0x81000000 0xFF 0x40000
TI8148_EVM# loadb 0x81000000
```

- From TeraTerm Menu click “File -> Transfer -> Kermit -> Send”.
- Select the 1st stage u-boot image “**u-boot.bin**” and click “OPEN” button
- Wait for download to complete and then run following commands in u-boot prompt

```
TI8148_EVM# sf probe 0:0
TI8148_EVM# sf erase 0x20000 0x40000
TI8148_EVM# sf write 0x81000000 0x20000 0x40000
```

If no error messages are displayed then the 2nd stage for SPI boot is successfully flashed to SPI.

U-Boot SD (Secured Digital card) Support

This section gives an overview of the SD (Secured Digital Card) support in U-Boot

Overview

SD (Secured Digital Card) support is available through HSMMC controller.

SD support is available by default in all U-Boot configs. SD card can be access in all other boot modes (NAND/SPI/NOR).

Read and execute application from SD card

List files on a FAT32 formatted SD card

```
TI8168_EVM# mmc rescan 0
TI8168_EVM# fatls mmc 0
```

Booting kernel image from the SD card

```
TI8168_EVM# mmc rescan 0
TI8168_EVM# fatload mmc 0 0x81000000 uImage
TI8168_EVM# bootm 0x81000000
```

Booting application (ex. u-boot.bin)image from the SD card

```
TI8168_EVM# mmc rescan 0
TI8168_EVM# fatload mmc 0 0x81000000 u-boot.bin
TI8168_EVM# go 0x81000000
```

Note: For the PSP_04.00.00.12 and older release use the following mmc commands

```
$mmc rescan 0 must be replaced with $mmc init
$fatload mmc 0 <addr> <file> must be replaced with $fatload mmc 1 <addr> <file>
```

Setting Up Boot Environment on SD Card

This section describes steps to be followed to create a standalone power-on bootable system on SD card.

Prerequisites Ensure that following is available:

- A Linux host with fdisk, sfdisk, mkfs.ext3 and mkfs.vfat utilities is available
- Copy images MLO, u-boot.bin, uImage, nfs.tar.gz and mkspd-ti816x.sh from release package to a directory on this Linux machine. For subsequent description, we will assume these files are copied to /home/ti816x. Please refer Package Contents section in TI816X User Guide for location of these files.
- Empty SD card (at least 256MB, preferably 4GB SDHC)
- A SD memory card reader/programmer to copy files from Linux Host

Note: The SD Boot has some specific restriction about the format of the 1st partition and copying the MLO image.

So it is recommended that the supplied script mkspd-ti816x.sh is used for creating partitions and copying files.

Steps

- Connect the SD memory card using Memory Card reader to the Linux Host
- Note the name allotted for this device. We assume the device is named as "/dev/sdd"
- Navigate to the /home/ti816x directory where all the mentioned files are copied
- Ensure that the script mkspd-ti816x.sh has executable permissions
- This scripts expects arguments in the following format

```
./mkspd-ti816x.sh <sd-device-name> <sd-1st-stage-bootloader> <kernel-uImage> <tar-gzipped-filesystem-directory>
```

- **Note** that the user will require root/sudo permissions
- In our example, we run the following command

```
sudo ./mkspd-ti816x.sh /dev/sdd MLO u-boot.bin uImage nfs.tar.gz
```

- You will be asked about data getting overwritten, confirm it and the files along with filesystem will be copied to SD card
- Note that this script will create two primary partitions:
 - 1st partition is formatted as FAT32 containing MLO, u-boot.bin, uImage files
 - 2nd partition is formatted as ext3 where the filesystem is extracted in root

Boot using SD card

Once the SD card has been setup as described in the previous section make sure the switch setting are set for SD boot mode and then plug in the SD card in the MMC/SD card slot on the EVM.

When the EVM is powered on the 1st stage will autoload the 2nd stage from SD. Interrupt the countdown in the 2nd stage if kernel boot is not required. You should see the **TI8168_EVM#** prompt on the console.

Flashing TI816X U-Boot to NAND using SD boot

Before proceeding with any of the commands given in this section please make sure that NAND is enabled on the EVM. The switch for enabling NAND on TI8168 EVM is SW4.

Copy the U-Boot image **u-boot.noxip.bin** built for NAND as described [#U-Boot_for_NAND_boot here] in the FAT partition on the SD card. (The release package contains a pre-built image u-boot.noxip.bin which can be used for this purpose)

Once the second stage of SD boot comes up use the following commands to flash to NAND

```
TI8168_EVM# mmc rescan 0
TI8168_EVM# fatload mmc 0 0x81000000 u-boot.noxip.bin
TI8168_EVM# nand erase 0x0 0x1c0000
TI8168_EVM# nand write.i 0x81000000 0x0 0x1c0000
```

After this the EVM switch settings can be changed to [#NAND_boot NAND boot mode] if boot out of NAND is required.

Flashing TI816X U-Boot to SPI using SD boot

Before proceeding with any of the commands given in this section please make sure that SPI is enabled on the EVM. The switch for enabling SPI on TI8168 EVM is SW4.

Copy the U-Boot image **u-boot.noxip.bin.spi** built for SPI as described U-Boot_for_SPI_boot ^[5] in the FAT partition on the SD card.

Once the second stage of SD boot comes up use the following commands to flash to SPI

```
TI8168_EVM# mmc rescan 0
TI8168_EVM# mw.b 0x81000000 0xFF 0x100000
TI8168_EVM# fatload mmc 0 0x81000000 u-boot.noxip.bin.spi
TI8168_EVM# sf probe 0:0
TI8168_EVM# sf erase 0x0 0x40000
TI8168_EVM# sf write 0x81000000 0x0 0x40000
```

After this the EVM switch settings can be changed to SPI_boot_mode ^[6] if boot out of SPI is required.

Flashing images to TI814X & TI813X NAND in SD boot

Before proceeding with any of the commands given in this section please make sure that NAND is enabled on the EVM. The switch for enabling NAND is shown over here.

Copy the U-Boot image **u-boot.min.nand** built for 1st stage NAND and **u-boot.bin** built for NAND in the FAT partition on the SD card.

After the 2nd stage prompt **TI8148_EVM#** comes up, the images for the 1st stage and 2nd stage can be flashed to NAND for persistent storage.

Flashing 1st stage to NAND from 2nd stage in SD boot

Flash U-Boot-MIN for NAND (**u-boot.min.nand**) to NAND by executing the following commands:

```
TI8148_EVM# mmc rescan 0
TI8148_EVM# mw.b 0x81000000 0xFF 0x20000
TI8148_EVM$ fatload mmc 0 0x81000000 u-boot.min.nand
TI8148_EVM# nand erase 0x0 0x20000
TI8148_EVM# nand write.i 0x81000000 0x0 0x20000
```

If no error messages are displayed the 1st stage of NAND boot has been successfully transferred to NAND.

Flashing 2nd stage to NAND from 2nd stage in SD boot

Flash the 2nd stage U-Boot (**u-boot.bin**) to NAND by executing the following commands:

```
TI8148_EVM# mmc rescan 0
TI8148_EVM# mw.b 0x81000000 0xFF 0x20000
TI8148_EVM$ fatload mmc 0 0x81000000 u-boot.bin
TI8148_EVM# nand erase 0x20000 0x60000
TI8148_EVM# nand write.i 0x81000000 0x20000 0x60000
```

If no error messages are displayed the 2nd stage of NAND boot has been successfully transferred to NAND.

Flashing images to TI814X SPI in SD boot

Before proceeding with any of the commands given in this section please make sure that SPI is enabled on the EVM. The switch for enabling SPI is shown over here.

Copy the U-Boot image **u-boot.min.spi** built for 1st stage SPI as described [here](#) and **u-boot.bin** built for SPI as described [here](#) in the FAT partition on the SD card.

After the 2nd stage prompt **TI8148_EVM#** comes up the images for the 1st stage and 2nd stage can be flashed to SPI for persistent storage.

Flashing TI814X 1st stage to SPI from 2nd stage in SD boot

Flash U-Boot-MIN for SPI (**u-boot.min.spi**) to SPI flash by executing the following commands:

```
TI8148_EVM# mmc rescan 0
TI8148_EVM# mw.b 0x81000000 0xFF 0x20000
TI8148_EVM# fatload mmc 0 0x81000000 u-boot.min.spi
TI8148_EVM# sf probe 0:0
TI8148_EVM# sf erase 0x0 0x20000
TI8148_EVM# sf write 0x81000000 0x0 0x20000
```

If no error messages are displayed then the 1st stage for SPI boot is successfully flashed to SPI.

Flashing TI814X 2nd stage to SPI from 2nd stage in SD boot

Flash 2nd stage u-boot image (**u-boot.bin**) to SPI flash by executing the following commands:

```
TI8148_EVM# mmc rescan 0
TI8148_EVM# mw.b 0x81000000 0xFF 0x40000
TI8148_EVM# fatload mmc 0 0x81000000 u-boot.bin
TI8148_EVM# sf probe 0:0
TI8148_EVM# sf erase 0x20000 0x40000
TI8148_EVM# sf write 0x81000000 0x20000 0x40000
```

If no error messages are displayed then the 2nd stage for SPI boot is successfully flashed to SPI.

Note: For the PSP_04.00.00.12 and older release use the following mmc commands

```
$mmc rescan 0 must be replaced with $mmc init
$fatload mmc 0 <addr> <file> must be replaced with $fatload mmc 1 <addr> <file>
```

ENV on SD card using a script

U-Boot environment variables can be modified using U-Boot scripts. The scripts can be used to modify and even over-ride the various parameters like bootargs, TFTP serverip etc.

Generation of the scripts is done with the help of the *mkimage* tool which can be found under the tools directory of the U-Boot source. The *mkimage* binary gets generated whenever any U-Boot image is built.

Once the *mkimage* binary generated, create a text file named *boot.txt* with the U-Boot commands that would normally be executed manually at the U-Boot prompt.

Example text file named *boot.txt*

TI816X

```
setenv bootargs 'console=ttyO2,115200n8 root=/dev/mmcblk0p2 mem=128M rootwait'
setenv bootcmd 'mmc rescan 0; fatload mmc 0 0x81000000 uImage; bootm 0x81000000'
boot
```

TI814X/TI813X

```
setenv bootargs 'console=ttyO0,115200n8 root=/dev/mmcblk0p2 mem=128M rootwait'
setenv bootcmd 'mmc rescan 0; fatload mmc 0 0x81000000 uImage; bootm 0x81000000'
boot
```

Note: For the PSP_04.00.00.12/PSP_04.00.00.5 and older release use the following

TI816X

```
setenv bootargs 'console=ttyO2,115200n8 root=/dev/mmcblk0p2 mem=128M rootwait'
setenv bootcmd 'mmc init; fatload mmc 1 0x81000000 uImage; bootm 0x81000000'
boot
```

TI814X/TI813X

```
setenv bootargs 'console=ttyO0,115200n8 root=/dev/mmcblk0p2 mem=128M rootwait'
setenv bootcmd 'mmc init; fatload mmc 1 0x81000000 uImage; bootm 0x81000000'
boot
```

Now use the following command to generate the script named *boot.scr*

```
mkimage -A arm -O linux -T script -C none -n TI_script -d boot.txt boot.scr
```


The file *boot.scr* can now be executed from U-Boot using the source command to execute all the commands present in it. Eg: TFTP the file to some location in DDR and then use source command in the following manner (assumption: network setting has already been done using the steps mentioned in this User Guide)

```
TI8168_EVM# tftp 0x81000000 boot.scr
TI8168_EVM# source 0x81000000
```

The script can even be placed in the SD card and then bootcmd set to autorun this script if present. This is the default behavior of the SD boot images built from the PSP release.

EMAC Boot

This section gives an overview of the EMAC Boot support in U-Boot. EMAC boot support can be referred in **EMAC Boot**

U-Boot Network configuration

In order to download the Linux kernel image from the TFTP server and for mounting NFS the network settings in U-Boot need to be configured.

Note: Uboot supports only Ethernet on Port 1 (J14), Port 2 (J27) is not supported in current release.

Please note that the following commands are being run from the 2nd stage U-Boot prompt on the serial console.

```
TI8168_EVM# setenv autoload no
TI8168_EVM# setenv bootfile uImage
```

The above two commands configure U-Boot not to autoboot the kernel and then set the name of the kernel image to be downloaded over the network.

When booting for the first time, U-Boot tries to fetch the MAC address from the env space. If it returns empty, it will look for MAC address from the eFuse registers in the Control module space and set the "ethaddr" variable in the env appropriately.

The ethaddr can also be set using the setenv/saveenv commands. In such cases the user-set MAC address will take effect on subsequent reboot only.

To set a different MAC address use the following command

```
TI8168_EVM# set ethaddr <random MAC address eg- 08:11:23:32:12:77>
```

Note

When setting a MAC address please ensure that the LSB of the 1st byte is not 1 i.e. when setting the MAC address: y in xy:ab:cd:ef:gh:jk has to be an even number. For more info this refer to the wiki page http://en.wikipedia.org/wiki/MAC_address

In case a static ip is not available run the dhcp command to obtain the ip address from the DHCP server on the network to which the EVM is connected.

```
TI8168_EVM# setenv serverip <tftp server in your network>
TI8168_EVM# dhcp
TI8168_EVM# saveenv
```

In case a static ip is available run the following commands

```
TI8168_EVM# setenv ipaddr <your static ip>
TI8168_EVM# saveenv
```

This completes the network configuration in U-Boot.

U-Boot Environment Variables

After completing the network configuration and flashing the kernel image and filesystems to flash you need to set some other parameters which are essential for booting the kernel.

Environment Settings for Ramdisk

In case you are using a RAMDISK as the Linux filesystem

TI816X

```
TI8168_EVM# setenv bootargs 'console=ttyO2,115200n8 mem=256M earlyprintk root=/dev/ram rw initrd=0x82000000,32MB'
```

TI814X/TI813X

```
TI8148_EVM# setenv bootargs 'console=ttyO0,115200n8 mem=256M earlyprintk root=/dev/ram rw initrd=0x82000000,32MB'
```

In case of NAND boot (0x170000 => size of Linux kernel uImage, 0x00320000 => size of Filesystem)

```
TI8168_EVM# setenv bootcmd 'nand read 0x81000000 0x280000 0x170000;nand read 0x82000000 0x6C0000 0x320000;bootm 0x81000000'
```

In case of NOR boot (0x00320000 => size of Filesystem)

```
TI8168_EVM# setenv bootcmd 'cp.w 0x8460000 0x82000000 0x320000;bootm 0x08060000'
```

In case of SPI boot (0x280000 => size of Linux kernel uImage, 0x13E000 => size of Filesystem)

```
TI8168_EVM# setenv bootcmd 'sf probe 0; sf read 0x81000000 0x42000 0x280000; sf read 0x82000000 0x2C2000 0x13E000;bootm 0x81000000'
```

In case of SD boot

```
TI8168_EVM# setenv bootcmd 'mmc init;fatload mmc 1 0x80009000 uImage;bootm 0x80009000'
```

If auto boot is required then prefix 'dhcp' and 'run addip' to the above 'bootcmd'

```
TI8168_EVM# setenv bootcmd 'dhcp;run addip;${bootcmd}'
```

NOTE: The sizes of images mentioned in the above commands have to be modified based on the actual image size. Also, it should be aligned to sector size of the flash device used.

Finally

```
TI8168_EVM# saveenv
```

Environment Settings for JFFS2 Filesystem

- U-Boot environment variable **bootargs** has information on arguments to be passed to Linux kernel. The **bootargs** format for JFFS2 root filesystem is,

TI816X

```
console=ttyO2,115200n8 root=/dev/mtdblock<partition_id> [ro|rw] rootfstype=jffs2 mem=100M earlyprintk
```

The value of **<partition_id>** depends on memory device which holds the rootfs. The below list gives values for different scenarios and it also assumes that only that respective device is enabled on the board,

```
rootfs on NAND ==> partition_id should be 3
rootfs on NOR ==> partition_id should be 3
rootfs on SPI ==> partition_id should be 3
```

NOTE: If the kernel is compiled with both SPI and NAND support then /dev/mtdblock7 should be used for NAND.
If the kernel is compiled with both SPI and NOR support then /dev/mtdblock7 should be used for SPI.

TI814X/TI813X

```
console=ttyO0,115200n8 root=/dev/mtdblock<partition_id> [ro|rw] rootfstype=jffs2 mem=100M earlyprintk
```

The value of **<partition_id>** depends on memory device which holds the rootfs. The below list gives values for different scenarios and it also assumes that only that respective device is enabled on the board,

```
rootfs on NAND ==> partition_id should be 4
rootfs on NOR ==> partition_id should be 3
rootfs on SPI ==> partition_id should be 4
```

NOTE: If the kernel is compiled with both SPI and NAND support then /dev/mtdblock9 should be used for NAND.
If the kernel is compiled with both SPI and NOR support then /dev/mtdblock9 should be used for SPI.

- Below examples set **bootargs** variable from u-boot prompt for different memory devices (in case of SPI, mtdblock3 should be used).

In case if you want readonly filesystem,

TI816X

```
TI8168_EVM# setenv bootargs 'console=ttyO2,115200n8 root=/dev/mtdblock3 ro rootfstype=jffs2 mem=100M earlyprintk'
```

TI814X/TI813X TI8148_EVM# setenv bootargs 'console=ttyO0,115200n8 root=/dev/mtdblock3 ro rootfstype=jffs2 mem=100M earlyprintk'

In case if you want read/write filesystem,

TI816X

```
TI8168_EVM# setenv bootargs 'console=ttyO2,115200n8 root=/dev/mtdblock3 rw rootfstype=jffs2 mem=100M earlyprintk'
```

TI814X/TI813X

```
TI8148_EVM# setenv bootargs 'console=ttyO0,115200n8 root=/dev/mtdblock4 rw rootfstype=jffs2 mem=100M earlyprintk'
```

NOTE: If the kernel is compiled with both SPI and NAND support then /dev/mtdblock9 should be used for NAND

In case of NAND boot (0x170000 => size of Linux kernel uImage)

```
TI8168_EVM# setenv bootcmd 'nand read 0x81000000 0x00280000 0x170000;bootm 0x81000000'
```

In case of NOR boot

```
TI8168_EVM# setenv bootcmd 'bootm 0x08060000'
```

In case of SPI boot (0x280000 => size of Linux kernel uImage)

```
TI8168_EVM# setenv bootcmd 'sf probe 0; sf read 0x81000000 0x42000 0x280000;bootm 0x81000000'
```

NOTE: The sizes of images mentioned in the above commands have to be modified based on the actual image size. Also, it should be aligned to sector size of the flash device used.

Environment Settings for NFS Filesystem

In case you want to have the kernel use the same ip as that assigned to U-Boot

```
TI8168_EVM# print ethaddr          <-- Check if MAC address is assigned and is unique
TI8168_EVM# setenv ethaddr <unique-MAC-address>    <-- Set only if not present already, format uv:yy:zz:aa:bb:cc
TI8168_EVM# setenv bootcmd 'dhcp;run addip; tftp 81000000 uImage;bootm'
TI8168_EVM# setenv hostname <unique-hostname>
TI8168_EVM# setenv addip 'setenv bootargs ${bootargs} ip=${ipaddr}:${nfssserver}:${gatewayip}:${netmask}:${hostname}:eth0:off'
TI8168_EVM# setenv autoload no
TI8168_EVM# setenv nfsserver <NFS server-ip>        <-- Make sure the same NFS server IP is used below
TI8168_EVM# setenv bootargs 'console=ttyO2,115200n8 root=/dev/nfs nfsroot=<NFS server-ip>:<NFS share>,nolock rw mem=128M'
TI8168_EVM# setenv serverip <tftp-server-ip>
```

In case you want to use dhcp for getting an IP when the kernel boots up

```
TI8168_EVM# print ethaddr          <-- Check if MAC address is assigned and is unique
TI8168_EVM# setenv ethaddr <unique-MAC-address>    <-- Set only if not present already, format uv:yy:zz:aa:bb:cc
TI8168_EVM# setenv bootcmd 'dhcp;tftp 81000000 uImage;bootm'
TI8168_EVM# setenv autoload no
TI8168_EVM# setenv nfsserver <NFS server-ip>        <-- Make sure the same NFS server IP is used below
TI8168_EVM# setenv bootargs 'console=ttyO2,115200n8 root=/dev/nfs nfsroot=<NFS server-ip>:<NFS share>,nolock rw mem=128M ip=dhcp'
TI8168_EVM# setenv serverip <tftp-server-ip>
```

Finally

```
TI8168_EVM# saveenv
```

Booting the kernel

In case everything went well you should now be able to boot the kernel from U-Boot using the following command.

```
TI8168_EVM# boot
```

References

- [1] <http://www.denx.de/wiki/U-Boot/WebHome>
- [2] <http://logmett.com/index.php/?download/tera-term-467.html>
- [3] <http://www.linux-mtd.infradead.org/archive/tech/faq.html>
- [4] <http://www.mail-archive.com/u-boot@lists.denx.de/msg35376.html>
- [5] http://processors.wiki.ti.com/index.php?title=TI816X_C6A816x_AM389x_PSP_U-Boot#U-Boot_for_SPI_boot
- [6] http://processors.wiki.ti.com/index.php?title=TI816X_C6A816x_AM389x_PSP_U-Boot#SPI_boot_mode

Article Sources and Contributors

TI81XX PSP UBOOT User Guide *Source:* <http://processors.wiki.ti.com/index.php?oldid=126134> *Contributors:* Deepu.raj, Mugunthanvm, Parth.saxena, RK

Image Sources, Licenses and Contributors

Image:TiBanner.png *Source:* <http://processors.wiki.ti.com/index.php?title=File:TiBanner.png> *License:* unknown *Contributors:* Nsnehaprabha

Image:U-boot nor-boot gpmc-init.jpg *Source:* http://processors.wiki.ti.com/index.php?title=File:U-boot_nor-boot_gpmc-init.jpg *License:* unknown *Contributors:* Vaibhav

License

THE WORK (AS DEFINED BELOW) IS PROVIDED UNDER THE TERMS OF THIS CREATIVE COMMONS PUBLIC LICENSE ("CCPL" OR "LICENSE"). THE WORK IS PROTECTED BY COPYRIGHT AND/OR OTHER APPLICABLE LAW. ANY USE OF THE WORK OTHER THAN AS AUTHORIZED UNDER THIS LICENSE OR COPYRIGHT LAW IS PROHIBITED. BY EXERCISING ANY RIGHTS TO THE WORK PROVIDED HERE, YOU ACCEPT AND AGREE TO BE BOUND BY THE TERMS OF THIS LICENSE. TO THE EXTENT THIS LICENSE MAY BE CONSIDERED TO BE A CONTRACT, THE LICENSOR GRANTS YOU THE RIGHTS CONTAINED HERE IN CONSIDERATION OF YOUR ACCEPTANCE OF SUCH TERMS AND CONDITIONS.

License

1. Definitions

- a. **"Adaptation"** means a work based upon the Work, or upon the Work and other pre-existing works, such as a translation, adaptation, derivative work, arrangement of music or other alterations of a literary or artistic work, or phonogram or performance and includes cinematographic adaptations or any other form in which the Work may be recast, transformed, or adapted including in any form recognizably derived from the original, except that a work that constitutes a Collection will not be considered an Adaptation for the purpose of this License. For the avoidance of doubt, where the Work is a musical work, performance or phonogram, the synchronization of the Work in timed-relation with a moving image ("synching") will be considered an Adaptation for the purpose of this License.
- b. **"Collection"** means a collection of literary or artistic works, such as encyclopedias and anthologies, or performances, phonograms or broadcasts, or other works or subject matter other than works listed in Section 1(f) below, which, by reason of the selection and arrangement of their contents, constitute intellectual creations, in which the Work is included in its entirety in unmodified form along with one or more other contributions, each constituting separate and independent works in themselves, which together are assembled into a collective whole. A work that constitutes a Collection will not be considered an Adaptation (as defined below) for the purposes of this License.
- c. **"Creative Commons Compatible License"** means a license that is listed at <http://creativecommons.org/compatiblicenses> that has been approved by Creative Commons as being essentially equivalent to this License, including, at a minimum, because that license: (i) contains terms that have the same purpose, meaning and effect as the License Elements of this License; and, (ii) explicitly permits the relicensing of adaptations of works made available under that license under this License or a Creative Commons jurisdiction license with the same License Elements as this License.
- d. **"Distribute"** means to make available to the public the original and copies of the Work or Adaptation, as appropriate, through sale or other transfer of ownership.
- e. **"License Elements"** means the following high-level license attributes as selected by Licensor and indicated in the title of this License: Attribution, ShareAlike.
- f. **"Licensor"** means the individual, individuals, entity or entities that offer(s) the Work under the terms of this License.
- g. **"Original Author"** means, in the case of a literary or artistic work, the individual, individuals, entity or entities who created the Work or if no individual or entity can be identified, the publisher; and in addition (i) in the case of a performance the actors, singers, musicians, dancers, and other persons who act, sing, deliver, declaim, play in, interpret or otherwise perform literary or artistic works or expressions of folklore; (ii) in the case of a phonogram the producer being the person or legal entity who first fixes the sounds of a performance or other sounds; and, (iii) in the case of broadcasts, the organization that transmits the broadcast.
- h. **"Work"** means the literary and/or artistic work offered under the terms of this License including without limitation any production in the literary, scientific and artistic domain, whatever may be the mode or form of its expression including digital form, such as a book, pamphlet and other writing; a lecture, address, sermon or other work of the same nature; a dramatic or dramatico-musical work; a choreographic work or entertainment in dumb show; a musical composition with or without words; a cinematographic work to which are assimilated works expressed by a process analogous to cinematography; a work of drawing, painting, architecture, sculpture, engraving or lithography; a photographic work to which are assimilated works expressed by a process analogous to photography; a work of applied art; an illustration, map, plan, sketch or three-dimensional work relative to geography, topography, architecture or science; a performance; a broadcast; a phonogram; a compilation of data to the extent it is protected as a copyrightable work; or a work performed by a variety or circus performer to the extent it is not otherwise considered a literary or artistic work.
- i. **"You"** means an individual or entity exercising rights under this License who has not previously violated the terms of this License with respect to the Work, or who has received express permission from the Licensor to exercise rights under this License despite a previous violation.
- j. **"Publicly Perform"** means to perform public recitations of the Work and to communicate to the public those public recitations, by any means or process, including by wire or wireless means or public digital performances; to make available to the public Works in such a way that members of the public may access these Works from a place and at a place individually chosen by them; to perform the Work to the public by any means or process and the communication to the public of the performances of the Work, including by public digital performance; to broadcast and rebroadcast the Work by any means including signs, sounds or images.
- k. **"Reproduce"** means to make copies of the Work by any means including without limitation by sound or visual recordings and the right of fixation and reproducing fixations of the Work, including storage of a protected performance or phonogram in digital form or other electronic medium.

2. Fair Dealing Rights

Nothing in this License is intended to reduce, limit, or restrict any uses free from copyright or rights arising from limitations or exceptions that are provided for in connection with the copyright protection under copyright law or other applicable laws.

3. License Grant

Subject to the terms and conditions of this License, Licensor hereby grants You a worldwide, royalty-free, non-exclusive, perpetual (for the duration of the applicable copyright) license to exercise the rights in the Work as stated below:

- a. to Reproduce the Work, to incorporate the Work into one or more Collections, and to Reproduce the Work as incorporated in the Collections;
- b. to create and Reproduce Adaptations provided that any such Adaptation, including any translation in any medium, takes reasonable steps to clearly label, demarcate or otherwise identify that changes were made to the original Work. For example, a translation could be marked "The original work was translated from English to Spanish," or a modification could indicate "The original work has been modified.";
- c. to Distribute and Publicly Perform the Work including as incorporated in Collections; and,
- d. to Distribute and Publicly Perform Adaptations.
- e. For the avoidance of doubt:
 - i. **Non-waivable Compulsory License Schemes.** In those jurisdictions in which the right to collect royalties through any statutory or compulsory licensing scheme cannot be waived, the Licensor reserves the exclusive right to collect such royalties for any exercise by You of the rights granted under this License.
 - ii. **Waivable Compulsory License Schemes.** In those jurisdictions in which the right to collect royalties through any statutory or compulsory licensing scheme can be waived, the Licensor waives the exclusive right to collect such royalties for any exercise by You of the rights granted under this License; and,
 - iii. **Voluntary License Schemes.** The Licensor waives the right to collect royalties, whether individually or, in the event that the Licensor is a member of a collecting society that administers voluntary licensing schemes, via that society, from any exercise by You of the rights granted under this License.

The above rights may be exercised in all media and formats whether now known or hereafter devised. The above rights include the right to make such modifications as are technically necessary to exercise the rights in other media and formats. Subject to Section 8(f), all rights not expressly granted by Licensor are hereby reserved.

4. Restrictions

The license granted in Section 3 above is expressly made subject to and limited by the following restrictions:

- a. You may Distribute or Publicly Perform the Work only under the terms of this License. You must include a copy of, or the Uniform Resource Identifier (URI) for, this License with every copy of the Work You Distribute or Publicly Perform. You may not offer or impose any terms on the Work that restrict the terms of this License or the ability of the recipient of the Work to exercise the rights granted to that recipient under the terms of the License. You may not sublicense the Work. You must keep intact all notices that refer to this License and to the disclaimer of warranties with every copy of the Work You Distribute or Publicly Perform. When You Distribute or Publicly Perform the Work, You may not impose any effective technological measures on the Work that restrict the ability of a recipient of the Work from You to exercise the rights granted to that recipient under the terms of the License. This Section 4(a) applies to the Work as incorporated in a Collection, but this does not require the Collection apart from the Work itself to be made subject to the terms of this License. If You create a Collection, upon notice from any Licensor You must, to the extent practicable, remove from the Adaptation any credit as required by Section 4(c), as requested. If You create an Adaptation, upon notice from any Licensor You must, to the extent practicable, remove from the Adaptation any credit as required by Section 4(c), as requested.
- b. You may Distribute or Publicly Perform an Adaptation only under the terms of: (i) this License; (ii) a later version of this License with the same License Elements as this License; (iii) a Creative Commons jurisdiction license (either this or a later license version) that contains the same License Elements as this License (e.g., Attribution-ShareAlike 3.0 US); (iv) a Creative Commons Compatible License. If you license the Adaptation under one of the licenses mentioned in (iv), you must comply with the terms of that license. If you license the Adaptation under the terms of any of the licenses mentioned in (i), (ii) or (iii) (the "Applicable License"), you must comply with the terms of the Applicable License generally and the following provisions: (I) You must include a copy of, or the URI for, the Applicable License with every copy of each Adaptation You Distribute or Publicly Perform; (II) You may not offer or impose any terms on the Adaptation that restrict the terms of the Applicable License or the ability of the recipient of the Adaptation to exercise the rights granted to that recipient under the terms of the Applicable License; (III) You must keep intact all notices that refer to the Applicable License and to the disclaimer of warranties with every copy of the Work as included in the Adaptation You Distribute or Publicly Perform; (IV) when You Distribute or Publicly Perform the Adaptation, You may not impose any effective technological measures on the Adaptation that restrict the ability of a recipient of the Adaptation from You to exercise the rights granted to that recipient under the terms of the Applicable License. This Section 4(b) applies to the Adaptation as incorporated in a Collection, but this does not require the Collection apart from the Adaptation itself to be made subject to the terms of the Applicable License.
- c. If You Distribute, or Publicly Perform the Work or any Adaptations or Collections, You must, unless a request has been made pursuant to Section 4(a), keep intact all copyright notices for the Work and provide, reasonable to the medium or means You are utilizing: (i) the name of the Original Author (or pseudonym, if applicable) if supplied, and/or if the Original Author and/or Licensor designate another party or parties (e.g., a sponsor institute, publishing entity, journal) for attribution ("Attribution Parties") in Licensor's copyright notice, terms of service or by other reasonable means, the name of such party or parties; (ii) the title of the Work if supplied; (iii) to the extent reasonably practicable, the URI, if any, that Licensor specifies to be associated with the Work, unless such URI does not refer to the copyright notice or licensing information for the Work; and (iv) , consistent with Section 3(b), in the case of an Adaptation, a credit identifying the use of the Work in the Adaptation (e.g., "French translation of the Work by Original Author," or "Screenplay based on original Work by Original Author"). The credit required by this Section 4(c) may be implemented in any reasonable manner; provided, however, that in the case of a Adaptation or Collection, at a minimum such credit will appear, if a credit for all contributing authors of the Adaptation or Collection appears, then as part of these credits and in a manner at least as prominent as the credits for the other contributing authors. For the avoidance of doubt, You may only use the credit required by this Section for the purpose of attribution in the manner set out above and, by exercising Your rights under this License, You may not implicitly or explicitly assert or imply any connection with, sponsorship or endorsement by the Original Author, Licensor and/or Attribution Parties, as appropriate, of You or Your use of the Work, without the separate, express prior written permission of the Original Author, Licensor and/or Attribution Parties.
- d. Except as otherwise agreed in writing by the Licensor or as may be otherwise permitted by applicable law, if You Reproduce, Distribute or Publicly Perform the Work either by itself or as part of any Adaptations or Collections, You must not distort, mutilate, modify or take other derogatory action in relation to the Work which would be prejudicial to the Original Author's honor or reputation. Licensor agrees that in those jurisdictions (e.g. Japan), in which any exercise of the right granted in Section 3(b) of this License (the right to make Adaptations) would be deemed to be a distortion, mutilation, modification or other derogatory action prejudicial to the Original Author's honor and reputation, the Licensor will waive or not assert, as appropriate, this Section, to the fullest extent permitted by the applicable national law, to enable You to reasonably exercise Your right under Section 3(b) of this License (right to make Adaptations) but not otherwise.

5. Representations, Warranties and Disclaimer

UNLESS OTHERWISE MUTUALLY AGREED TO BY THE PARTIES IN WRITING, LICENSOR OFFERS THE WORK AS-IS AND MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND CONCERNING THE WORK, EXPRESS, IMPLIED, STATUTORY OR OTHERWISE, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF TITLE, MERCHANTIBILITY, FITNESS FOR A PARTICULAR PURPOSE, NONINFRINGEMENT, OR THE ABSENCE OF LATENT OR OTHER DEFECTS, ACCURACY, OR THE PRESENCE OF ABSENCE OF ERRORS, WHETHER OR NOT DISCOVERABLE. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES, SO SUCH EXCLUSION MAY NOT APPLY TO YOU.

6. Limitation on Liability

EXCEPT TO THE EXTENT REQUIRED BY APPLICABLE LAW, IN NO EVENT WILL LICENSOR BE LIABLE TO YOU ON ANY LEGAL THEORY FOR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY DAMAGES ARISING OUT OF THIS LICENSE OR THE USE OF THE WORK, EVEN IF LICENSOR HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

7. Termination

- a. This License and the rights granted hereunder will terminate automatically upon any breach by You of the terms of this License. Individuals or entities who have received Adaptations or Collections from You under this License, however, will not have their licenses terminated provided such individuals or entities remain in full compliance with those licenses. Sections 1, 2, 5, 6, 7, and 8 will survive any termination of this License.

- b. Subject to the above terms and conditions, the license granted here is perpetual (for the duration of the applicable copyright in the Work). Notwithstanding the above, Licensor reserves the right to release the Work under different license terms or to stop distributing the Work at any time; provided, however that any such election will not serve to withdraw this License (or any other license that has been, or is required to be, granted under the terms of this License), and this License will continue in full force and effect unless terminated as stated above.

8. Miscellaneous

- a. Each time You Distribute or Publicly Perform the Work or a Collection, the Licensor offers to the recipient a license to the Work on the same terms and conditions as the license granted to You under this License.
- b. Each time You Distribute or Publicly Perform an Adaptation, Licensor offers to the recipient a license to the original Work on the same terms and conditions as the license granted to You under this License.
- c. If any provision of this License is invalid or unenforceable under applicable law, it shall not affect the validity or enforceability of the remainder of the terms of this License, and without further action by the parties to this agreement, such provision shall be reformed to the minimum extent necessary to make such provision valid and enforceable.
- d. No term or provision of this License shall be deemed waived and no breach consented to unless such waiver or consent shall be in writing and signed by the party to be charged with such waiver or consent.
- e. This License constitutes the entire agreement between the parties with respect to the Work licensed here. There are no understandings, agreements or representations with respect to the Work not specified here. Licensor shall not be bound by any additional provisions that may appear in any communication from You. This License may not be modified without the mutual written agreement of the Licensor and You.
- f. The rights granted under, and the subject matter referenced, in this License were drafted utilizing the terminology of the Berne Convention for the Protection of Literary and Artistic Works (as amended on September 28, 1979), the Rome Convention of 1961, the WIPO Copyright Treaty of 1996, the WIPO Performances and Phonograms Treaty of 1996 and the Universal Copyright Convention (as revised on July 24, 1971). These rights and subject matter take effect in the relevant jurisdiction in which the License terms are sought to be enforced according to the corresponding provisions of the implementation of those treaty provisions in the applicable national law. If the standard suite of rights granted under applicable copyright law includes additional rights not granted under this License, such additional rights are deemed to be included in the License; this License is not intended to restrict the license of any rights under applicable law.