



Object Library

Intrusion Keypad/Display Object

Copyright 2008
Johnson Controls, Inc.
All Rights Reserved

No part of this document may be reproduced without the prior permission of
Johnson Controls, Inc.

These instructions are supplemental. Some times they are supplemental to
other manufacturer's documentation. Never discard other manufacturer's
documentation. Publications from Johnson Controls, Inc. are not intended to
duplicate nor replace other manufacturer's documentation.

If this document is translated from the original English version by Johnson
Controls, Inc., all reasonable endeavors will be used to ensure the accuracy of
translation. Johnson Controls, Inc. shall not be liable for any translation errors
contained herein or for incidental or consequential damages in connection with
the furnishing or use of this translated material.

INTRUSION KEYPAD/DISPLAY OBJECT

INTRODUCTION

The Intrusion Keypad/Display object interfaces to the Intrusion Keypad/Display module and allows authorized users to control the Intrusion Area, Intrusion Zone, and Intrusion Annunciator objects.

The Intrusion Keypad/Display object may generate notifications when an error occurs while writing to other objects.

Use the Intrusion Keypad/Display object to perform the following functions on other objects:

- The Intrusion Area object: view status, arm, and disarm
- The Intrusion Annunciator object: view status, silence
- The Intrusion Zone object: view status, bypass, activate, and acknowledge




Figure 1: Keypad/Display Object Details




Figure 2: Intrusion Detection System: Keypad/Display Object

ATTRIBUTES

This section describes visible attributes specific to the Intrusion Keypad/Display object. This object also contains:

- Attributes common to all objects in the P2000 Security Management System. For details, see the *General Object Information* document.
- Internal attributes, which are invisible to the user and cannot be modified directly, but may be referred to throughout this document.

Table 1: Intrusion Keypad/Display Object Attributes

Attribute Name	Attribute Number	Data Type	Notes	Initial Value	Values/Options /Range
<i>Allow All Annunciator Objects</i>	4006	Boolean	WCA	1	0 = Use only Intrusion Annunciators Objects in list 1 = Allow use of all Intrusion Annunciators Objects
<i>Allow All Area Objects</i>	4010	Boolean	WCA	1	0 = Use only Intrusion Area Objects in list 1 = Allow use of all Intrusion Area Objects
<i>Allow All Zone Objects</i>	4011	Boolean	WCA	1	0 = Use only Intrusion Zone Objects in list 1 = Allow use of all Intrusion Zone Objects
<i>Annunciator Object List</i>	4038	List of Object Reference	WCAN	-	Max. 256 entries
<i>Area Object List</i>	4120	List of Object Reference	WCAN	-	Max. 256 entries
<i>Display Overview</i>	4145	Enumeration	WCA	1	0 = Disable 1 = All Alarm and Status 2 = All Alarms Only 3 = Select Alarm and Status 4 = Select Alarms Only
<i>Hardware Module Number</i>	3711	Unsigned32	-	-	Value is inherited from parent object
<i>Hardware Module Type</i>	3710	Enumeration	-	-	Value is inherited from parent object
<i>Notification Class</i>	17	Unsigned32	WCA	1	-
<i>Notify Priority</i>	3644	Unsigned8	WCA	-	-
<i>Reader Status</i>	4298	Enumeration	F	-	0 = Not initialized 1 = Operational 2 = Unknown 3 = Fault
<i>Trunk Number</i>	549	Unsigned8	-	-	Value is inherited from parent object
<i>Zone Object List</i>	4116	List of Object Reference	WCAN	-	Max. 256 entries

A - Archive, C - Configurable, N - Value not required, W - Writable

Allow All Annunciator Objects – Specifies whether the Intrusion Keypad/Display object may control all on box (residing on the same controller) Intrusion Annunciator objects or only those Intrusion Annunciator objects in the list.

Allow All Area Objects – Specifies whether the Intrusion Keypad/Display object may control all on box Intrusion Area objects or only those the Intrusion Area objects in the list.

Allow All Zone Objects – Specifies whether Intrusion Keypad/Display object may control all on box Intrusion Zone objects or only those Intrusion Zone objects in the list.

Annunciator Object List – A list of on box Intrusion Annunciator object references.

If the *Allow All Annunciator Objects* attribute is “False,” then:

- Intrusion Keypad/Display objects may silence listed Intrusion Annunciator objects.
- Intrusion Keypad/Display objects may display the status of listed Intrusion Annunciator objects.

If the *Allow All Annunciator Objects* attribute is “True,” then:

- Intrusion Keypad/Display objects may silence all on box Intrusion Annunciator objects.
- Intrusion Keypad/Display objects may display the status of all on box Intrusion Annunciator objects.

Area Object List – A list of on box Intrusion Area object references.

If the *Allow All Area Objects* attribute is “False,” then:

- Intrusion Keypad/Display objects may arm or disarm listed Intrusion Area objects.
- Intrusion Keypad/Display objects may display the status of listed Intrusion Area objects.

If the *Allow All Area Objects* attribute is “True,” then:

- Intrusion Keypad/Display objects may arm or disarm all on box Intrusion Area objects.
- Intrusion Keypad/Display objects may display the status of all on box Intrusion Area objects.

Display Overview – Enables and disables the display of overview screens on the Keypad/Display Module.

Hardware Module Number – Indicates the logical hardware module number that this object is associated with; the Intrusion Keypad/Display object computes the value for this attribute from information provided by its parent.

Hardware Module Type – Indicates the type of hardware module that this object is associated with; the Intrusion Keypad/Display object computes the value for this attribute from information provided by its parent.

Notification Class – Specifies which Security Notification Class object should be used by the Intrusion Keypad/Display object to send its notifications.

Reader Status – Indicates the condition of the keypad portion of the Intrusion Keypad/Display object:

- Not initialized - The keypad condition has not yet been obtained
- Operational - The keypad is determined to be working correctly
- Unknown - The keypad is offline
- Fault - The keypad is determined to be faulty

Notify Priority – Specifies the Priority parameter of all notifications generated by the Intrusion Keypad/Display object.

Trunk Number – Indicates the trunk that this object belongs to; the Intrusion Keypad/Display object must be a child of an S300 Hardware Module object of type “KDM” (Keypad/Display Module).

Zone Object List – A list of on box Intrusion Zone object references.

If the *Allow All Zone Objects* attribute is “False,” then:

- Intrusion Keypad/Display objects may bypass or activate listed Intrusion Zone objects.
- Intrusion Keypad/Display objects may acknowledge listed Intrusion Zone objects.
- Intrusion Keypad/Display objects may display the status of listed Intrusion Zone objects.

If the *Allow All Zone Objects* attribute is “True,” then:

- Intrusion Keypad/Display objects may bypass or activate all on box Intrusion Zone objects.
- Intrusion Keypad/Display objects may acknowledge all on box Intrusion Zone objects.
- Intrusion Keypad/Display objects may display the status of all on box Intrusion Zone objects.

COMMANDS

This section describes commands that can be issued to this object from SCT.

Table 2: Intrusion Keypad/Display Object Commands

Command Name	Description
Change Attribute	See the description below.

The `Change Attribute` is a generic command available for writing the attributes of an object. It is mainly used to change an attribute value from those features which work only with commands. For the sole purpose of giving a generic example, there is no command defined to change the *Notify Priority* attribute of an object. `Change Attribute` could, therefore, be used to change the *Notify Priority* attribute through an interlock or multiple command, both features which require commands to be entered. The `Change Attribute` command requires two parameters:

- **Attribute** - This parameter specifies which attribute of the object is to be written. Only writable attributes may be changed by this command.
- **New value** - This parameter specifies new value to be written and must be the same data type as the attribute. The only data types allowed in this command are those allowed as command parameters. A command priority can be specified if the attribute to be changed is a prioritized attribute.

VIEWS

This section illustrates how the System Configuration Tool displays properties of the Intrusion Keypad/Display object. This screen also allows you to set the values of configurable attributes. For more information refer to the *System Configuration Tool (SCT)* manual.

The screenshot shows a window titled "Configuration" with an "Edit" button. It displays a table of attributes and their values for an "Intrusion Keypad Display" object.

Attribute	Value
Object	
Name	C0002-00016-IKD
Description	
Object Type	Intrusion Keypad Display
Object Category	General
Partition	Super User
Public	<input type="checkbox"/>
Engineering Values	
Display Overview	All Alarms and Status
Allow all Area Objects	<input checked="" type="checkbox"/>
Area Object List	Listof[0]
Allow all Zone Objects	<input checked="" type="checkbox"/>
Zone Object List	Listof[0]
Allow all Annunciator Object	<input checked="" type="checkbox"/>
Annunciator Object List	Listof[0]
Notification	
Notification Class	1
Notify Priority	0

Figure 3: Configuration View

