



Object Library

KONE Controller Object

Copyright 2008
Johnson Controls, Inc.
All Rights Reserved

No part of this document may be reproduced without the prior permission of
Johnson Controls, Inc.

These instructions are supplemental. Some times they are supplemental to
other manufacturer's documentation. Never discard other manufacturer's
documentation. Publications from Johnson Controls, Inc. are not intended to
duplicate nor replace other manufacturer's documentation.

If this document is translated from the original English version by Johnson
Controls, Inc., all reasonable endeavors will be used to ensure the accuracy of
translation. Johnson Controls, Inc. shall not be liable for any translation errors
contained herein or for incidental or consequential damages in connection with
the furnishing or use of this translated material.

KONE CONTROLLER OBJECT

INTRODUCTION

The KONE Controller object represents the KONE elevator controller inside the Metasys Control Engine (MCE). The object serves as the interface to set configuration parameters related to the elevator controller, as well as the interface to monitor the status of the elevator controller and its communication with the CK722 supervisory controller.

The KONE Controller object must be a child of a KONE Integration object. Each KONE Controller object represents a single elevator controller that is connected to the CK722 supervisory controller. The limit is 1 elevator controller per CK722.




Figure 1: KONE Controller Object

ATTRIBUTES

This object contains attributes common to all objects in the P2000 Security Management System. For details, see the *General Object Information* document. The table below lists only the attributes specific to the KONE Controller object.

Table 1: KONE Controller Object Attributes

Attribute Name	Attribute Number	Data Type	Notes	Initial Value	Values/Options /Range
<i>Acked Transitions</i>	0	BACnetEvent TransitionBits	-	-	Refer to <i>BACnet Standard 12.19.19</i>
<i>Baudrate</i>	-	-	-	-	-
<i>Clear Statistics</i>	2427	Boolean	W	-	-
<i>Corrupted Polls</i>	4089	Unsigned32	-	-	-
<i>Corrupted Responses</i>	4084	Unsigned32	-	-	-
<i>Date</i>	548	Date	-	-	-
<i>Default Locking Polls</i>	4080	Unsigned32	-	-	-
<i>Event Enable</i>	35	BACnetEvent TransitionBits	-	1,1,1	Refer to <i>BACnet Standard 12.19.18</i>
<i>Event State</i>	36	Enumeration	F	-	0 = Normal 1 = Fault 2 = Off-Normal
<i>Event Time Stamps</i>	130	BACnetARRAY [3] of BACnetTimeStamp	-	-	Refer to <i>BACnet Standard 12.19.21</i>
<i>Fault Cause</i>	2896	Enumeration	F	-	0 = None 1 = Port 2 = Task
<i>Group Controller Address</i>	4092	Unsigned8	WCA	-	1 - 8
<i>Incomplete Responses</i>	4085	Unsigned32	-	-	-
<i>Invalid Polls</i>	4088	Unsigned32	-	-	-
<i>Invalid Responses</i>	4083	Unsigned32	-	-	-
<i>Latch Statistics</i>	2426	Boolean	W	-	-
<i>Missing Responses</i>	4086	Unsigned32	-	-	-
<i>Notification Class</i>	17	Unsigned32	WCA	1	Refer to <i>BACnet Standard 12.19.15</i>
<i>Notify Priority</i>	3644	Unsigned8	WCA	-	-

Table 1: KONE Controller Object Attributes

Attribute Name	Attribute Number	Data Type	Notes	Initial Value	Values/Options /Range
<i>Notify Type</i>	72	Enumeration	WCA	-	Refer to <i>BACnet Standard 12.19.20</i>
<i>Null Polls</i>	4078	Unsigned32	-	-	-
<i>Offlines</i>	3744	Unsigned32	-	-	-
<i>Present Value</i>	85	Enumeration	F	-	0 = Not Initialized 1 = Operational 2 = Offline 3 = Fault
<i>Reset Date</i>	1141	Date	-	-	-
<i>Reset Time</i>	1140	Time	-	-	-
<i>Set Access Polls</i>	4079	Unsigned32	-	-	-
<i>Time</i>	547	Time	-	-	-
<i>Total Polls</i>	4081	Unsigned32	-	-	-
<i>Total Responses</i>	4087	Unsigned32	-	-	-
<i>Valid Responses</i>	4082	Unsigned32	-	-	-
<i>Watchdog Events</i>	4090	Unsigned32	-	-	-

A - Archive, C - Configurable, F - PMI (Person/Machine Interface) refreshing, W - Writable

Acked Transitions – Refer to *BACnet Standard 135-2001 12.19.19*.

Baudrate – Specifies the communication speed to interface to the KONE elevator controller.

Clear Statistics – Resets the KONE Controller object's statistics when written to “True.”

Corrupted Polls – Indicates how many polls the KONE elevator controller rejected because of checksum errors.

Corrupted Responses – Indicates how many responses from the KONE elevator controller were found to have an incorrect checksum.

Date – Indicates the local date when the KONE Controller object's statistics were last updated.

Default Locking Polls – Indicates how many “default locking polls” were sent to the KONE elevator controller.

Event Enable – Refer to *BACnet Standard 135-2001 12.19.18*.

Event State – Indicates the event related status of the KONE Controller object, which is determined as follows:

- Off-Normal - The *Present Value* attribute is set to “Offline” or the last To-Offnormal notification has not yet been acknowledged.
- Fault - The *Present Value* attribute is set to “Fault” or the last To-Fault notification has not yet been acknowledged.
- Normal - All other conditions.

Event Time Stamps – Refer to *BACnet Standard 135-2001 12.19.21*.

Fault Cause – Indicates the reason why the KONE Controller object is in the fault state. If multiple reasons apply, the state with the higher enumeration value is shown. The options are:

- None - No fault detected.
- Port - The controller's port for communicating with the KONE elevator controller is not working correctly.
- Task - The controller's KONE elevator integration task is not working correctly.

Group Controller Address – Specifies the KONE elevator controller's group address.

Incomplete Responses – Indicates how many responses from the KONE elevator controller were not fully received.

Invalid Polls – Indicates how many polls were not understood by the KONE elevator controller despite a correct checksum.

Invalid Responses – Indicates how many responses from the KONE elevator controller were not understood despite a correct checksum.

Latch Statistics – Updates the KONE Controller object's statistics when written to “True.”

Missing Responses – Indicates how many expected responses from the KONE elevator controller were not received at all.

Notification Class – Specifies which Security Notification Class object should be used by the KONE Controller object to send its notifications.

Notify Priority – Specifies the Priority parameter of all notifications generated by the KONE Controller object.

Notify Type – Specifies the Notify Type of the KONE Controller object. Refer to *BACnet Standard 135-2001 12.19.20*.

Null Polls – Indicates how many “null polls” were sent to the KONE elevator controller.

Offlines – Indicates how many times the KONE elevator controller transitioned from the online into the offline state.

Present Value – Indicates the principal condition that the KONE elevator controller is in. The options are:

- Not initialized - The KONE elevator controller's condition is not yet determined. This state is used only as the initial state.
- Operational - The KONE elevator controller is up and running.
- Offline - The KONE elevator controller is offline to the controller that this object resides on.
- Fault - The KONE elevator task is in the fault state. The *Fault Cause* attribute contains details about the reason of the fault condition.

Reset Date – Indicates the local date when the KONE Controller object's statistics were last reset.

Reset Time – Indicates the local time when the KONE Controller object's statistics were last reset.

Set Access Polls – Indicates how many “set access polls” were sent to the KONE elevator controller.

Time – Indicates the local time when the KONE Controller object's statistics were last updated.

Total Polls – Indicates the sum of the *Null Polls*, *Set Access Polls*, and *Default Locking Polls* attribute values.

Total Responses – Indicates the sum of the *Valid Responses*, *Invalid Responses*, *Corrupted Responses*, *Incomplete Responses*, and *Missing Responses* attribute values.

Valid Responses – Indicates how many correct responses from the KONE elevator controller were received.

Watchdog Events – Indicates how many times the KONE elevator controller's watchdog timer timed out.

COMMANDS

This section describes commands that can be issued to this object from SCT.

Table 2: KONE Controller Object Commands

Command Name	Description
Latch Statistics	Writes the <i>Latch Statistics</i> attribute to "True."
Clear Statistics	Writes the <i>Clear Statistics</i> attribute to "True."
Change Attribute	See the description below.

The *Change Attribute* is a generic command available for writing the attributes of an object. It is mainly used to change an attribute value from those features which work only with commands. For the sole purpose of giving a generic example, there is no command defined to change the *Notify Priority* attribute of an object. *Change Attribute* could, therefore, be used to change the *Notify Priority* attribute through an interlock or multiple command, both features which require commands to be entered. The *Change Attribute* command requires two parameters:

- Attribute - This parameter specifies which attribute of the object is to be written. Only writable attributes may be changed by this command.
- New value - This parameter specifies new value to be written and must be the same data type as the attribute. The only data types allowed in this command are those allowed as command parameters. A command priority can be specified if the attribute to be changed is a prioritized attribute.

VIEWS

This section illustrates how the System Configuration Tool displays properties of the KONE Controller object. This screen also allows you to set the values of configurable attributes. For more information refer to the *System Configuration Tool (SCT)* manual.

Attribute	Value
Object	
Name	C0002-00017-KONE-I
Description	
Object Type	KONE Integration
Object Category	System
Partition	Super User
Public	<input type="checkbox"/>
Engineering Values	
Baud Rate	9600
Floor List	Listof[0]

Figure 2: Configuration View

DESCRIPTION OF OPERATION

The elevator controller statistics are reset when the *Clear Statistics* attribute is written to “True.” The elevator controller statistics are updated when the *Latch Statistics* attribute is written to “True.”

Present Value and Fault Cause Attributes

Immediately after the KONE Controller object is started, it attempts to communicate with the elevator task. In case this task cannot be communicated with, or does not work properly, the KONE Controller object's *Present Value* attribute is set to “Fault,” and the *Fault Cause* attribute is set to “Task.” Such a condition indicates a severe error with the operating system and application software of the CK722.

When the elevator task runs successfully, it builds a database of all its defined elevators and floors. As soon as at least one elevator is defined, the elevator task starts communicating with the elevator controller through the specified port on the CK722. In case that port cannot be accessed correctly, the object's *Present Value* attribute is set to “Fault,” and the *Fault Cause* attribute is set to “Port.” Such a condition indicates a severe error with the operating system and application software of the CK722, or a hardware failure of the serial port.

When the elevator task is able to use the CK722's port correctly, it determines the status of the elevator controller. If after a certain number of tries no valid communication can be established, the object's *Present Value* attribute is set to “Offline,” while the *Fault Cause* attribute is set to “None.” Such a condition indicates an error with the elevator controller, or with the cabling between it and the CK722.

