

CONNECT  
USING BT

START

SERIALBT  
BEGIN

SERIALBT = HAS CLIENT?

READ  
BLUETOOTH  
DATA

READ = ?

"BLUE"

CONNECTION  
STATUS = BT

"SSID"

READ = "PASS"?

CONNECTION  
STATUS = WIFI

END

