

### 03.118 TCCS Auxiliary Fan Activation (03. HSS Procedures)

#### OBJECTIVE:

To activate the auxiliary cabin fans on the Trace Contaminant Control Subassembly (TCCS) panel.

#### NOTE

The TCCS auxiliary (aux) fans do not have variable speeds. They are used to increase air flow throughout the habitat during off-nominal operations.

GMWS

#### 1. ACTIVATE TCCS AUX FAN 1 AND FAN 2



**Figure 1.** Trace Contaminant Control Subassembly (TCCS) Panel

- 1.1. On the TCCS Panel, flip the power switch of Aux Cabin Fan 1 to “ON” (see Figure 1).
- 1.2. On the TCCS Panel, flip the power switch of Aux Cabin Fan 2 to “ON” (see Figure 1).
2. TURN ON AUX FANS ON HSS
  - 2.1. Access the HSS interface on Surface Pro
  - 2.2. Select the CDRA display
  - 2.3. Hover over Aux Fan 1
    - 2.3.1. Press finger to Aux fan one. The Aux fan One display should start moving
  - 2.4. Hover over Aux fan 2
    - 2.4.1. Press finger to Aux fan two, the Aux Fan Two display should start moving