

Edit Field Output Request

Name: F-Output-nuevo

Step: CasoEstatico

Procedure: Static, General

Domain: Whole model ☐ Exterior onlyFrequency: Every n increments ☐ n: 1

Timing: Output at exact times

☐ Output Variables☒ Select from list below ☐ Preselected defaults ☐ All ☐ Edit variables

S,MISES,U,RF,CF

☒ Stresses☐ Strains☒ Displacement/Velocity/Acceleration☒ Forces/Reactions☐ Contact☐ Energy☐ Failure/Fracture☐ Thermal**Note:** Some error indicators are not available when Domain is Whole Model or Int☐ Output for rebar

Output at shell, beam, and layered section points:

☒ Use defaults ☐ Specify: ☒ Include local coordinate directions when available

OK

Cancel