

	Changed buttons	
Hardware (DDJ-SZ)	Main Function	+Shift
FILTER	Color FX	
OSC NOISE	CFX Noise (Hold)	
OSC CYMBAL	CFX Crush (Hold)	
OSC SIREN	CFX Space (Hold)	
OSC HORN	CFX Resonant Filter (Hold)	
OSC VOLUME	Please keep it at zero!	
OSC PARAMETER	CFX parameter	
PARAMETER <	Random VideoFX	
PARAMETER >	Next VideoFX	

KEYBOARD mode / KEY SHIFT mode

PAGE 1

Semitone +12	No Assignment	No Assignment	No Assignment
Semitone +8	Semitone +9	Semitone +10	Semitone +11

PAGE 2 (Default)

Semitone +4	Semitone +5	Semitone +6	Semitone +7
Semitone ±0	Semitone +1	Semitone +2	Semitone +3

PAGE 3

Semitone -4	Semitone -3	Semitone -2	Semitone -1
Semitone -8	Semitone -7	Semitone -6	Semitone -5

PAGE 4

Semitone -12	Semitone -11	Semitone -10	Semitone -9
No Assignment	No Assignment	No Assignment	No Assignment

PAGE 5

Key Sync On / Off	Semitone Up	Semitone +7	Semitone +12
Key Reset	Semitone Down	Semitone -5	Semitone -12

PAGE 2 (Default)

1 beat (reverse direction)	1 beat (forward direction)	2 beats (reverse direction)	2 beats (forward direction)
4 beats (reverse direction)	4 beats (forward direction)	8 beats (reverse direction)	8 beats (forward direction)

PAGE 3

16 beats (reverse direction)	16 beats (forward direction)	32 beats (reverse direction)	32 beats (forward direction)
64 beats (reverse direction)	64 beats (forward direction)	128 beats (reverse direction)	128 beats (forward direction)