

HuboInitPanel

Joint CommandJoint StateSensor CommandSensor State

Ach Networking

Connect

Disconnect

IP Address

19216810

Status: Not Connected

Initialization Commands

Home All

Rehome

Start Sensors

Refresh Rate:

0.10

Joint Commands

☒ Home☐ Reset☐ Ctrl On☐ Ctrl Off☐ FET On☐ FET OFF☐ Beep

☐ Initialize

WST	NKY	NK1	NK2	LSP	LSR	LSY
LEB	LWY	LWR	LWP	RSP	RSR	RSY
REB	RWY	RWR	RWP	N/A	LHY	LHR
LHP	LKN	LAP	LAR	N/A	RHY	RHR
RHP	RKN	RAP	RAR	RF1	RF2	RF3
RF4	RF5	LF1	LF2	LF3	LF4	LF5

Connection
To Hubo

Homing
&
Sensor
Initialization
Commands

Joint States