

Chart 53

Copy Status

PURPOSE

This procedure displays the allow/inhibit status of the NE's Automatic Software Download feature. It also displays the status of a remote download (initiated by the Copy Program - Remote dialog) while this download is in progress.

PREREQUISITES

The following conditions must be met before starting this procedure:

- 1603 SM NE is equipped and in-service.
- User is logged on the NE using 1301 NMX.

GENERAL

The Copy Database function is typically used during software upgrades to write new data resident in the working (NEP) database to the non-volatile backup primary storage (COA). Copying from primary (COA) to working (NEP) is available also, but this copy function is not needed often because, in most instances, the primary database is updated when the working database is changed.

When performing this function, make sure you are copying from the desired source database (primary to working, or working to primary). Copying a corrupt or empty database into the valid provisioning database will corrupt or destroy the valid provisioning data.

This function is disabled if the NE is running bootcode.

Procedure

1. Select the following menu items: **Download**
2. Select Status tab button.

NOTE: *The Download - Status dialog screen displays.*

3. Click on Retrieve.
4. STOP. This procedure is complete.