

Chart 2

Assign or Delete NE to PC Domain

PURPOSE

This procedure is used to assign or delete an NE from a PC domain (new or existing domain).

PREREQUISITES

The following conditions must be met before starting this procedure:

- 1603 SM NE is equipped.
- User is logged on to the NE using 1301 NMX.

Procedure

1. Log on to the NE being added or deleted to the PC domain.
2. Do you want to assign an NE to a PC domain, or delete an NE from a PC domain?

If assign, go to step [3](#).

If delete, go to step [15](#).

Assign NE to PC Domain

1. In the scope pane, right-click [*NE Name*] to display a context menu.
2. From the context menu, select: **Provision>Network Element>Settings**
3. Click on PC Domain tab button.

4. Click on Retrieve.

NOTE: Initial factory default is Alcatel for host domain.

5. Select PC Domain ID (select 1 if first entry).
6. Click on Modify.
7. Enter domain name under PC Domain Name field (1...15 alphanumeric characters).
8. Click on OK.
9. Repeat steps [7](#) through [10](#) for other PC Domains to which the NE belongs.
10. Click on Send.
11. Click on Close.
12. STOP. This procedure is complete.

Delete NE from a PC Domain

1. In the scope pane, right-click [NE Name] to display a context menu.
2. From the context menu, select: **Provision>Network Element>Settings**
3. Click on PC Domain tab button.
4. Click on Retrieve.

NOTE: Initial factory default is Alcatel for host domain.

5. Select the PC Domain that the NE is being deleted from.
6. Click on Delete.

7. In the Confirm Delete pop-up window, click on Yes.
8. Click on Close.
9. STOP. This procedure is complete.