

Chart 8

Set NE Date and Time

PURPOSE

This procedure is used to set date and time for the NE.

PREREQUISITES

The following conditions must be met before starting this procedure:

- 1603 SM NE is equipped and in-service.
- User is logged on the NE using 1301 NMX.

GENERAL

Clear any unexpected alarms that occur during these procedures by referring to the 1603 SM Maintenance and Trouble Clearing manual. To set NE Name refer to Chart [3](#).

Procedure

1. In the scope pane, right-click [*NE Name*] to display a context menu.
2. From the context menu, select: **Provision>Network Element>Settings**
3. Click on Time and Date tab button.
4. Click on PC Time/Date.
5. If the Time and Date do not display, click on Retrieve.
6. Click in the Time field, backspace over existing time, and enter new time in the form of

HH:MM:SS, where
HH = hour (0...23)
MM = min (0...59)
SS = sec (0...59)

1. Click in the Date field, backspace over existing date, and enter new date in the form of MM:DD:YY, where
mm = month (1...12)dd = day (1...31)yy = year (00...99)
2. Click on Send (answer Yes to dialog message that appears).
3. Click on Close.
4. STOP. This procedure is complete.