



8.4 Functions



8.4.1 Advanced Menu

⚠ Through the control, it is possible to access the advanced menu.


To access the advanced menu

- ▶ with the display off, hold down  for 10 seconds
The device turns on and the temperature appears.
- ▶ keep pressed until the indication  appears


To navigate in the menu

- ▶ use the icons  

To select a menu item and to confirm the changes made

- ▶ press the key  for about 2 seconds
*During the modification the symbol flashes to remind you that you are in the setup menu.
Confirming the change takes you to the next item.*

To exit the menu

- ▶ press the icon  for 10 seconds
- ▶ or wait 30 seconds the automatic shutdown

⚠ After a period of 30 seconds from the last action, the display turns off.

Menu items

Ad: Modbus address

uu: Not used

br: Adjust the brightness

di: Digital input

UC: UV lamp options

rH: Not used

rC: Not used

Fr: Factory reset




ot: Offset probe T

Sc: Scale

rE: Not used




Set the ModBus address

To set the Modbus address

- ▶ select 
 - ▶ increase or decrease the value with the icons  
- The setting range is from 01 (min) to 99 (max).*

Adjust the brightness



To adjust the brightness

- ▶ select 
 - ▶ increase or decrease the value with the icons  
- The brightness setting range is from 00 to 01.*

⚠ The display brightness changes after confirm the modification.


⚠ You can also reduce the brightness of the display through the keys of the control.

To reduce the lightness of the display via the control keys


- ▶ from the display off, press  for about 20 seconds
01 will appear.
- ▶ press  *00 will appear.
Wait 30 seconds and check the correct setting.*

Select Digital Input

To change digital input





- ▶ select 
- ▶ select CP for potential-free contact (default)
- ▶ select CO to cooling open
- ▶ select CC to cooling close
By default digital input is set to CP.

⚠ For return to the default settings, set the digital input to "CP".


⚠ By selecting one of the other inputs (CO,CC) the seasonality is locked. It is not possible to modify it through the key  of the control.

UV lamp options

To enable UV lamp option

- ▶ select 
- ▶ use the   icons to move inside the menu
- ▶ select No to disable the UV lamp option
- ▶ select RE to enable the UV lamp option with residential operation (only with an active fan)
- ▶ select SA to enable the UV lamp option (in sanitary operation always on)
- ▶ press  to confirm
By default the UV lamp option is set to No.


Reset Modbus

- ▶ select 
- ▶ select "no" to keep the current settings
- ▶ select "YS" to reset the settings






Incorrect setpoint
The symbol of the function activated flashes and ventilation is stopped until the set setpoint is reached.

Factory reset**To reset the control to factory settings**


- ▶ select 
- ▶ select "YS" to reset the settings
- ▶ select "no" to keep the current settings

Probe T regulation offset (room temperature probe)**To adjust the probe T**

- ▶ select 
 - ▶ increase or decrease the value with the icons  
- The setting range is from -9 to 12.*

- ⚠ Use this adjustment carefully.
- ⚠ This adjustment must be carried out only after having found actual deviations from the room temperature using a reliable tool.
- ⚠ Adjust the value within a range of -9 °C to +12 °C, in steps of 0,1 °C.
- ⚠ After 30 seconds from the last action the control goes out and the settings is memorized.

Scale**To change the temperature unit of measure**

- ▶ select 
 - ▶ select °C or °F
- By default the temperature unit of measure is ° C.*

8.4.2 Long period shut-down

For seasonal shutdowns or for long periods:

- ▶ disable the device
- ▶ set the main system switch to "OFF"

- ⚠ The antifreeze function is not on.

8.4.3 Error signals**Displayed alarms**

- ▶ E1 Room temperature probe failure
None of the modes can be activated.
- ▶ E2 Faulty fan motor
Caused by jamming due to foreign bodies or a failure of the rotary sensor.
- ▶ E3 Probe T2 water temperature unsuitable
Ventilation is temporarily stopped until the set setpoint is reached.
- ▶ E5 Probe T3 water temperature unsuitable
Ventilation is temporarily stopped until the set setpoint is reached. (Only for ECA647 - EWF647 controls).