


MaxAir – Usr Accounts

Introduction

MaxAir supports two types of user account, 'Administrator' and 'None-Administrator'. The difference between the two types is that 'Administrator' type accounts have full access to all the features of MaxAir, whilst 'None-Administrator' access is both limited and the user display configurable.

An initial 'admin' is installed at system setup, the details, including the password, can be changed by clicking on the toolbar 'Person' icon and selecting 'Change Password'.



The 'Change Password' screen allows a new password to be entered, confirmed and saved.

Change Password

Edit Password Details below.
Do not use any special character i.e ' ` , & ? { } [] () - ; ! ~ * % \ |

Full Name

Administrator

Username

admin

Email Address

Old Password

Old Password

New Password

New Password

Confirm Password



Confirm New Password

Cancel

Save

Outside: 6° C Clouds - overcast clouds

New user accounts can be added and edited using the 'Settings/System Maintenance/User Accounts' option.



Selecting this option allows the editing of existing accounts, the deletion of existing account (Note: the 'admin' and the logged-on accounts cannot be deleted).

The format of the screen is the same for both editing an existing user or adding a new user.

Add User

Add New User Account Details below.
Do not use any special character i.e ' , & ? { } [] () - ; ! ~ * % \ |

☐ Enable User Account
Disabling the account will prevent the user accessing the system.

☐ Administrator Account
Account with full access to all systems features and settings.

☐ Persistent Session
Session does not timeout after 24 minutes.

Full Name

Username

Email Address

New Password


Confirm Password

Outside: 6° C Clouds - overcast clouds

Enter the relevant user details and click on 'Enable User Account' to activate the account. Note: the account can be made an administrator type account by clicking in 'Administrator Account' and/or the user session made to not timeout by clicking on 'Persistent session'. Click on 'Save' to either add the new account or save the changes to an existing account.

None-Administrator Accounts

When logged-on as a 'none-administrator' the 'Settings' option is not displayed on the top right toolbar, also both the 'One Touch' and 'Mode' buttons are removed from the Home screen display.



An 'administrator' can determine which additional tiles are displayed, in the above example the 'Boost' and 'Live Temp' tiles have been selected for display, along with the 'MySensor 1' tile.

What to display is configured by an 'administrator' account. To determine which function tiles to display (ie. Boost, Override, Night Climate, Away, Holidays, Live Temp, Add Theme, Add relay, Add Sensor, Add MQTT Dev and Add Zone), use the 'Settings/System Configuration/Set Buttons' option to allocate required tiles to the Home screen, rather than the One Touch screen.

In this example only the 'Boost' and 'Live Temperature' tiles are allocated to the Home screen and so will still be displayed for 'none-administrator' type users.

Set Buttons

Place Buttons on Home or OneTouch Screen and set display ordering.

Button Name	Toggle Page	Index Number
Boost	Home	1
Override	OneTouch	2
Offset	OneTouch	3
Night Climate	OneTouch	4
Away	OneTouch	5
Holidays	OneTouch	6
Live Temperature	Home	7

CloseSave

Sensors can be hidden on the Home screen using two different methods. The first is by setting the sensor to 'Not Show' in the sensor configuration. Use the 'Settings/Device Configuration/Sensors' option and de-select 'Show' for the sensor you do not wish to display and then click the 'Save' button. Note: this will not display the sensor for all users, including 'administrators'.

Sensor Settings

Edit or Delete the Sensor's Configuration.
Sensors Allocated to a Zone Cannot be Deleted.
Last Seen Date/Time is shown with Sensor Name.

Sensor Name	Node ID	Sensor Child ID	Mode	Correct Factor	Res +/-	Zone Name	Show	DB Msg	
MySensors 1 (2024-02-27 10:27:48)	41	0		0	0.0	Not Allocated	<input type="checkbox"/>	<input checked="" type="checkbox"/>	
MySensors 2 (2024-02-27 10:29:36)	31	0		0	0.0	Not Allocated	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
MySensors 2-1 (2024-02-27 10:29:36)	31	1		0	0.0	Not Allocated	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	

Close

Save

Add Sensor

The second method hides both sensors and relays on a user-by-user basis. Use the 'Settings/Device Configuration/Hide Sen/Rel' option. In this example 'Sensor 1' will be displayed for 'user1' and all sensors will be hidden for 'user2'.

Hide Sensors and/or Relays

Select Sensors and/or Relays which will not be displayed for the selected User.

Note 1: All Sensors and Relays will be displayed for the 'admin' user.
Note 2: Sensors and Relays allocated to 'Heating' type Zones will ALWAYS be displayed and are NOT selectable.

Name	Type	user1	user2
MySensors 1	Sensor	<input type="checkbox"/>	<input type="checkbox"/>
MySensors 2	Sensor	<input checked="" type="checkbox"/>	<input type="checkbox"/>
MySensors 2-1	Sensor	<input checked="" type="checkbox"/>	<input type="checkbox"/>

Close

Save