

Issue No. 01	Rev. No: 02	Effective Date: 20.09.2017	SOP/INST/047
Issued By: M.R		Approved By: HOD - INSTRUMENTATION	
SOP for S7300 PLC UPLOAD & DOWNLOAD PROCEDURE			

Establish the Communication Between PC And PLC:

- CONNECT THE SERIAL /USB CABLE ADAPTER FROM LAPTOP TO S7 300 PLC CPU.



- FIRST CLICK ON START BUTTON IN LAPTOP.



- SELECT SIMATIC MANAGER FROM THE SOFTWARE LIST




OR

- OPEN BY ALL PROGRAMS – SIMATIC – SIMATIC MANAGER




Issue No. 01	Rev. No: 02	Effective Date: 20.09.2017	SOP/INST/047
Issued By: M.R		Approved By: HOD - INSTRUMENTATION	
SOP for S7300 PLC UPLOAD & DOWNLOAD PROCEDURE			


- FOR CHECKING THE COMMUNICATION CLICK ACCESSIBLE NODES ICON



- IF COMMUNICATIONS ARE SUCCESSFUL BELOW POP UP WILL APPEAR.




- IF COMMUNICATIONS FAILS, BELOW POP UP WILL APPEAR




Issue No. 01	Rev. No: 02	Effective Date: 20.09.2017	SOP/INST/047
Issued By: M.R		Approved By: HOD - INSTRUMENTATION	
SOP for S7300 PLC UPLOAD & DOWNLOAD PROCEDURE			

- IN ORDER TO COMMUNICATE WITH PLC CLICK “SET PG/PC INTERFACE.”




- FOLLOWING DIALOG BOX WILL OPEN UP DISPLAYING ALL THE DIFFERENT INTERFACES. ONCE THE PROPER INTERFACE IS SELECTED AND THE PROPERTIES ARE SET THEN CLICK “OK”

Issue No. 01	Rev. No: 02	Effective Date: 20.09.2017	SOP/INST/047
Issued By: M.R		Approved By: HOD - INSTRUMENTATION	
SOP for S7300 PLC UPLOAD & DOWNLOAD PROCEDURE			




➤ IN ORDER TO COMMUNICATE WITH PLC CLICK “SET PG/PC INTERFACE.”



Issue No. 01	Rev. No: 02	Effective Date: 20.09.2017	SOP/INST/047
Issued By: M.R		Approved By: HOD - INSTRUMENTATION	
SOP for S7300 PLC UPLOAD & DOWNLOAD PROCEDURE			


- FOLLOWING DIALOG BOX WILL OPEN UP DISPLAYING ALL THE DIFFERENT INTERFACES. ONCE THE PROPER INTERFACE IS SELECTED AND THE PROPERTIES ARE SET THEN CLICK “OK”




UPLOAD THE PROGRAMME:

- FIRST OPEN NEW PROJECT FROM FILE MENU

Issue No. 01	Rev. No: 02	Effective Date: 20.09.2017	SOP/INST/047
Issued By: M.R		Approved By: HOD - INSTRUMENTATION	
SOP for S7300 PLC UPLOAD & DOWNLOAD PROCEDURE			




- PROVIDE FILE NAME AND SELECT LOCATION THROUGH BROWSE.
- THEN GIVEN FILE NAME WILL APPEAR IN THE MAIN SCREEN.
- SELECT PLC > UPLOAD STATION TO PG.



Issue No. 01	Rev. No: 02	Effective Date: 20.09.2017	SOP/INST/047
Issued By: M.R		Approved By: HOD - INSTRUMENTATION	
SOP for S7300 PLC UPLOAD & DOWNLOAD PROCEDURE			

- IN THE NEXT SCREEN, FILL THE SLOT AND NODE ADDRESS OF THE COMMUNICAION PORT ON THE CPU. EX. BELOW CPU OVER MPI WITH NODE ADDRESS 10;



Select Node Address

Which module do you want to reach?

Rack: 0

Slot: 2

Target Station: ☒ Local
☐ Can be reached by means of gateway

Enter connection to target station:

MPI address	Module type	Station name	Module name	Plant designation
10	CPU841-0			

Accessible Nodes

View


OK Cancel Help

- AFTER CLICKING OK THE WHOLE CONTENTS OF THE PLC INCLUDING ALL BLOCKS AND HARDWARE CONFIGURAION WILL BE UPLOADED IN TO A NEW SELECTED PROJECT.

Issue No. 01	Rev. No: 02	Effective Date: 20.09.2017	SOP/INST/047
Issued By: M.R		Approved By: HOD - INSTRUMENTATION	
SOP for S7300 PLC UPLOAD & DOWNLOAD PROCEDURE			



DOWN LOAD THE PROGRAMME:

- FIRST IN ORDER TO ENABLE DOWNLOAD FIRST SELECT THE BLOCK WHICH WE WISH TO DOWNLOAD AND THEN CLICK DOWNLOAD.



Issue No. 01	Rev. No: 02	Effective Date: 20.09.2017	SOP/INST/047
Issued By: M.R		Approved By: HOD - INSTRUMENTATION	
SOP for S7300 PLC UPLOAD & DOWNLOAD PROCEDURE			

- CPU NEEDS TO BE IN STOP MODE BEFORE DOWNLOADING THE SYSTEM DATA BLOCK AS THIS IS EQUIVALENT TO A HARDWARE CONFIGURATION DOWNLOAD. IF WE DOWNLOAD THE SYSTEM DATA, FOLLOWING MESSAGES WILL APPEAR.




- IF THE CPU IS IN RUN MODE THEN IT WILL BE GO TO STOP THE CPU. THE SOFTWARE WILL DO THE RUN TO STOP TRANSITION WHEN WE CLICK OK.



Issue No. 01	Rev. No: 02	Effective Date: 20.09.2017	SOP/INST/047
Issued By: M.R		Approved By: HOD - INSTRUMENTATION	
SOP for S7300 PLC UPLOAD & DOWNLOAD PROCEDURE			

- AFTER DOWNLOADING THE SDB WILL PROMPTED TO RUN THE CPU AGAIN.



- CLICKING YES WILL AUTOMATICALLY PUT THE CPU BACK INTO RUN MODE.