

Run

Program

Installation

Move

I/O

Log

PROGRAM

<unnamed>

INSTALLATION

default

New...

Open...

Save...

C

C

C

C

Basic

Move

Waypoint

Wait

Set

Popup

Halt

Comment

Folder

Advanced

Templates

Robot Program

<empty>

Command

Graphics

Variables

Program

Here you can program your robot to do tasks.

To program your robot, select the nodes from the **Node List** and they will appear on the **Program Tree**.

Node List

Program Tree

Add Before Start Sequence

Set Initial Variable Values

Program Loops Forever

Speed

100%