



0. Disconnect Arduino from USB  
Make connections:

1. Black from pump -> GND
2. Red from pump -> COM on relay
3. NO (normally open) on relay -> VIN
4. VCC on relay -> RED on Arduino
5. GND on relay -> BLACK on Arduino
6. IN on relay -> 13 on Arduino
7. Load Blink from examples.
8. Change interval to 5 seconds.

