



1. Connect power (GND and VDD)
2. Connect SDA and SCL
3. gyro_L3G4200.ino

