

[illegible]

Reza Al Kutsar Lubis
Supervisi Alat Bongkar Muat Darat

Ifsan Rosady
Asisten Manajer Peralatan

| REMARKS | | |
|---------------------------------|--|--|
| NOTE : | <div style="display: inline-block; width: 15px; height: 15px; background-color: red; border: 1px solid black; margin-right: 5px;"></div> PM 250H | <div style="display: inline-block; width: 15px; height: 15px; background-color: blue; border: 1px solid black; margin-right: 5px;"></div> PM 500H |
| | <div style="display: inline-block; width: 15px; height: 15px; background-color: green; border: 1px solid black; margin-right: 5px;"></div> PM 2500H | <div style="display: inline-block; width: 15px; height: 15px; background-color: yellow; border: 1px solid black; margin-right: 5px;"></div> DAILY/WEEKLY |
| | <div style="display: inline-block; width: 15px; height: 15px; background-color: purple; border: 1px solid black; margin-right: 5px;"></div> PM 1000H | <div style="display: inline-block; width: 15px; height: 15px; background-color: orange; border: 1px solid black; margin-right: 5px;"></div> PM 2000H |
| PM 250H / Monthly | | |
| ALL GREASING POINT | | |
| 1 | General Grease | Pertamina EPX NL 2/ EP2 |
| | | 2 Kg |
| ENGINE | | |
| | Air Filter | Check Condition |
| BATTERIES | | |
| | Battery | Check Condition (Replace if Needed) |
| HYDRAULIC | | |
| | Cab Lifting | Check oil level |
| REAR AXLE/GEARBOX/CARDAN | | |
| | Disc Brake | Check pad wear |
| | | Check caliper running clearance |
| | | Check lining wear |
| | | Check brake shaft |
| | Fifth Wheel | Check for bent, worn/broken part |
| | | Check crack on part |
| | | Check Locking Mechanism |
| | Wash & Clean TT & Chassis | |
| CABIN | | |
| | Wiper | Check Function & Clean |
| | Chair | Check Condition & correct mounting |
| | Hand bars & foot step | Check Condition |
| | Radiator, hoses & pipe | Check Condition, correct mounting, leak & Clean external pollution |
| | Exhaust | Check Condition & correct mounting |
| | Fuel system | Check function, correct mounting & leaks for tank, hoses, pipes & venting |
| PM 500H/ 6 Monthly | | |
| ENGINE | | |
| 1 | Oil Engine | Valvoline 15W 40 |
| | | 20 Ltr |
| 1 | Oil Filter | |
| | | 1 pcs |
| 1 | Fuel Filter | |
| | | 1 pcs |
| 1 | Fuel / Water Sparator | |
| | | 1 pcs |
| | Engine | Check for Leakage |
| | | Check & Correct mounting bolt, suspension & cooler suspension |
| | | Check engine low idle in (700-800 rpm) |
| TRANSMISSION | | |
| 1 | Oil Transmission | Shell Spirax S4 ATF HDX |
| | | 20 ltr |
| 1 | Main Filter | |
| HYDRAULIC | | |
| 1 | Oil Power Steering | Shell Tellus VG 46 |
| | | 3 ltr |
| 1 | Oil Cab Lifting | Shell Tellus VG 46 |
| | | 1 ltr |
| PM 1000H/ Annual | | |
| ENGINE | | |
| 1 | Air Filter | |
| | | 1 pcs |
| 1 | Air Dryer | |
| | | 1 pcs |
| ENGINE | | |
| | Valve IN/OUT | Check & adjust clearance if needed (when engine cold) |
| | Crackcase Breather | Clean when Checking Valve Clearance |
| REAR AXLE/GEARBOX/CARDAN | | |
| | Oil | Check oil level |
| PM 2000H/ Annual | | |
| ENGINE | | |
| 1 | Coolant | Change Coolant |
| | | 15 ltr |
| PM 2500H/ Annual | | |
| REAR AXLE/GEARBOX/CARDAN | | |
| 1 | Oil Cardan | Shell Spirax S3 G 80W - 90 |
| | | 12 ltr |
| DAILY/WEEKLY | | |
| TRANSMISSION | | |
| | Oil | Check oil level with engine running idle & transmission in neutral position |
| ENGINE | | |
| | Oil | Check oil level for leakage |
| | | Drain water plug on fuel pre filter with separator |
| | Coolant | Check Quality & Level (change if < 1/3) |
| | Air Dryer | Open manual drain valve |
| CABIN | | |
| | Mirror | Check Condition & correct mounting |
| | Inside Cabin | Cleaning Inside Cabin |
| | Wiper | Refill Liquid |
| | Pneumatic Tyre | Check Condition (Pressure, Damage, Depth) or 750Kpa of 100 Psi |
| | Retorque | |
| FRONT AXLE | | |
| | Wheel Hub | Check Leakage |