



Qualität von Anfang an.

Original Operating Manual Pressure Reducer

DM
DK
SD



© by **END-Armaturen GmbH & Co. KG**

All rights reserved. No part of this publication may be copied or published by means of printing, photocopying, microfilm or otherwise without prior written consent of **END-Armaturen GmbH & Co. KG**. This restriction also applies to the corresponding drawings. **END-Armaturen GmbH & Co. KG** has the right to change parts of the valves at any time without prior or direct notice to the client. The contents of this publication are subject to change without notice.

This publication has been written with great care. However, **END-Armaturen GmbH & Co. KG** cannot be held responsible, either for any errors occurring in this publication or for their consequences.

The products are specified by the statements in this documentation; no assurance of the properties is given.

END-Armaturen GmbH & Co. KG
Oberbecksener Straße 78
D-32547 Bad Oeynhausen
Telefon: 05731 / 7900 - 0
Telefax: 05731 / 7900 - 199
Internet: <http://www.end.de>
E-Mail: post@end.de

Edition: 09.2012

Contents

1	Foreword	4
2	General advice	5
2.1	Validity	5
2.2	Inward monitoring	5
2.3	Complaints	5
2.4	Warranty	5
2.5	Symbols and their Signification	6
3.	Safety advice	7
3.1.	Personal protection	7
3.1.1.	Safety advice for mounting	7
3.1.2	Safety advice for adjustment and starting	8
3.1.3	Safety advice for maintaining / repairing	8
3.2	Device safety	9
4	Name-plate	10
5	Pressure reducer	11
5.1	General	11
5.2	Corresponding use	11
5.3	Mounting position	11
5.4	Mounting / Disassembly	12
5.4.1	Mounting with threaded connection	14
5.4.2	Mounting with screw pipe connection	14
5.4.3	Mounting with welded connection	15
5.4.4	Mounting with flanged connection	16
5.6	Maintenance	18
5.5.1	Cleaning of the mesh (only Art. SD)	18
6	Index	20
7	Declaration in conformity as defined by Pressure-Equipment-Directive 97/23/EC	22

1 Foreword

Dear customer,
Dear assembler / user,

these operation and installation manuals are intended to give you the knowledge which is necessary for you to be able to carry out the mounting and adjustment of an pressure reducer rapidly and correctly.



Please read these instructions carefully and pay particular attention to the advice and warning notes.

Only instructed and qualified mechanician should mount, adjust or maintain the pressure reducer.

If you have any questions in relation to the pressure reducer, we shall be pleased to answer them.

The telephone number will be found on the inside cover of these operation and installtion manual.

Yours

END-Armaturen GmbH & Co. KG

2 General advice

2.1 Validity

These mounting and installation manual is valid for the standard version of the pressure reducer.

2.2 Inward monitoring

Please check

- directly after delivery the pressure reducer for any transport damages and deficiencies
- with reference to the accompanying delivery note the number of parts.

Do not leave any parts in the package.

2.3 Complaints

Claims for replacement of goods which relate to transport damage can only be considered valid if the delivery company is notified without delay.

In case of returns (because of transport damage/repairs), please make a damage protocol and send the parts back to the manufacturer, if possible in the original packaging.

In case of return, please mention the following:

- Name and address of the consignee
- Stock-/ordering-/article-number
- Description of the defect

2.4 Warranty

For our pressure reducer we give a guarantee period in accordance with the sales contract.

The warranty and guarantee rules of **END-Armaturen GmbH & Co. KG** are applicable.

2.5 Symbols and their Signification



Paragraphs which are identified with this symbol contain very important advices; this also includes advices for averting health risks.
Observe these paragraphs without fail!



Paragraphs which are identified with this symbol contain very important advices; this also includes how to avoid damage to property.
Observe these paragraphs without fail!



This symbol indicates paragraphs which contain comments/advice or tips.



This bullet identifies the description of actions which you should carry out.

3. Safety advice

Depending on the technical circumstances and the time under and at which the pressure reducer is mounted, adjusted and commissioned, you must in each case take into account particular safety aspects!

If, for example, the pressure reducer works in an operational chemical plant, the potential hazards of commissioning have another dimension from that when this is only being carried out for test purposes in a „dry“ part of the plant in the assembly room.

Since we do not know the circumstances at the time of the mounting/adjustment/commissioning, you may find advice on hazards in the following descriptions which are not relevant to you .

Please observe (only) the advice which applies to your situation!

3.1. Personal protection

3.1.1. Safety advice for mounting



We wish to point out expressly that the mounting, the electrical installation and the adjustment of the pressure reducer and the accessories must be carried out only by trained specialist personnel having mechanical and electrical knowledge!



**Switch off all the devices / machines / plant affected by mounting or repair.
If appropriate, isolate the devices / machines / plant from the mains.**



Check (for example in chemical plants) whether the switching off of devices / machines / plant will cause potential danger.



If appropriate, in the event of a fault in the pressure reducer (in a plant which is in operation) inform the shift foreman / safety engineer or the works manager without delay about the fault, in order, for example, to avoid an outflow / overflow of chemicals or the discharge of gases in good time by means of suitable measures!



Before mounting or repair, remove the pressure from pneumatic / hydraulic devices / machines / plant.



Empty the conduit from medium.



If necessary, set up warning signs in order to prevent the inadvertent starting up of the devices / machines / plant.



Observe the respective relevant professional safety and accident prevention regulations when carrying out the mounting / repair work.



Check the correct functioning of the safety equipment (for example the emergency push off buttons/ safety valves, etc)!

3.1.2 Safety advice for adjustment and starting



As a result of the starting of a pressure reducer the flow of gases, steam, liquids, etc. may be enabled or interrupted!



Satisfy yourself that, as the result of the starting or the test adjustments of the pressure reducer, no potential hazards will be produced for the personnel or the environment!



If necessary, set up warning signs in order to prevent the inadvertent starting up or shutting down of the devices / machines / plant.



By ending mounting check the correct function and the tightness of the valve.



Check the right function of all safety devices (for example emergency off push buttons / safety valves, etc.)!



Carry out the starting and the adjustments only in accordance with the instructions described in this documentation!

3.1.3 Safety advice for maintaining / repairing



Do not carry out any maintenances / repairs if the pressure reducer will be under pressure.

Before disassembling a pressure reducer some essential points should be clarified!



- Will the pressure reducer to be disassembled be replaced by another immediately?
- If appropriate, does the production process of the plant needed to be stopped?
- Is it necessary to inform specific personnel about the disassembly?



If necessary, inform the shift foreman/ safety engineer or the manager about the maintenance or repair without delay in order, for example, to avoid an outflow/ overflow of chemicals or a discharge of gases in good time by means of suitable measures.



Switch off pilot pressure and the power supply and relieve the pressure in the pipes.

If necessary set up warning signs in order to prevent



- the inadvertent starting up of the devices/machines/plants in which the pressure reducer is mounted
- the switching on of pilot medium supply, pilot power supply and/or the power supply of actuators and accessories.



In case of defect in the pressure reducer make contact to the supplier. The telephone number will be found on the back cover of these mounting and installation manual.



If you ascertain a damage of the pressure reducer, isolate the device from the mains. Please observe the safety advices.



Do not mount, start or adjust the pressure reducer if itself, the pipes or a mounted actuator will be damaged.

3.2 Device safety

The pressure reducers

- are quality products which are produced in accordance to the recognized industrial regulations.
- left the manufacturer`s work in a perfect safety condition.



In order to maintain this condition, as installer / user you must carry out your task in accordance with the description in these instructions, technically correctly and with the greatest possible precision .



We assume, as a trained specialist you are having mechanical and electrical knowledge!



Satisfy yourself that the pressure reducers will only be used within their admissible limiting value (see the technical data) .

The pressure reducers must be used only for a purpose corresponding to their construction!

The pressure reducers must be used within the values specified in the technical data!



The operating of the pressure reducers outside the nominal temperature range could destroy the seals and the bearings.



The operating of the pressure reducers outside the nominal pressure range could destroy the inner parts and the body.

Never remove a cap or a other component part if the pressure reducers will be under pressure.



Do not mount, start or adjust the pressure reducers if itself, the pipes or a mounted actuator will be damaged.



After the maintenance or repair check the right function of the pressure reducers and the tightness of the pipe connections.



Pressure reducer are not shut-off elements providing leak-proof seating.

Name-plate

4 Name-plate

The pressure reducers will be provided with a name-plate, which permits a definite identification of the pressure reducers and shows the most important technical data to you. The name-plate should not be displaced or changed.




Fig. 4.1 -name-plate

Art.Nr.	Article number of the pressure reducer
Serial	Order- or production number
Inlet pressure	max. admissible inlet pressure of the pressure reducer [bar]
Outlet pressure	outlet pressure range of the pressure reducer [bar]
Temperature (TS)	temperature range of the pressure reducer [°C]
G/DN	connecting size of the valve
Testing pressure (PT)	testing pressure of the pressure reducer
Fluidgroup	allowed fluid group of the pressure reducer
Date of manufacturing	Week and year of the manufacturing

5 Pressure reducer

5.1 General

Before mounting /disassembly the pressure reducer we assume that you have read the advices and warnings from chapter 3.



→ safety advice

If you have not read chapter 3. until now, read these important advices now and turn back to this page.

5.2 Corresponding use



Pressure reducers will be used to reduce the medium pressure (inlet pressure) upstream of the pressure reducer to a reduced pressure (outlet pressure) downstream of pressure reducer . It should only be used clean liquids and gases without doubts concerning the material resistance of the pressure reducer. Pollution or using outside the nominal pressure range and/or the nominal temperature range should causes damages on the pressure reducer especially on the diaphragm.



Pressure reducer are regulating devices, not shut-off elements providing leak-proof seating. A leakage rate of 0,05% of the Kvs- value is permitted. Therefore we recommend the installation of a shut-off valve.

5.3 Mounting position



The preferred location of pressure reducers in pipework systems is where the operating conditions are stable, that is not immediately upstream or downstream from bends, branches, pressure devices, stop valve fittings or similar restricting elements, and not adjacent to consumer points.



Pressure reducer should be fitted to horizontal sections of the pipe.

Mounting position at liquid and gaseous media




Fig. 5.1 - Pressure reducer, Mounting position at liquid and gaseous media

Mounting position



At liquid and gaseous media the piston design pressure reducer and the diaphragm design pressure reducer with size: 01/03/05 can be fitted with vertical up and vertical down standing spring bonnet. Diaphragm design pressure reduce for extremely low outlet pressures must be fitted with vertical down standing spring bonnet.



At steam application all pressure reducers must be fitted with vertical down standing spring bonnet.

mounting position medium steam




Fig. 5.2 - pressure reducer, mounting position medium steam

5.4 Mounting / Disassembly



The mechanical installation are the same by all variants. It differs by the type of connection only.



Consider the flow direction of the medium, specified on the valve body. Pressure reducers should be install with released spring.



We recommend the installation of a shut-off valves in front of and behind the pressure reducer to enable to clean the pressure reducer without empty of the conduit.



Remove the hole packing material (e.g. caps and plugs). Take care that there will be no packing material or other pollution in the pressure reducer.



Before mounting the pressure reducer clean up the pipes. If fouling during operation is unavoidable, a strainer must be fitted in front of the pressure reducer.



Avoid strains on the body by non align pipes.



Screw a manometer into the manometer port. Not used ports must be closed by fit plugs.



In same cases the installation of a safety valve behind the pressure reducer will be necessary to prevent the maximum permissible pressure from being exceeded in the downstream section of the pipe.




Fig. 5.3 - pressure reducer, mounting diagram



Where a fault in the pressure reducer could result in an unacceptable breakdown of downstream consumer units, a by-pass with a shut-off device must be provided. In the event of a fault, emergency operation can be maintained via by-pass.



The by-pass must be kept closed during normal operation.




Fig. 5.4 - pressure reducer, mounting diagram with by-pass

Special Advice,- installation in boiler systems








Pressure reducer have to be installed in the upstream (cold water) of the system to avoid calcification. The distance to the check valve has to be far enough that the pressure reducer can not be reached by hot water even if the check valve is defective.






Please refer to DIN 1988 and AD leaflet A3 DIN 4753.

5.4.1 Mounting with threaded connection

-  Before lay on sealing compounds, check the hardly screwing by the pipes into the pressure reducer's body.
-  Lay on the correct sealing compounds on the pipes end. By using PTFE- ribbon or hemp seals consider the screw direction. Don't use sealing compounds which are not prescribed for your employment.
-  Screw the pipes into the threaded ends of the pressure reducer. Don't use the bonnet of the spring as a lever.
-  Strike up the pipes with pressure after that time the manufacturer of the sealing compounds pre-tends for harden it.
-  Check the tightness of all connections.

5.4.2 Mounting with screw pipe connection

-  Before lay on sealing compounds, check the hardly screwing by the pipes into the pressure reducer's body.
-  Lay on the correct sealing compounds on the pipes end. By using PTFE- ribbon or hemp seals observe the screw direction. Don't use sealing compounds which are not prescribed for your employment.
-  Put the screw caps onto the pipes and screw the screw pipe connections into the pipes.








Fig. 5.5 - pressure reducer, mounting with screw pipe connection (Fig. Art. SD220025). Option: manometer Art.M073xx

-  Put the pressure reducer with the seals between the screw pipe connections and tighten the screw caps.
-  Adjust the pressure reducer to the pipes. Tighten the screw caps.
-  Strike up the pipes with pressure after that time the manufacturer of the sealing compounds pretends for harden it.
-  Check the tightness of all connections.

5.4.3 Mounting with welded connection



The safety demands by welding are depending on the place and the position of the point of weld. Welding the parts at a serviceable device/machine/plant the potential of danger is as higher as welding the parts in a welding room.



If appropriate, inform the shift foreman / safety engineer or the works manager and the fire brigade of your factory



By welding observe your own national guide lines about safety and prevention of accidents.



By welding the body of the pressure reducer with the pipes observe appropriate demands and guide lines.




Abb. 5.6 - pressure reducer, mounting, welded connection, use of heat absorbing paste (Fig. Art. DM330362).

Mounting / Disassembly



To protect the seals of the of a pressure actuated valve you have to apply a amount of heat absorb-ing paste (e.g. TECHNOLIT heat absorbing paste, BLOC-IT heat absorbing paste, METAFLEX THER-MEX) to the area to be protected.

By using the heat absorbing paste you have to observe the instructions of the manufacturer.



By making multiple welding seam, the valve will have to be cool down after every working opera-tion.



After welding check the function of the pressure reducer.



Check the tightness of all the connections.

5.4.4 Mounting with flanged connection



We assume, that you have mounted the flanges at the end of pipes and they are cooled down. (e.g. welded flanges).



Push the body of the pressure reducer between the flanges by using the appropriate seals.



Aligns the flange boring and put the fit screws through the holes.





Fig. 5.7 - pressure reducer, mouting with flanged connection (Fig.: Art. DM330302). Option: manometer Art.M073xx

 Screw the fit nuts onto the screws and tighten it up crosswise. By doing this consider the maximum torque moment of the screws.

 Check the tightness of all connections.

5.5 Operation

 Before putting the the pressure reducer into operation the regulation spring should be released by turning the toggle spindle anticlockwise.

 The upstream shut-off valve must be opened slowly until the inlet pressure reaches the limit.

 Next adjust the outlet pressure by turning the toggle spindle clockwise




There must be some medium consumption on the outlet side to set the required outlet pressure .




Adjusting the desired outlet pressure at zero consumption observe that the outlet pressure will decrease below the adjusted range in case of medium consumption. The pressure decrease is depending on the medium consumption.



Adjusting the desired outlet pressure at medium consumption observe the outlet pressure will increase above the adjusted range in case of zero consumption.

 Once the adjustment is complete, the toggle spindle should be secured with the lock nut.

 During the adjustment a sharply fluctuating flow or shock pressure loading are to be avoided.



In case of using the pressure reducer for steam applications the tightening of the screws and the ground cap once the pressure reduce has throughly heated up will be necessary.




Fig. 5.8 - pressure reducer, adjustment of the outlet pressure (Fig. shows Art. DM330323).

5.6 Maintenance

Before you maintain or shut down the pressure reducer you have to read



→ Safety advice

If you have not read the safety advices until now, read these important advices now and turn back to this page.

On normal accounts the pressure reducer is maintenance free. In periodical turns you have to:

- Check the function of the pressure reducer
- Check or clean the mesh (only Art. SD)
- Check the right outlet pressure
- Check the tightness off all the connection

In case of a defect of the pressure reducer make a contact to the supplier. The telephone number will be found on the back or these operation and installation manual.



If you determinate that there is a damage to the pressure reducer switch off the device/ machine/ plant! However before doing this, it is essential to refer to the

→ Safety advice.

5.5.1 Cleaning of the mesh (only Art. SD)



Cut off the medium flow on both sides of the pressure reducer and release the pressure in the pressure reducer.



Keep ready some fit tanks to catch up leaking liquids.



Before disassembling the pressure reducer you have to release the spring to prevent the fly around of the pieces . Heavy injuries of persons or damages of the pieces would be the result.



Turn the adjustment screw anti clockwise until the spring is totally released.



Loosen the bonnet with a fit spanner (Art. SD).



Take off the bonnet of pressure reducer and take it by side carefully.



Take off all the inner parts of the pressure reducer and take them by side carefully.




Now the mesh could be taken out of the body of the pressure reducer.

By mounting please consider,



- that the cam or peg will be placed exactly above the counter part at the body,
- that the inner parts will not be braced by the placement into the body

- the correct placement of the seals,
- that there will be no pollution on the seals.

 After mounting check the function of the pressure reducer.

 Check the tightness of all connections.




Fig.. 5.9 -pressure reducer, cleaning of the mesh(Art. SD220025). Option: manometer Art.M073xx

Index

6 Index

A		
AD leaflet A3 DIN 4753	13	
C		
Cleaning of the mesh	18	
Complaints	5	
Corresponding use	11	
D		
Date of manufacturing	10	
Device safety	9	
DIN 1988	13	
Disassembly	12	
F		
Fluidgroup	10	
Foreword	4	
G		
General advice	5	
H		
Heat absorbing paste	15, 16	
I		
Inlet pressure	17	
Inlet pressure	10	
Input pressure	17	
Installation in boiler systems	13	
Inward monitoring	5	
K		
Kvs- value	11	
M		
Maintenance	18	
Mounting	12	
Mounting diagram	13	
Mounting diagram with by-pass	13	
Mounting position	11	
Mounting position at liquid and gaseous media	11	
Mounting position medium steam	12	
Mounting with flanged connection	16	
Mounting with screw pipe connection	14	
Mounting with threaded connection	14	
Mounting with welded connection	15	
Multiple welding seam	16	
N		
Name-plate	10	
O		
Operation	17	
Outlet pressure	10, 17	
Outlet pressure - decrease	17	
Outlet pressure - increase	17	
P		
Personal protection	7	
R		
Regulation spring	17	
S		
Safety advice	7	
Safety advice for adjustment	8	
Safety advice for maintaining	8	
Safety advice for mounting	7	
Safety advice for repairing	8	
Safety advice for starting	8	
Serial	10	
Shock pressure loading	17	
Steam application	12	
Steam applications	17	
Strainer	12	
Symbols and their Signification	6	
T		
Temperature	10	
Testing pressure	10	
V		
Validity	5	
W		
Warranty	5	



Qualität von Anfang an.

(1) **Declaration in conformity**
(2) **as defined by Pressure-Equipment-Directive 97/23/EC**

(3) This declaration apply to the article groups with the nominal sizes:

Articles	Nominal size
Pressure Reducer	
DK	1/2" ... 2"
DK	DN15 ... DN50
DM	1/4" ... 1 1/2"
DM	DN10 ... DN50
SD	3/8" ... 2"

and all variations of these articles

(4) of the company **END-Armaturen GmbH & Co. KG**
D-32547 Bad Oeynhausen
Germany

(5) Herewith we declare that the above-mentioned articles in the conditions of our delivery are in conformity with the regulations of Article 3 Part 3 of the directive 97/23/EG. These products bear no CE mark, but are in line to the good engineering practice designed and manufactured.

(6) Applied harmonized standards, in particular:

DIN EN 12516:2005

Industriearmaturen - Gehäusefestigkeit

(7)





END-Armaturen GmbH & Co. KG
Oberbecksener Str. 78
32547 Bad Oeynhausen · Germany
Telefon: +49 (0)5731 - 7900-0
Telefax: +49 (0)5731 - 7900-199
<http://www.end.de> · post@end.de

Bad Oeynhausen, 14. Oktober 2011

Michael End
Quality Manager

Declaration without signature or company stamp shall not be valid. The declaration may be circulated only without alternation. Extracts or alternations are subject to approval by END-Armaturen GmbH & Co. KG.





Qualität von Anfang an.

END-Armaturen GmbH & Co. KG

Oberbecksener Str.78
D-32547 Bad Oeynhausen
Postfach (PLZ 32503) 100 341
Telefon +49 (0) 5731 / 7900-0
Telefax +49 (0) 5731 / 7900-199
Internet <http://www.end.de>
E-Mail post@end.de

Watergates GmbH & Co. KG

Oberbecksener Str.70
D-32547 Bad Oeynhausen
Postfach (PLZ 32503) 100 321
Telefon +49 (0) 5731 / 7900-0
Telefax +49 (0) 5731 / 7900-199
Internet <http://www.watergates.de>
E-Mail post@watergates.de

ISO 9001
97/23/EG
BUREAU VERITAS
Certification



N° INT80209DE