


Installation, Maintenance, & Repair

Series 919 and LF919

Reduced Pressure Zone Assemblies

Sizes: 1/4" – 2" (8 – 50mm)



919QT

WARNING

You are required to thoroughly read all installation instructions and product safety information before beginning the installation of this product. **FAILURE TO COMPLY WITH PROPER INSTALLATION AND MAINTENANCE INSTRUCTIONS COULD RESULT IN PRODUCT FAILURE WHICH CAN CAUSE PROPERTY DAMAGE, PERSONAL INJURY AND/OR DEATH.** Watts is not responsible for damages resulting from improper installation and/or maintenance.

Local building or plumbing codes may require modifications to the information provided. You are required to consult the local building and plumbing codes prior to installation. If this information is not consistent with local building or plumbing codes, the local codes should be followed.

Need for Periodic Inspection/Maintenance: This product must be tested periodically in compliance with local codes, but at least once per year or more as service conditions warrant. Corrosive water conditions, and/or unauthorized adjustments or repair could render the product ineffective for the service intended. Regular checking and cleaning of the product's internal components helps assure maximum life and proper product function.

NOTE: For Australia and New Zealand, line strainers should be installed between the upstream shutoff valve and the inlet of the backflow preventer.

It is important that this assembly be tested periodically in compliance with local codes, but at least once per year or more as service conditions warrant. If installed on a fire sprinkler system, all mechanical checks, such as alarm checks and backflow preventers, should be flow tested and inspected internally in accordance with NFPA 13 and NFPA 25.

Testing

For field testing procedure, send for IS-TK-DL, IS-TK-7, IS-TK-9A, IS-TK-99E AND IS-TK-99D.

For other repair kits and service parts, send for PL-RP-BPD.

For technical assistance, contact your local Watts representative.

Installation Instructions


Series 919 and LF919

1/4" – 2" (8 – 50mm)


Reduced Pressure Zone Assemblies Indoor Installation

For indoor installations, make sure the Series 919 and LF919 is easily accessible to facilitate testing and servicing. Do not install in concealed locations. If the location of the Series 919 and LF919 is parallel and close to the wall, make sure the test cocks are easily accessible, and the drain line can adequately drain if required. An air gap and drain line (see literature ES-AG/EL/TC) are piped from the relief valve connection as shown, allowing evidence of discharge to be clearly visible and preventing the occurrence of water damage.

Indoor Installation



Outdoor Installation



Now available, WattsBox Insulated Enclosures,
for more information, send for literature ES-WB.

Outdoor, Above Ground Installation


For outdoor installations, it is recommended that you install the Series 919 and LF919 where there are no freezing conditions and above ground whenever possible.

You must install the Series 919 and LF919 in an accessible location to facilitate testing and servicing. The installation must also allow for adequate drainage from the air gap and the discharge line if needed.

WARNING:

1. Do not allow the drain line to empty directly into a drainage ditch, sewer system, or sump.
2. Do not install the Series 919 and LF919 in any location where any part of the unit could become submerged in standing water.

Parallel Installation



Parallel Installation

For parallel installations, you can install two or more small sized Series 919's and LF919's (when approved) to serve a large supply pipe main. You can use this type of installation in an application where increased capacity beyond that provided by a single valve is required. Additionally, this type of installation permits testing and/or servicing of a single valve without shutting down the complete line.

The number of Series 919 and LF919 units installed in parallel should be determined by the engineer's judgement, based on the operating conditions of a specific application.

NOTE: The total capacity of all the units installed in the application should equal or exceed that required by the system.

Annual inspection of all water system safety and control valves is required and necessary. Regular inspection, testing and cleaning assures maximum life and proper product function.

Installation Instructions

Series 919 and LF919

1/4" – 2" (8 – 50mm)

- Shutoff Valves: If you remove the shutoff valves from the Series 919 and LF919, reassemble the shutoff valve with the test cock mounted on the inlet side of the unit.
- Always install the Series 919 and LF919 in an accessible location to facilitate testing and servicing (See Page 2). ***Check the state and local codes to ensure that you install the backflow preventer in compliance with those codes, such as the proper height above the ground.**
- It is recommended that you install a strainer ahead of the Series 919 assemblies to protect the internal components from unnecessary fouling.

CAUTION:

Do not install a Series 919 and LF919 with a strainer in rarely used water lines, such as a fire sprinkler system which is only used during emergencies.

Start Up: Close the downstream shutoff. Open the upstream slowly and fill the valve. When the valve is filled, open the downstream shutoff slowly, and fill the water supply system. This is necessary to avoid water hammer and/or shock damage.

- Vent the air gap and drain line from the relief valve in accordance with code requirements. Terminate discharge approximately 12" (300mm) above the ground or through an air gap piped to a floor drain.

WARNING:

Do not allow the drain line to empty directly into a drainage ditch, sewer system, or sump.

NOTE: Relief Valve Discharge Rates

The Series 919 and LF919 air gap and drain line terminating above a floor drain can accommodate any moderate discharge or nuisance spitting through the relief valve. However, to prevent water damage in the case of a catastrophic failure, you may need to design the floor drain size to accommodate the increased discharge. Refer to Figure 1 for maximum relief valve discharge rates, size, and capacity of typical floor drains.

NOTE: DO NOT reduce the size of the drain line from the air gap fitting. The drain line must remain at full line size.

- After initial installation of the Series 919 and LF919, a discharge from the relief valve may occur due to dirt and pipe compounds. This may be due to inadequate initial flushing of the pipe lines. If flushing the valve does not clear the unit, remove the first check valve and clean thoroughly, using the procedures in "Servicing First & Second Check Valves" on page 6.

NOTE: Periodic relief valve discharge may occur on dead end service applications, such as boiler feed lines or cooling tower makeup lines. This may be due to fluctuating supply pressure during a static or no flow condition. To avoid this discharge, install a spring-loaded, rubber seated check valve ahead of the backflow assembly.

- It is recommended that you not place the Series 919 and LF919 in a pit or at a depth below the ground level, unless absolutely necessary. If an installation requires below ground level installation, a modified pit installation is recommended, as well as the approval of local codes. In such cases, provision should be made to always vent the drain line above the flood level. In the case of a pit drain, ensure an adequate air gap exists between the bottom of the drain line and the bottom of the pit.

- It is recommended that periodic inspection of the Series 919 and LF919 be done to check for any discharge from the relief valve. This discharge is a visual indication that the valve needs cleaning or repair. In addition, it is recommended that periodic testing of the valve be done in compliance with local codes to ensure its proper operation.




The relief vent discharges water during no-flow periods when:

- (1) the first check valve is fouled; or
- (2) the inlet pressure to the check valve drops sufficiently due to upstream pressure fluctuations. This affects the required operating differential between the inlet pressure and the reduced pressure zone; or
- (3) the second check is fouled during emergency backflow or resulting from a water hammer condition.

For troubleshooting guide send for literature S-TSG.

NOTE: When installing the Series 919 and LF919 on fire prevention systems, special considerations are required.

Fire Protection System Installations: The National Fire Protection Agency (NFPA) Guidelines require a confirming flow test be conducted by a certified tester whenever a "main line" valve is installed, such as a shutoff valve or a backflow preventer.



Typical Flow Rates as sized by floor drain manufacturers:

2"	55 GPM	5"	350 GPM
3"	112 GPM	6"	450 GPM
4"	170 GPM	8"	760 GPM

Figure 1

Servicing the Relief Valve

Series 919 and LF919

1/4" – 2" (8 – 50mm)

NOTES: 1. No special tools are required to service the Series 919 and LF919 1/4" - 2".

2. Before servicing, make sure the water is turned off or shutoff valves are closed.

The following procedures provide information for replacing the diaphragm, the relief valve disc, and the relief valve seat. It is recommended that you visually inspect these parts to determine if a replacement or cleaning is required.

Disassembling the Relief Valve

1. Remove the relief valve cover bolts while holding the cover down.
2. Turn the cover counterclockwise for 1/4 turn, and lift it straight off while still applying pressure to the cover with your hand.

WARNING:

Make sure you apply pressure to the cover as you lift it straight off. Due to the release of pressure when removing the cover, the relief valve spring may eject quickly.

3. Remove the relief valve assembly (includes cover O-ring, stem and diaphragm assembly).
4. Remove the relief valve spring.
5. Remove the pressed in relief valve seat and seat O-ring.

Replacing the Diaphragm

6. Using a wrench, loosen the diaphragm assembly by turning the hex bolt counterclockwise.
7. Remove the diaphragm and replace with a new diaphragm if required, or clean the existing diaphragm. The molded step of the diaphragm should point down towards the relief valve stem.
8. Using a wrench, reassemble the diaphragm assembly by turning the hex bolt clockwise to tighten.

Replacing the Relief Valve Disc and Seat

9. Using a phillips screwdriver, remove the screw in the relief valve disc and replace the disc if required, or clean the existing disc.
10. Place the screw back into the relief valve disc and tighten.
11. Replace the relief valve seat with a new seat if required, or clean the existing seat.


Reassembling the Relief Valve

12. Place the relief valve seat back into the chamber bore.
13. Slide the diaphragm assembly into the relief valve seat.
14. Place the spring on to the diaphragm assembly.
15. Place the cover O-ring on the diaphragm assembly.
16. Line up the grooves on the relief valve cover with the grooves in the relief valve body, and turn the cover clockwise 1/4 turn to seat the cover.
17. Using a wrench, place the bolts back into the cover and tighten.

CAUTION:

If the cover does not lie flat against the relief valve body, the diaphragm assembly is not installed properly and damage can result. Remove the bolts and cover, realign the diaphragm assembly, and place the cover back on the relief valve body.


18. Open the shutoff valves.



Servicing the Relief Valve

Series 919 and LF919

1/4" – 2" (8 – 50mm)



Repair Kits

1/4" – 2" (8 – 50mm)

When ordering, specify Ordering Code Number, Kit Number and Valve Size.

ORDERING CODE	KIT NO.	in.	SIZE	mm
---------------	---------	-----	------	----

Total Repair Kits:

LEAD FREE	0888167	RK 919-T	1/4 – 1/2	8 – 15
	0888168	RK 919-T	3/4	20
	0888169	RK 919-T	1	25
	0888170	RK 919-T	1 1/4 – 1 1/2	32 – 40
	0888171	RK 919-T	2	50

Kit consists of: Relief Valve Repair Kit, First Check Repair Kit, Second Check Repair Kit

Total Relief Valve Kits:

LEAD FREE	0888130	RK 919 VT	1/4 – 1/2	8 – 15
	0888131	RK 919 VT	3/4 – 1	20 – 25
	0888132	RK 919 VT	1 1/4 – 2	32 – 50

Kit consists of: Relief Valve Assembly, RV Spring, and RV Cover O-ring

Relief Valve Rubber Parts Kits:

LEAD FREE	0888135	RK 919 RV	1/4 – 1/2	8 – 15
	0888136	RK 919 RV	3/4 – 1	20 – 25
	0888137	RK 919 RV	1 1/4 – 2	32 – 50

Kit consists of: Relief Valve Disc, RV Diaphragm, RV Seat O-ring and Cover O-ring

ORDERING CODE	KIT NO.	in.	SIZE	mm
---------------	---------	-----	------	----

Relief Valve Seat Kits:

LEAD FREE	0888150	RK 919 SV	1/4 – 1/2	8 – 15
	0888151	RK 919 SV	3/4 – 1	20 – 25
	0888153	RK 919 SV	1 1/4 – 2	32 – 50

Kit consists of: Relief Valve Seat, RV Seat O-ring and RV Cover O-ring

Relief Valve Cover Kits:

LEAD FREE	0888155	RK 919 VC	1/4 – 1/2	8 – 15
	0888156	RK 919 VC	3/4 – 1	20 – 25
	0888158	RK 919 VC	1 1/4 – 2	32 – 50
	0794142	LFRK 919 VC	3/4 – 1	20 – 25
	0794143	LFRK 919 VC	1 1/4 – 2	32 – 50

Kit consists of: Relief Valve Cover and Cover O-ring

Air Gaps

0881575	919 AGA	1/4 – 1/2	8 – 15
0881576	919 AGC	3/4 – 1	20 – 25
0881577	919 AGF	1 1/4 – 2	32 – 50

*The wetted surface of this product contacted by consumable water contains less than 0.25% of lead by weight.

Servicing First & Second Check Valves

Series 919 and LF919

1/4" – 2" (8 – 50mm)

NOTES: 1. No special tools are required to service the Series 919 and LF919 1/4" – 2" (8 – 50mm).

2. Before servicing, make sure the water is turned off or shutoff valves are closed.

1. Close shutoff valves up and downstream of the valve.
2. Using an appropriate sized wrench, loosen the check valve cover. Unscrew the check valve cover and lift it off.
3. Remove the spring.
4. Lift out the disc holder assembly from the body of the valve.
5. To reverse the seat disc, unscrew the disc screw and disassemble the disc washer and disc rubber from the disc holder assembly. Reverse the disc rubber so the opposite face is showing.
6. Assemble the disc screw through the disc washer and disc rubber, and screw it into the disc holder.
7. To replace the seat module, pull the seat module out of the body by gripping at the reinforcement ring. Replace the seat module with the new seat by placing it into the body seat bore.


NOTE: When you tighten the cover in Step 12, the cover will engage the seat module properly.

8. Insert the disc holder assembly back into the seat module.
9. Replace the spring ensuring that it seats properly on the disc holder.

WARNING:

The first check valve has a heavy weight spring. The second check valve has a lighter weight spring. When reassembling the check valves, make sure you install the correct spring into the correct check valve.


10. Place the cover onto the spring with the internal guide on the cover positioned inside the end coil.
11. Screw the cover onto the valve body.
12. Tighten the cover using the appropriate sized wrench.
13. Service the second check valve using Steps 2 through 12.
14. Slowly open shutoff valves.



Servicing First & Second Check Valves

Series 919 and LF919

1/4" – 2" (8 – 50mm)



Check Valve Kits

1/4" – 2" (8 – 50mm)

When ordering, specify Ordering Code Number, Kit Number and Valve Size.

ORDERING CODE	KIT NO.	in.	SIZE	mm
---------------	---------	-----	------	----

1st Check Kits:

LEAD FREE	0888110	RK 919 CK1	1/4 – 1/2	8 – 15
	0888111	RK 919 CK1	3/4	20
	0888112	RK 919 CK1	1	25
	0888113	RK 919 CK1	1 1/4 – 1 1/2	32 – 40
	0888114	RK 919 CK1	2	50

Kit consists of: Check Assembly, Spring and Cover O-ring

2nd Check Kits:

LEAD FREE	0888115	RK 919 CK2	1/4 – 1/2	8 – 15
	0888116	RK 919 CK2	3/4	20
	0888117	RK 919 CK2	1	25
	0888118	RK 919 CK2	1 1/4 – 1 1/2	32 – 40
	0888119	RK 919 CK2	2	50

Kit consists of: Check Assembly, Spring and Cover O-ring

1st or 2nd Check Rubber Parts Kits:

LEAD FREE	0888120	RK 919 RC4	1/4 – 1/2	8 – 15
	0888121	RK 919 RC4	3/4	20
	0888122	RK 919 RC4	1	25
	0888123	RK 919 RC4	1 1/4 – 1 1/2	32 – 40
	0888124	RK 919 RC4	2	50

Kit consists of: Disc, Seat O-ring and Cover O-ring

ORDERING CODE	KIT NO.	in.	SIZE	mm
---------------	---------	-----	------	----

Check Seat Kits:

LEAD FREE	0888125	RK 919 S	1/4 – 1/2	8 – 15
	0888126	RK 919 S	3/4	20
	0888127	RK 919 S	1	25
	0888128	RK 919 S	1 1/4 – 1 1/2	32 – 40
	0888129	RK 919 S	2	50

Kit consists of: Seat, Seat O-ring and Cover O-ring

Complete Valve Rubber Parts Kits:

LEAD FREE	0888140	RK 919 RT	1/4 – 1/2	8 – 15
	0888141	RK 919 RT	3/4	20
	0888142	RK 919 RT	1	25
	0888143	RK 919 RT	1 1/4 – 1 1/2	32 – 40
	0888144	RK 919 RT	2	50

Kit consists of: 2 Check Discs, 2 Check Seat O-rings, 1 RV Disc

Check Cover Kits:

LEAD FREE	0888145	RK 919 C	1/4 – 1/2	8 – 15
	0888146	RK 919 C	3/4	20
	0888147	RK 919 C	1	25
	0888148	RK 919 C	1 1/4 – 1 1/2	32 – 40
	0888149	RK 919 C	2	50
	0794144	LFRK 919 C	1/4 – 1/2	8 – 15
LEAD FREE	0794145	LFRK 919 C	3/4	20
	0794146	LFRK 919 C	1	25
	0794147	LFRK 919 C	1 1/4 – 1 1/2	32 – 40
	0794148	LFRK 919 C	2	50

Kit consists of: Cover and Cover O-ring

Note: For 1/2" and 3/4" 919R10 models use 1" repair kits.

*The wetted surface of this product contacted by consumable water contains less than 0.25% of lead by weight.

Troubleshooting Guide

Series 919 and LF919

Symptom	Cause	Solution
1. Check valve fails to hold 1.0 PSID minimum	a. Debris on check disc sealing surface b. Leaking gate valve c. Damaged seat disc or seat o-ring d. Damaged guide holding check open e. Weak or broken spring	Disassemble and clean Disassemble and clean or repair Disassemble and replace Disassemble clean or replace Disassemble and replace spring
2. Chatter during flow conditions	a. Worn, damaged or defective guide	Disassemble and repair or replace guide
3. Low flows passing through mainline valve	a. Mainline check fouled b. Meter strainer plugged c. Damaged mainline seat disc or seat d. Broken mainline spring	Disassemble and clean Disassemble and clean Disassemble and replace Disassemble and replace

For additional cross-connection control information, send for F-50 brochure.

CALIFORNIA PROPOSITION 65 WARNING

WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. (California law requires this warning to be given to customers in the State of California.)

For more information: www.watts.com/prop65

Limited Warranty: Watts Regulator Co. (the "Company") warrants each product to be free from defects in material and workmanship under normal usage for a period of one year from the date of original shipment. In the event of such defects within the warranty period, the Company will, at its option, replace or recondition the product without charge.

THE WARRANTY SET FORTH HEREIN IS GIVEN EXPRESSLY AND IS THE ONLY WARRANTY GIVEN BY THE COMPANY WITH RESPECT TO THE PRODUCT. THE COMPANY MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED. THE COMPANY HEREBY SPECIFICALLY DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

The remedy described in the first paragraph of this warranty shall constitute the sole and exclusive remedy for breach of warranty, and the Company shall not be responsible for any incidental, special or consequential damages, including without limitation, lost profits or the cost of repairing or replacing other property which is damaged if this product does not work properly, other costs resulting from labor charges, delays, vandalism, negligence, fouling caused by foreign material, damage from adverse water conditions, chemical, or any other circumstances over which the Company has no control. This warranty shall be invalidated by any abuse, misuse, misapplication, improper installation or improper maintenance or alteration of the product.

Some States do not allow limitations on how long an implied warranty lasts, and some States do not allow the exclusion or limitation of incidental or consequential damages. Therefore the above limitations may not apply to you. This Limited Warranty gives you specific legal rights, and you may have other rights that vary from State to State. You should consult applicable state laws to determine your rights. **SO FAR AS IS CONSISTENT WITH APPLICABLE STATE LAW, ANY IMPLIED WARRANTIES THAT MAY NOT BE DISCLAIMED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO ONE YEAR FROM THE DATE OF ORIGINAL SHIPMENT.**



A Watts Water Technologies Company



USA: Tel: (978) 688-1811 • Fax: (978) 794-1848 • www.watts.com

Canada: Tel: (905) 332-4090 • Fax: (905) 332-7068 • www.wattscanada.ca