

Dozzfly

Dozzfly

Manual

Thank you for purchasing our product, please read this instructions carefully before using it.

I.Warning

1. Do not disassemble or repair this unit by yourself.
2. Do not use or store this unit in environment of high temperature, high humidity, high voltage or dirty place.
3. Do not drop off or hit it against hard surface.
4. Do not use cleaning liquid or alcohol to clean this unit in case of damage.
5. Unplug the power cable if don't use the unit for a long time.

II.How to use

1. Connect the power cable to the unit, press down the switch to turn it on.
2. Connect the effect pedal to your guitars, amps, adjust the knob to get the effect you want.
3. Press down the switch to turn it off.

III.Specifications

	Input Impedance	Out Impedance	Running Current	Power	Speed Range	Delay Time
Vintage Overdrive	500K Ω	10K Ω	7mA	DC 9V	/	
Ultimate Drive	1M Ω	1K Ω	6mA	DC 9V	/	
Crunch Distortion	1M Ω	1K Ω	10mA	DC 9V	/	
Us Dream	1M Ω	1K Ω	10mA	DC 9V	/	
Classic Chorus	500K Ω	10K Ω	9mA	DC 9V	/	
Vintage Phase	500K Ω	10K Ω	13mA	DC 9V	0.2Hz-16Hz	
Analog Chorus	1M Ω	1K Ω	12mA	DC 9V	/	
Digital Delay	500K Ω	10K Ω	26mA	DC 9V	/	20ms-600ms
Tremolo	1M Ω	1K Ω	7mA	DC 9V	1Hz-25Hz	
Analog Delay	1M Ω	1K Ω	13mA	DC 9V	/	