

You now can search signal in dtc-signal tab

Example:

ALL CONFIGURATION DATA

| | |
|--------------------------|---------------------|
| DTCInfoFVCMHSC2 | All signal |
| LDWLKAAudReqHSC2 | Precondition signal |
| LDWLKAAudReqHSC2 | All speed signal |
| RNonDrvnWhlRotlDircnHSC2 | |

Choose the signal in configuration data tab and copy it

Paste it in signal combobox in dtc-signal tab and press enter

Enable trigger DTC mode Done

| | |
|---------------|-------------------|
| Message | DIAG_DTCInfo_FVCM |
| Signal | LDWLKAAudReqHSC2 |
| Raw value | |
| Enable string | |

If this signal has been configured before, the rest data will be automatically filled in

Enable trigger DTC mode Done

| | |
|---------------|------------------|
| Message | FVCM_HSC2_FrP02 |
| Signal | LDWLKAAudReqHSC2 |
| Raw value | Level 1 |
| Enable string | 2e02023f |