

Introduction:

The purpose of this lab is to introduce you to the NXP S32K Cortex®-M4 processor

using the ARM® Keil® MDK toolkit featuring the IDE µVision®. We will demonstrate all debugging features available on this processor. At the end of this tutorial, you will be able to confidently work with these processors and Keil MDK.

See www.keil.com/NXP and www.keil.com/S32 **New** Getting Started MDK 5: www.keil.com/gsg.

Keil MDK supports and has examples for most NXP Arm processors. Check the Keil Device Database® on www.keil.com/dd2. This list is also provided by the µVision Pack Installer utility.

NXP i.MX processors are supported by Arm DS-MDK™. www.keil.com/ds-mdk.

Keil MDK-Lite™ is a free evaluation version that limits code size to 32 Kbytes. Nearly all Keil examples will compile within this 32K limit. The addition of a valid license number will turn it into one of the commercial versions.

RTX RTOS: All variants of MDK contain the full version of RTX with Source Code. RTX has a BSD or Apache 2.0 license with source code. www.keil.com/RTX and https://github.com/ARM-software/CMSIS_5 FreeRTOS is now supported.


Why Use Keil MDK ?

MDK provides these features particularly suited for NXP Cortex-M users:

1. µVision IDE with Integrated Debugger, Flash programmer and the ARM® Compiler toolchain. MDK is turn-key "out-of-the-box". Examples and board support included.
2. Arm Compiler 5 and Arm Compiler 6 (LLVM) are included. For GCC: <https://developer.arm.com/open-source/gnu-toolchain/gnu-rm/downloads>
3. **Compiler Safety Certification Kit:** www.keil.com/safety/
4. TÜV certified. SIL3 (IEC 61508) and ASILD (ISO 26262). AC5 and AC6.
5. Dynamic Syntax checking on C/C++ source lines.
6. MISRA C/C++ support using PC-Lint. www.gimpel.com
7. **Keil Middleware:** Network, USB, Flash File and Graphics for some NXP processors.
8. **NEW! Event Recorder for Keil Middleware, RTX and User programs. Page 17.**
9. CoreSight™ Serial Wire Viewer (SWV). ETM instruction trace capability on appropriately equipped NXP processors. Provides Instruction Debugging, Code Coverage and Performance Analysis. For the S32K148 ETM lab see: www.keil.com/apnotes/docs/apnt_305.asp
10. Adapters: OpenSDA (CMSIS-DAP or P&E mode), ULINK™2, ULINK-ME, ULINKplus, ULINKpro and J-Link.
11. Affordable perpetual and term licensing with support. Contact Keil sales for pricing options. Inside-Sales@arm.com
12. Keil Technical Support is included for one year and is renewable. This helps you get your project completed faster.
13. Micrium µC/Probe compatible. www.micrium.com/ucprobe FreeRTOS is supported. NXP SDK included.

This document includes details on these features plus more:

1. Serial Wire Viewer (SWV) data trace. Includes Exceptions (interrupts), Data writes, graphical Logic Analyzer.
2. Real-time Read and Write to memory locations for the Watch, Memory and Peripheral windows. These are non-intrusive to your program. No CPU cycles are stolen. No instrumentation code is added to your source files.
3. Six Hardware Breakpoints (can be set/unset on-the-fly) and two Watchpoints (also known as Access Breaks).
4. RTX and RTX Tasks window: a kernel awareness program for RTX that updates while your program is running.
5. **NEW!** µVision Event Recorder. You can use this in your own programs too.
6. printf using SWV ITM or Event Recorder (EVR). No UART is required.
7. A DSP example program using Arm CMSIS-DSP libraries.
8. An extensive list of available document resources.



General Information:

1. NXP Evaluation Boards & Keil Evaluation Software:	3
2. MDK 5 Keil Software Information:	3
3. Debug Adapters Supported:	3
4. CoreSight Definitions:	4

Keil Software and Software Packs:

5. Keil MDK Software Download and Installation:	5
6. μ Vision Software Pack and RTX5_Blinky example Download and Install Process:	5
7. Other features of Software Packs:	6

Using Debug Adapters:

8. Configuring the P&E OpenSDA Debug Adapter:	7
9. Configuring the CMSIS-DAP OpenSDA Adapter:	8
10. Testing the OpenSDA CMSIS-DAP Connection:	8
11. Configuring External Debug Adapters: Keil ULINK2/ME, ULINK <i>pro</i> , J-Link:	9

Blinky Example and Debugging Features:

12. <i>Blinky</i> example using the S32K144 EVB:	10
13. Hardware Breakpoints and Single Stepping:	11
14. Call Stack & Locals window:	12
15. Watch and Memory windows and how to use them:	13
16. Peripheral System Viewer (SV):	14
17. Watchpoints: Conditional Breakpoints:	15
18. RTX System and Threads Viewer:	16
19. RTX Event Viewer:	17
20. NEW! Event Recorder:	18

Serial Wire Viewer (SWV):

21. Serial Wire Viewer (SWV) Configuration with ULINK2, ULINK-ME and J-Link:	19
22. SWV ULINK <i>pro</i> Configuration:	20
23. Displaying Exceptions (including Interrupts) with SWV Event Viewer:	21
24. Using μ Vision Logic Analyzer (LA) Graphical variable display:	22
25. printf using ITM:	23

DSP:

26. DSP Sine Example:	24
-----------------------	----

Other Useful Information:

27. Document Resources:	27
28. Keil Products and contact information:	28

1) NXP Evaluation Boards & Keil Evaluation Software:

Keil MDK provides board support for many NXP Cortex-M processors. For the i.MX series see www.keil.com/ds5-mdk

On the second last page of this document is an extensive list of resources that will help you successfully create your projects. This list includes application notes, books and labs and tutorials for other NXP boards.

We recommend you obtain the latest Getting Started Guide for MDK5: It is available free on www.keil.com/gsg/.

Arm forums: <https://developer.arm.com>

Keil Forums: www.keil.com/forum/

2) MDK 5 Keil Software Information: *This document uses MDK 5.24 or later.*

MDK 5 Core is the heart of the MDK toolchain. This will be in the form of MDK Lite which is the evaluation version. The addition of a Keil license will turn it into one of the commercial versions available. Contact Keil Sales for more information.

Device and board support are distributed via Software Packs. These Packs are downloaded from the web with the "Pack Installer", the version(s) selected with "Select Software Packs" and your project configured with "Run Time Environment" (RTE). These utilities are components of μ Vision.

A Software Pack is an ordinary .zip file with the extension changed to .pack. It contains various header, Flash programming and example files and more. Contents of a Pack is described by a .pdsc file in XML format.

See www.keil.com/dd2/pack for the current list of available Software Packs. More packs are being added.



Example Project Files: This document uses the RTX5_Blinky example project contained in the S32K Software Pack.

3) Debug Adapters Supported:

These are listed below with a brief description. Configuration instructions start on page 7.

1. **OpenSDA:** OpenSDA is an on-board debug adapter. NXP OpenSDA has a P&E and a CMSIS-DAP mode depending on the firmware loaded into the OpenSDA processor U8. You do not need an external debugger such as a ULINK2 to do this lab. If you want to use Serial Wire Viewer (SWV), you need any ULINK or a J-Link. You can add CMSIS-DAP to a custom board. See https://github.com/ARM-software/CMSIS_5.
2. **CMSIS-DAP:** An extra processor on your board becomes a debug adapter compliant to CMSIS-DAP. The S32K and many other NXP boards incorporate CMSIS-DAP.
3. **ULINK2 and ULINK-ME:** ULINK-ME is only offered as part of certain evaluation board packages. ULINK2 can be purchased separately. These are electrically the same and both support Serial Wire Viewer (SWV), Run-time memory reads and writes for the Watch and Memory windows and hardware breakpoint set/unset on-the-fly.
4. **ULINKpro:** ULINKpro supports all SWV features and adds ETM Instruction Trace. ETM records all executed instructions. ETM provides Code Coverage, Execution Profiling and Performance Analysis features. ULINKpro also provides the fastest Flash programming times. Not all S32K devices have ETM. Consult your datasheet.
5. **NEW ! ULINKplus:** High SWV performance plus Power Measurement. See www.keil.com/ulink/ulinkplus/ for complete details.
6. **Segger J-Link:** J-Link Version 6 (black) or later supports Serial Wire Viewer. SWV data reads and writes are not currently supported with a J-Link.

Debug Connections: An external debug adapter must be connected to the J14 SWD connector and shown in these pictures. This is a 10 pin CoreSight standard connector. A special cable is provided with a ULINK2, ULINK-ME and ULINKpro. Contact Segger for a special adapter board for the J-Link series. www.segger.com




4) CoreSight Definitions: It is useful to have a basic understanding of these terms:

Cortex-M0 and Cortex-M0+ may have only features 2) and 4) plus 11), 12) and 13) implemented. Cortex-M3, Cortex-M4 and Cortex-M7 can have all features listed implemented. MTB is normally found on Cortex-M0+. It is possible some processors have all features except ETM Instruction trace and the trace port. Consult your specific datasheet.

1. **JTAG:** Provides access to the CoreSight debugging module located on the Cortex processor. It uses 4 to 5 pins.
2. **SWD:** Serial Wire Debug is a two pin alternative to JTAG and has about the same capabilities except Boundary Scan is not possible. SWD is referenced as SW in the μ Vision Cortex-M Target Driver Setup. The SWJ box must be selected in ULINK2/ME or ULINK pro . Serial Wire Viewer (SWV) must use SWD because the JTAG signal TDO shares the same pin as SWO. The SWV data normally comes out the SWO pin or Trace Port.
3. JTAG and SWD are functionally equivalent. The signals and protocols are not directly compatible.
4. **DAP:** Debug Access Port. This is a component of the Arm CoreSight debugging module that is accessed via the JTAG or SWD port. One of the features of the DAP are the memory read and write accesses which provide on-the-fly memory accesses without the need for processor core intervention. μ Vision uses the DAP to update Memory, Watch, Peripheral and RTOS kernel awareness windows while the processor is running. You can also modify variable values on the fly. No CPU cycles are used, the program can be running and no code stubs are needed. You do not need to configure or activate DAP. μ Vision configures DAP when you select a function that uses it. Do not confuse this with CMSIS_DAP which is an Arm on-board debug adapter standard.
5. **SWV:** Serial Wire Viewer: A trace capability providing display of reads, writes, exceptions, PC Samples and printf.
6. **SWO:** Serial Wire Output: SWV frames usually come out this one pin output. It shares the JTAG signal TDO.
7. **Trace Port:** A 4 bit port that ULINK pro uses to collect ETM frames and optionally SWV (rather than SWO pin).
8. **ITM:** Instrumentation Trace Macrocell: As used by μ Vision, ITM is thirty-two 32 bit memory addresses (Port 0 through 31) that when written to, will be output on either the SWO or Trace Port. This is useful for printf type operations. μ Vision uses Port 0 for printf and Port 31 for the RTOS Event Viewer. The data can be saved to a file.
9. **ETM:** Embedded Trace Macrocell: Displays all the executed instructions. The ULINK pro provides ETM. ETM requires a special 20 pin CoreSight connector. ETM also provides Code Coverage and Performance Analysis. ETM is output on the Trace Port or accessible in the ETB (ETB has no Code Coverage or Performance Analysis).
10. **ETB:** Embedded Trace Buffer: A small amount of internal RAM used as an ETM trace buffer. This trace does not need a specialized debug adapter such as a ULINK pro . ETB runs as fast as the processor and is especially useful for very fast Cortex-A processors. Not all processors have ETB. See your specific datasheet.
11. **MTB:** Micro Trace Buffer. A portion of the device internal user RAM is used for an instruction trace buffer. Only on Cortex-M0+ processors. Cortex-M3/M4 and Cortex-M7 processors provide ETM trace instead.
12. **Hardware Breakpoints:** The Cortex-M0+ has 2 breakpoints. The Cortex-M3, M4 and M7 usually have 6. These can be set/unset on-the-fly without stopping the processor. They are no skid: they do not execute the instruction they are set on when a match occurs. The CPU is halted before the instruction is executed.
13. **Watchpoints:** Both the Cortex-M0, M0+, Cortex-M3, Cortex-M4 and Cortex-M7 can have 2 Watchpoints. These are conditional breakpoints. They stop the program when a specified value is read and/or written to a specified address or variable. There also referred to as Access Breaks in Keil documentation.

Read-Only Source Files:

Some source files in the Project window will have a yellow key on them:  This means they are read-only. This is to help unintentional changes to these files. This can cause difficult to solve problems. These files normally need no modification. μ Vision icon meanings are found here: www.keil.com/support/man/docs/uv4/uv4_ca_filegrp_att.htm

If you need to modify one, you can use Windows Explorer to modify its permission.

1. In the Projects window, double click on the file to open it in the Sources window.
2. Right click on its source tab and select Open Containing folder.
3. Explorer will open with the file selected.
4. Right click on the file and select Properties.
5. Unselect Read-only and click OK. You are now able to change the file in the μ Vision editor.
6. It is a good idea to make the file read-only when you are finished modifications.

5) Keil MDK Software Download and Installation:



1. Download MDK 5.24 Lite or later from the Keil website. www.keil.com/mdk5/install
2. Install MDK into the default folder. You can install into any folder, but this lab uses the default C:\Keil_v5
3. We recommend you use the default folders for this tutorial. We will use C:\00MDK\ for the examples.
4. If you install MDK into a different folder, you will have to adjust for the folder location differences.
5. You do not need a debug adapter: just the S32K board, a USB cable and MDK installed on your PC.
6. For the exercises using SWV, you need a Keil ULINK2, ULINK-ME, ULINK_{plus}, ULINK_{pro} or a J-Link.
7. You do not need a Keil MDK license for this tutorial. All examples will compile within the 32 K limit.


Download MDK-Core Version 5

6) µVision Software Pack Download and Install Process:



A Software Pack contain components such as header, Flash programming, documents and other files used in a project.

1) Start µVision and open Pack Installer:

1. Connect your computer to the internet. This is needed to download the Software Packs. Start µVision:
2. Open the Pack Installer by clicking on its icon:  A Pack Installer Welcome screen will open. Read and close it.
3. This window opens up: Select the Devices tab:
4. Note “ONLINE” is displayed at the bottom right. If “OFFLINE” is displayed, connect to the Internet before continuing.
5. If there are no entries shown because you were not connected to the Internet when Pack Installer opened, select Packs/Check for Updates or  to refresh once you have connected to the Internet.






2) Install The S32K Software Pack:

1. In the Devices tab, select NXP and then S32K Series as shown above: The devices supported are displayed.
2. Select Keil::S32_SDK_DFP and click Install. This Pack will download and install into MDK. This download can take several minutes. Both S32K-144 and S32K-148 processors are contained in this pack.
3. Its status is indicated by the “Up to date” icon: 
4. Update means there is an updated Software Pack available for download. 


TIP: The left hand pane filters the selections displayed on the right pane. You can start with either Devices or Boards.

3) Install the RTX5_Blinky Example:

1. Select the Boards tab. Select S32K.
2. Select the Examples tab:
3. Opposite CMSIS-RTOS2 Blinky (S32K144-EVB): select Copy: 
4. The Copy Example window opens up: Select Use Pack Folder Structure. Unselect Launch µVision.
5. Type in C:\00MDK\. Click OK to copy the RTX5_Blinky project.
6. The RTX5_Blinky example will now copy to C:\00MDK\addon_mdk\Boards\NXP\S32K144-EVB\




TIP: The default folder for copied examples the first time you install MDK is C:\Users\<user>\Documents. For simplicity, we will use the default folder of C:\00MDK\ in this tutorial. You can use any folder you prefer.


7. Close the Pack Installer. You can open it any time by clicking on its icon. 


7) Other features of Software Packs:

Select Software Pack version:


This µVision utility provides the ability to choose among the various software pack versions installed in your computer.


1. Open the Select Software Pack by clicking on its icon: 
2. This window opens up. Note **Use latest versions ...** is selected. The latest version of the Pack will be used.
3. Unselect this setting and the window changes to allow various versions of Packs to be selected.



4. Note various options are visible as shown here: 
5. Select excluded and see the options as shown:
6. Select Use latest versions... Do not make any changes.
7. Click Cancel to close this window to make sure no changes are made.

Manage Run-Time Environment (MRTE):

1. Select Project/Open Project.
2. Open the project: C:\00MDK\addon_mdk\Boards\NXP\S32K144-EVB\RTX5_Blinky\Blinky.uvprojx.
3. Click on the Manage Run-Time Environment (MRTE) icon:  The window below opens:
4. Expand various headers and note the selections you can make. A selection made here will automatically insert the appropriate source files into your project. You can select NXP SDK files from under the Device header.
5. Do not make any changes. Click Cancel to close this window.



TIP: µVision icon meanings are found here: www.keil.com/support/man/docs/uv4/uv4_ca_filegrp_att.htm

8) Configuring OpenSDA in P&E Mode:

If you are using any Keil ULINK, CMSIS-DAP or J-Link as your debug adapter: you can skip this page:

µVision supports OpenSDA on this board in either P&E or CMSIS-DAP mode. This allows debugging the S32K board with a USB cable. No external adapter is required. The P&E firmware is installed on the S32K144 board at delivery. OpenSDA in CMSIS-DAP mode is described on the next page.


If you decide to use a ULINK2, ULINK-ME or ULINK_{plus}, you will get Serial Wire Viewer (SWV). With a ULINK_{pro}, ETM Trace is added which records all executed instructions and provides Code Coverage and Performance Analysis.

Install the P&E USB drivers:






1. Plug a USB cable from your PC to J7 on the S32K board.
2. Windows will automatically install the necessary P&E USB drivers.
Green LEDs D2 and D3 will light. If Blinky is installed, LED D11 will blink.







Start µVision and select the Blinky Project:



1. Start µVision by clicking on its desktop icon. 
2. Select Project/Open Project.
3. Open the project: C:\00MDK\addon_mdk\Boards\NXP\S32K144-EVB\RTX5_Blinky\Blinky.uvprojx.

Create a new Target Selection for P&E OpenSDA:

1. Select Project/Manage/Project Items... or select: 
2. In the Project Targets area, select NEW  or press your keyboard INSERT key.
3. Enter **PE Flash** and press Enter. Click OK to close this window.
4. In the Target Selector menu, select the PE Flash selection you just made: 
5. Select Options for Target  or ALT-F7. Click on the Debug tab to select a debug adapter.
6. Select PEMicro Debugger... as shown here: <an important step> 

Configure the P&E Connection Manager: (the board must be connected)

1. Click on Settings: The P&E Connection Manager window opens.
2. In the Interface box, select OpenSDA Embedded Tower Debug: USB Port: as shown here:

3. Click the Select New Device box, and select your exact processor. In this case it is S32K144F512M15 as shown here: This step is very important.
4. Click on the Refresh List and you will get a valid Port: box: 

Port: 

5. This means µVision is connected to the target S32K processor using P&E OpenSDA.
6. At the bottom of this window, unselect Show this dialog before attempting... as shown below:

7. Click on OK to close this window.
8. If you see **Undetected** in Port:, this means µVision is not connected to the target. Problems can be the S32K board is not connected to USB, or the wrong device is selected. Fix the problem and click Refresh List to try again.
9. Select File/Save All or click . P&E OpenSDA is now completely configured including Flash programming.
10. You can go to page 10 to compile and run Blinky !

TIP: You can program the on-board OpenSDA debug adapter U8 to run in CMSIS-DAP mode. This procedure is described on the next page. CMSIS-DAP currently has more features than P&E.

9) Configuring OpenSDA in CMSIS-DAP mode:

If you are using any Keil ULINK, or a J-Link as your debug adapter: you can skip this page:



This document will use NXP OpenSDA as a CMSIS-DAP debug adapter. This will replace the P&E debugger that comes pre-installed on a new S32K board. Target connection by μ Vision will be via a standard USB cable connected to USB connector J7. The on-board Kinetis K20 processor U8 acts as the CMSIS-DAP on-board debug adapter.

Program the K20 with the CMSIS-DAP application file CMSIS-DAP.S19:

1) Locate the file CMSIS-DAP.S19:

1. CMSIS-DAP.S19 is located where this document is located. www.keil.com/appnotes/docs/apnt_299.asp. You will now copy this file into the S32K board USB device.

2) Put the S32K Board into Bootloader: Mode:

2. Set jumper J104 to position 1-2. 
3. Hold RESET button SW5 on the board down and connect a USB cable to J7 as shown below: 
4. When you hear the USB dual-tone, release the RESET button to enter bootloader mode.
5. The **S32K board** will act as a USB mass storage device called BOOTLOADER connected to your PC. Open this USB device with Windows Explorer.

3) Copy CMSIS-DAP.S19 into the S32K Board:

6. Copy and paste or drag and drop CMSIS-DAP.S19 into this Bootloader USB device.






4) Exit Bootloader Mode:

7. Set jumper J104 to back to position 2-3.
8. Cycle the power to the S32K board while **not** holding RESET button down.
9. The **S32K board** is now ready to connect to μ Vision as a CMSIS-DAP debug adapter.


TIP: This application will remain in the U8 K20 Flash each time the board power is cycled with RESET not pressed. The next time board is powered with RESET held on, it will be erased. CMSIS-DAP.S19 is the CMSIS application in the Motorola S record format that loads and runs on the K20 OpenSDA processor.

TIP: If you must later re-program CMSIS-DAP.s19 and it still does not work with μ Vision: check that Port: is set to SW and not JTAG. See the **TIP:** below.

10) Testing The OpenSDA CMSIS-DAP Connection: (Optional Exercise)

1. Start μ Vision  if it is not already running. Select Project/Open Project.
2. Select the Blinky project C:\00MDK\addon_mdk\Boards\NXP\S32K144-EVB\RTX5_Blinky\Blinky.uvprojx.
3. Select Target Options  or ALT-F7 and select the Debug tab:
4. Select CMSIS-DAP Debugger as shown here:  
5. Click on Settings: and the window below opens up: Select SW in the Port box as shown below. An IDCODE and Device name will then be displayed indicating connection to the CoreSight DAP. This means CMSIS-DAP OpenSDA is working. You can continue with the tutorial. Click on OK twice to return to the μ Vision main menu.
6. If nothing or an error is displayed in this SW Device box, this **must** be corrected before you can continue.
7. Select File/Save All or .

TIP: To refresh the SW Device box, in the Port: box select JTAG and then select SW again. You can also exit then re-enter this window. CMSIS-DAP will not work with JTAG selected, only SW. But this is a useful way to refresh the SW setting.









11) Configuring External Debug Adapters in µVision: ULINK2/ME, ULINKpro and J-Link:

It is easy to configure for a variety of Debug Adapters. The RTX5_Blinky example is preconfigured for a Keil ULINK2. You can select S32K144 as in Step 1 and then jump to step to Testing the Debug Connection below. You can add a configuration for a ULINKpro, a J-Link or OpenSDA in either P&E or CMSIS-DAP modes easily.

Prerequisites:


µVision must be running and in Edit mode (not Debug mode). Your project must be loaded. We will use Blinky.

Create a new Target Selection:


1. Select S32K144 Flash to use as the template adapter: 
2. Select Project/Manage/Project Items... or select: 
3. In the Project Targets area, select NEW  or press your keyboard INSERT key.
4. Enter your debug adapter name and press Enter. Click OK to close this window.
5. In the Target Selector menu, select the menu item you just made: 
6. Select Options for Target  or ALT-F7. Click on the Debug tab to select a debug adapter.
7. Select your debug adapter. Valid options are ULINK2/ME, ULINK Pro Cortex Debugger, CMSIS-DAP, J-Link / JTRACE or PEMicro as shown: 

TIP: For the selections CMSIS-DAP or PEMicro Debugger, the onboard OpenSDA K20 processor must have the proper firmware installed as described on the previous two pages.

Testing the Debug Connection:

1. Connect the appropriate Debug Adapter connected to the 10 pin CoreSight connector J14.
2. Click on Settings: and the window below opens up: Select SW in the Port box and SWJ as shown below. An IDCODE and Device name will be displayed indicating connection to the processor.
3. If nothing or an error is displayed in this SW Device box, this **must** be corrected before you can continue.
4. Select File/Save All or .

TIP: To refresh the SW Device box, in the Port: box select JTAG and then select SW again. You can also exit then re-enter this window. CMSIS-DAP will not work with JTAG selected, only SW. But this is a useful way to refresh the SW setting.



Verify the Flash Program Algorithm: This is preset by the Software Pack when you select the processor.

1. Select the Flash Download tab.
2. The window that opens will display the correct algorithm. This is selected automatically according to the processor selected in the Device tab.
3. Below is the correct algorithm for the S32K144 processor:
4. Click OK twice to return to the main µVision window.





Programming Algorithm			
Description	Device Size	Device Type	Address Range
S32K144 512KB PFlash (4K...	512k	On-chip Flash	00000000H - 0007FFFFH


The new Debug Adapter is now ready to use.



TIP: You have now created a new Target Option. You can make any changes in the Options Target windows and save it. These are easily recalled by selecting the appropriate Options Target in the drop down menu as described above.

12) *Blinky* example program using the NXP S32K144 board:

Now we will connect a Keil MDK development system using the S32K board. This page will use the OpenSDA P&E debug adapter but you can select any that you have programmed and connected according to one of the three preceding pages.

1. Connect a USB cable between your PC and the S32K board J7 USB connector.
2. If you are using an external debug adapter, connect it to J14 SWD. Power the board to USB J7.
3. Start μ Vision by clicking on its desktop icon. 
4. Select Project/Open Project.
5. Open the file: C:\00MDK\addon_mdk\Boards\NXP\S32K144-EVB\RTX5_Blinky\Blinky.uvprojx.
6. Choose your debug adapter that you configured previously: 
7. Compile the source files by clicking on the Rebuild icon. 
8. Enter Debug mode by clicking on the Debug icon.  The Flash memory will be programmed. Progress will be indicated in the Output Window or in the P&E window. Select OK if the Evaluation Mode box appears.

TIP: If the Flash programs with P&E but does not enter debug mode, select Debug mode again: 


9. Click on the RUN icon. 
10. Stop the program with the STOP icon. 

The tri-colour LED will now blink in sequence on the S32K board.

Now you know how to compile a program, program it into the S32K processor Flash, run it and stop it !

Note: The board will start Blinky stand-alone. Blinky is now permanently programmed in the Flash until reprogrammed.


Single-Stepping:

1. With Blinky.c in focus (Blinky.c tab is underlined), click on the Step In icon  or F11 a few times: You will see the program counter jumps a C line at a time. The yellow arrow indicates the next C line to be executed.
2. Click on the top margin of the Disassembly window to bring it into focus. Clicking Step Into now jumps the program counter one assembly instruction at a time.

Debug Adapters:

You can use a variety of debug adapters with your S32K and μ Vision. Their feature list increases as follows:
The one with the higher number has the most performance.


1. P&E OpenSDA
2. CMSIS-DAP OpenSDA
3. Keil ULINK2 or ULINK-ME
4. J-Link
5. Keil ULINK_{plus}
6. Keil ULINK_{pro}




Keil ULINK2 with NXP S32K144 EVB

13) Hardware Breakpoints:

The S32 has six hardware breakpoints that can be set or unset on the fly while the program is running and using a CMSIS-DAP, any Keil ULINK or a J-Link debug adapter. **You must stop the program to set/unset breakpoints with P&E.**

1. With Blinky running, in the Blinky.c window, click on a darker grey block on the left on a suitable part of the source code. This means assembly instructions are present at these points. Inside the thread **thrADC** between near lines 47 through 50 is a good place: You can also click in the Disassembly window to set a breakpoint.
2. A red circle will appear and the program will presently stop. Remember to restart the program if using P&E.
3. Note the breakpoint is displayed in both the Disassembly and source windows as shown here:
4. Set a second breakpoint in the for (;;) loop as before.
5. Every time you click on the RUN icon  the program will run until the breakpoint is again encountered.
6. The yellow arrow is the current program counter value.
7. Clicking in the source window will indicate the appropriate code line in the Disassembly window and vice versa. This is relationship indicated by the cyan arrow and the yellow highlight:
8. Open Debug/Breakpoints or Ctrl-B and you can see any breakpoints set. You can temporarily unselect them or delete them.
9. Delete all breakpoints and close the Breakpoint window.
10. You can also delete the breakpoints by clicking on the red circle.



TIP: If you set too many breakpoints, μ Vision will warn you.

TIP: Arm hardware breakpoints do **not** execute the instruction they are set to and land on. Arm CoreSight hardware breakpoints are no-skid. This is a rather important feature for effective debugging.




Keil ULINKpro with NXP S32K144 EVB


14) Call Stack + Locals Window:

Local Variables:


The Call Stack and Locals windows are incorporated into one integrated window. Whenever the program is stopped, the Call Stack + Locals window will display call stack contents as well as any local variables located in the active function or thread.

If possible, the values of the local variables will be displayed and if not the message <not in scope> will be displayed. The Call + Stack window presence or visibility can be toggled by selecting View/Call Stack Window in the main µVision window when in Debug mode.


1. Set a breakpoint on one of the lines inside the thread **thrADC** in Blinky.c near lines 47 through 50.
2. Click on RUN . The program will stop on the breakpoint.


3. Click on the Step In icon  to enter a few functions.
4. Click on the Call Stack + Locals tab if necessary to open it. Expand some of the entries.

5. As you click on Step In, you can see the program entering and perhaps leaving various functions. Note the local variables are displayed




Name	Location/Value	Type
EvrRtxThreadDelay	0x000015B4	void f(unsigned int)
ticks	0x00000014	param - unsigned int
osDelay	0x00001F08	enum (int) f(unsigned int)
ticks	0x00000014	param - unsigned int
thrADC	0x00000000	void f(void *)
argument	<not in scope>	param - void *

6. Shown is an example Call Stack + Locals window:
7. The functions as they were called are displayed. If these functions had local variables, they would be displayed.
8. If you get stuck in a delay or the os_idle_Daemon, click on RUN to start over.
9. If using P&E and the program does not stop, click Stop. 

10. Click Step Out  to immediately exit a function.

11. Right click on a function and select either Callee or Caller code and this will be highlighted in the source and disassembly windows.



12. When you ready to continue, remove the hardware breakpoint by clicking on its red circle ! You can also type Ctrl-B, select Kill All and then Close.

TIP: You can modify a variable value in the Call Stack & Locals window when the program is stopped.

TIP: This window is only valid when the processor is halted. It does not update while the program is running because locals are normally kept in a CPU register. These cannot be read by the debugger while the program is running. Any local variable values are visible only when they are in scope.

Do not forget to remove any hardware breakpoints before continuing.


15) Watch and Memory Windows and how to use them:

The Watch and Memory windows will display updated variable values in real-time. It does this using the Arm CoreSight debugging technology that is part of Cortex-M processors. It is also possible to “put” or insert variable values into a Watch or Memory window in real-time. This is possible with a Watch if the variable is changing slowly or the program is stopped. It is possible to enter variable names into windows manually. You can also right click on a variable and select Add *varname* to.. and select the appropriate window. The System Viewer windows work using the same CoreSight technology. Call Stack, Watch and Memory windows can’t see local variables unless stopped in their function.

Watch window:

A global variable: The global variable `delay_val` is declared in `Blinky.c` near line 34.

1. Leave Blinky running.
2. You can configure a Watch or Memory window while the program is running.
3. **Note:** With P&E, you must stop the program to configure Watch window and to view the variable.
4. In `Blinky.c`, right click on `delay_val` and select Add `delay_val` to ... and select Watch 1. Watch 1 will automatically open. `delay_val` will be displayed as shown here:
5. Vary the pot R13 and `delay_val` will update in real time.
6. With P&E, you must stop the program to update the window.




TIP: To Drag ‘n Drop into a tab that is not active, pick up the variable and hold it over the tab you want to open; when it opens, move your mouse into the window and release the variable.

TIP: A Watch or Memory window can display and update global and static variables, structures and peripheral addresses while the program is running. These are unable to display local variables because these are typically stored in a CPU register. These cannot be read by μ Vision in real-time. To view a local variable in these windows, convert it to a static or global variable.

Memory window:

1. Right click on `delay_val` and select Add `delay_val` to ... and select Memory 1.
2. Vary the pot R13. Note: With P&E you must stop the program to see the updated variable.
3. Note the value of `delay_val` is displaying its address in Memory 1 as if it is a pointer. This is useful to see what address a pointer is pointing to but this not what we want to see at this time.
4. Add an ampersand “&” in front of the variable name and press Enter. The physical address here is `0x2000_0000`.
5. Right click in the Memory window and select Unsigned/Int.
6. The data contents of `delay_val` is displayed as shown here:
7. Both the Watch and Memory windows are updated in real-time.
8. Right-click with the mouse cursor over the desired data field and select Modify Memory. You can change a memory or variable on-the-fly while the program is still running. You will not see any change as this variable is constantly updated.



TIP: No CPU cycles are used to perform these operations.

TIP: To view variables and their location use the Symbol window. Select View/Symbol Window while in Debug mode.

SystemCoreClock:


1. In the Watch1 window, double click on `<Enter Expression>` and type in `SystemCoreClock`.
2. Right click on `SystemCoreClock` and unselect Hexadecimal Display.
3. 96 MHz will be displayed. `SystemCoreClock` is provided by CMSIS to help determine the CPU clock frequency.

16) Peripherals System Viewer (SV):

The System Viewer provides the ability to view certain registers in the CPU core and in peripherals. In most cases, these Views are updated in real-time while your program is running. These Views are available only while in Debug mode. There are two ways to access these Views: **a) View/System Viewer** and **b) Peripherals/System Viewer**.

1. Click on RUN. You can open SV windows when your program is running.



Select ADC0:

2. Select Peripherals/System Viewer and then ADC0 as shown here.
3. This window opens up. Expand RA: 
4. You can now see RA update as the pot is changed.
5. You can change the values in the System Viewer on-the-fly. In this case, the values are updated quickly so it is hard to see the change.

TIP: If you click on a register in the properties column, a description about this register will appear at the bottom of the window.


TIP: You can also open GPIO PTD to monitor the LEDs blinking.

SysTick Timer: This program uses the SysTick timer as a tick timer for RTX. RTX has configured the SysTick timer in RTX_Config.h.

1. Select Peripherals/Core Peripherals and then select SysTick
2. The SysTick window shown below opens:
3. Note it also updates in real-time while your program runs. These windows use the same CoreSight DAP technology as the Watch, Memory and Peripheral windows.
4. Note the ST_RELOAD and RELOAD registers. This is the reload register value. This is set during the SysTick configuration by RTX using values set in RTX_Config.h Kernel Tick Frequency and the CPU clock.
5. Note that it is set to 0x176FF. This is the same value hex value of 96,000,000/1000-1 (0x17700-1) that is programmed into RTX_Config.h. This is where this value comes from. Changing the variable passed to this function is how you change how often the SysTick timer creates its interrupt 15.
6. In the RELOAD register in the SysTick window, *while the program is running*, type in 0x5000 and click inside ST_RELOAD ! (or the other way around)
7. The blinking LEDs will speed up. This will convince you of the power of Arm CoreSight debugging.
8. Replace RELOAD with 0x176FF. A CPU RESET  will also do this.
9. You can look at other Peripherals contained in the System View windows.
10. When you are done, stop the program  and close all the System Viewer windows that are open.




TIP: It is true: you can modify values in the SV while the program is running. This is very useful for making slight timing value changes instead of the usual modify, compile, program, run cycle.



You must make sure a given peripheral register allows and will properly react to such a change. Changing such values indiscriminately is a good way to cause serious and difficult to find problems.



17) Watchpoints: Conditional Breakpoints

The S32K Cortex-M4 processor has two Watchpoints. Watchpoints can be thought of as conditional breakpoints. Watchpoints are also referred to as Access Breaks in Keil documents. Cortex-M3/M4/M7 Watchpoints are not intrusive for equality test. Currently, you can set one Watchpoint with μ Vision.


1. Use the same Blinky configuration as the previous page. You can configure a Watchpoint while the program is running or halted.
2. We will use the same global variable `delay_val` found in Blinky.c you used to explore the Watch windows.
3. Select Debug in the main μ Vision window and then select Breakpoints or press Ctrl-B.
4. Select Access to Read and Write.
5. Enter: “`delay_val == 0x80`” without the quotes in the Expression box. This window will display:
6. Click on Define or press Enter and the expression will be accepted into the Current Breakpoints: box as shown below in the bottom Breakpoints window:
7. Click on Close.
8. Enter the variable `delay_val` in Watch 1 if it is not already there.
9. Click on RUN. 
10. Vary Pot R13 until `delay_val` equals 0x80 as displayed in the Watch window.
11. When `delay_val` equals 0x80, the Watchpoint will stop the program. See Watch 1 shown below:
12. Watchpoint expressions you can enter are detailed in the Help button in the Breakpoints window. Triggering on a data read or write is most common. You can leave out the value and trigger on just a Read and/or Write as you select.
13. This is useful to detect levels of stack pointers.
14. To repeat this exercise, change `delay_val` to something other than 0x80 in the Watch window and click on RUN.
15. Stop the CPU if it is running. 
16. Select Debug/Breakpoints (or Ctrl-B) and delete the Watchpoint with Kill All and select Close.
17. Exit Debug mode. 



TIP: To edit a Watchpoint, double-click on it in the Breakpoints window and its information will be dropped down into the configuration area. Clicking on Define will create another Watchpoint. You should delete the old one by highlighting it and click on Kill Selected or try the next TIP:

TIP: The checkbox beside the expression allows you to temporarily unselect or disable a Watchpoint without deleting it.

TIP: Raw addresses can be used with a Watchpoint. An example is: `*((unsigned long *)0x20000004)`



18) RTX System and Threads Viewer: Need OpenSDA P&E or CMSIS-DAP, any ULINK and J-Link.

This example uses the new Arm RTX 5 RTOS. It has an Apache 2.0 license and sources and documents are included. See <http://www2.keil.com/mdk5/cmsis/rtx>. It is also located on https://github.com/ARM-software/CMSIS_5


With previous versions of RTX, the System and Thread Viewer was opened in Open Debug/OS Support.

With RTX5, select View/Watch/RTX RTOS.


Keil uses the term "threads" instead of "tasks" for consistency. You do not need to run RTX or any RTOS in your project. Using an RTOS is becoming increasingly common as projects complexity increases.

NOTE: With OpenSDA in P&E mode, the program must be stopped to open the RTX RTOS window and to see updates. OpenSDA in CMSIS-MODE displays this window updating in real-time while the program runs.

Running System and Threads Viewer:


1. μ Vision must be in Debug mode and the program running. If using P&E, stop the program.
2. Select View/Watch/RTX RTOS. A window similar to below opens up. You may have to click on its header and drag it into the middle of the screen and resize the columns to comfortably view it.
3. This window updates as the various threads switch state. (except with P&E).
4. There are three Threads listed under the Threads heading. thrADC to operate the ADC to measure the pot R13 position, thrLED to change the LEDS and thrBUT is for the buttons. These are all located in Blinky.c near lines 43, 59 and 80 respectively. It is easy to add more threads to RTX.
5. Stop the program.  It will probably stop in app_main thread in the for (;;) as shown by osThreadRunning. This program spends most of its time in app_main. This can be adjusted to meet your needs.

Stopping in a Thread:

1. Set a breakpoint in one of the three tasks in Blinky.c by clicking in the left margin on a grey area. Do not select the for (;;) statement as this will not stop the program. This line (NOP) is executed only once at the start of the program.
2. Click on Run  and the program will stop at this thread and the System and Threads Viewer will be updated.
3. You will be able to determine which thread is running when the breakpoint was activated. This is shown by osThreadRunning displayed beside the thread name.
4. If you set a breakpoint in another thread, each time you click on RUN, the next task will display as Running.
5. Remove all the breakpoints by clicking on each one. You can use Ctrl-B and select Kill All.
6. Stay in Debug mode for the next page.

TIP: You can set/unset hardware breakpoints while the program is running.

TIP: Recall this window uses CoreSight DAP read and write technology to update this window. Serial Wire Viewer is not used and is not required to be activated for this window to display and be updated.



Property	Value
System	
Kernel ID	RTX V5.1.0
Kernel State	osKernelRunning
Kernel Tick Count	1216341
Kernel Tick Frequency	1000
System Timer Frequency	96000000
Round Robin Tick Count	0
Round Robin Timeout	5
Global Dynamic Memory	Base: 0x1FFF8000, Size: 4096
Stack Overrun Check	Enabled
Stack Usage Watermark	Disabled
Default Thread Stack Size	200
ISR FIFO Queue	Size: 16, Used: 0
Threads	
id: 0x1FFF90C4, osRxBldThread	osThreadReady, osPriorityIdle
id: 0x1FFF8010, app_main	osThreadRunning, osPriorityNormal
id: 0x1FFF8130, thrBUT	osThreadBlocked, osPriorityNormal
State	osThreadBlocked
Priority	osPriorityNormal
Attributes	osThreadDetached
Waiting	Delay, Timeout: 39
Stack	Used: 36% [72]
Flags	0x00000000
id: 0x1FFF8250, thrLED	osThreadBlocked, osPriorityNormal
id: 0x1FFF8370, thrADC	osThreadBlocked, osPriorityNormal


19) Event Viewer: Uses SWV: ULINK2, ULINKplus, ULINKpro or J-Link:

Event Viewer displays the RTX threads executing in a graphical format. It is easy to make measurements of various timings of RTX. FreeRTOS has a similar window in μ Vision. A ULINKpro has the advantage of also displaying interrupt routines.

Viewing Event Viewer:


1. Run RTX5_Blinky with a suitable debug adapter connected and configured for Serial Wire Viewer operation.

2. Select Debug/OS Support and then select Event Viewer.




3. The Event Viewer window below will open:

4. Note: In This version of Event Viewer, only the main() thread is implemented for RTX5. This window is still under development. The other threads will be added in a future version of μ Vision. will be added.
5. Event Viewer for other versions of RTX are fully implemented.
6. The interrupt handlers for SVCcall, SysTick and ADC0 are displayed as a ULINKpro was used. This will also work with a ULINKplus which adds power sensing capability.



7. Select Cursor and you can make various measurements of the waveforms.
8. If you hover your mouse over a blue block, statistics will be displayed and the block turned yellow as shown below:
9. In this case, the mouse was over the ADC0 interrupt #55.
10. There were 10,512 ADC0 events. They lasted from 6.5 through 32.1 μ s with 27.85 μ s as the average time.

TIP: You can stop the update of this Event Viewer without stopping the program.



20) Event Recorder:


Event Recorder is a new μ Vision feature. Code annotations can be inserted into your code to send out messages to μ Vision and be displayed as shown below. Keil Middleware and RTX5 have these annotations already inserted. You can add Event Recorder annotations to your own source code.

Documentation for Event Recorder is found here: www.keil.com/pack/doc/compiler/EventRecorder/html/

Event Recorder				
Enable Recorder: <input checked="" type="checkbox"/> Mark: All Operations Stopped				
Event	Time (sec)	Component	Event Property	Value
0	0.01588850		Init Event	Restart Count=0x00000001
1	0.01593770	RTX Kernel	KernelInitialize	
2	0.01632660	RTX Thread	ThreadNew	func=app_main, argument=0x00000000, attr=0x00000000
3	0.01658320	RTX Kernel	KernelGetState	state=osKernelInactive
4	0.01663840	RTX Kernel	KernelStart	
5	0.01686830	RTX Thread	ThreadNew	func=thrBUT, argument=0x00000000, attr=0x00000000
6	0.01713370	RTX Thread	ThreadNew	func=thrLED, argument=0x00000000, attr=0x00000000
7	0.01740950	RTX Thread	ThreadNew	func=thrADC, argument=0x00000000, attr=0x00000000
8	0.07453070	RTX Thread	ThreadDelay	ticks=500
9	0.07466330	RTX Thread	ThreadFlagsWait	flags=0x00000001, options=0x00000000, timeout=-1
10	0.07487220	RTX Thread	ThreadDelay	ticks=20
11	0.26659260	RTX Thread	ThreadDelay	ticks=20
12	0.45859260	RTX Thread	ThreadDelay	ticks=20
13	0.65059220	RTX Thread	ThreadDelay	ticks=20
14	0.84259260	RTX Thread	ThreadDelay	ticks=20
15	1.03459260	RTX Thread	ThreadDelay	ticks=20
16	1.22659260	RTX Thread	ThreadDelay	ticks=20
17	1.41859260	RTX Thread	ThreadDelay	ticks=20
18	1.61059260	RTX Thread	ThreadDelay	ticks=20

Demonstrating Event Recorder with RTX5_Blinky:

1. μ Vision must be running Blinky from the previous page.
2. Open Event Recorder by selecting View/Analysis/Event Recorder or
3. Since Event Recorder is activated in Blinky.c, the window above will display.
4. Various RTX events will display as they happen. You can do this for your own code.



Event Recorder Features:

1. Stop and start Event Recorder while the program is running: Enable Recorder: ☒
2. Clear the window when the program is not running:
3. Stop the program.
4. In the Mark: box, enter ThreadDelay and these frames will be highlighted as shown here: This is useful to find events that do not occur frequently.
5. If you click on a frame in the Event Property column, you will be taken to Help for this event.
6. Hover your mouse over an event in the Value column and a hint will display such as this one:

osThreadFlagsSet function was called.

Event Recorder				
Enable Recorder: <input checked="" type="checkbox"/> Mark: ThreadDelay All Operations Stopped				
Event	Time (sec)	Component	Event Property	Value
0	36978.77539070	RTX Thread	ThreadDelay	ticks=20
1	36978.92899500	RTX Thread	ThreadFlagsSet	thread_id=0x1FFF8250, flags=0x00000001
2	36978.92917570	RTX Thread	ThreadDelay	ticks=70
3	36978.98654190	RTX Thread	ThreadFlagsWait	flags=0x00000001, options=0x00000000, timeout=-1
4	36978.98676130	RTX Thread	ThreadDelay	ticks=20
5	36979.17859070	RTX Thread	ThreadDelay	ticks=20
6	36979.37059070	RTX Thread	ThreadDelay	ticks=20

1. Stop the program. Close any Event Recorder and Threads and Event (RTX RTOS) windows.
2. Exit Debug mode.

21) Serial Wire Viewer (SWV) Configuration: For Keil ULINK2/ME, ULINKplus or J-Link.

Serial Wire Viewer is a data trace including interrupts in real-time without any code stubs in your sources. SWV is output on the SWO pin found on the JTAG/SWD connectors, either 10 or 20 pin. SWO is shared with JTAG TDO pin. This means you must use SWD (Keil SW) and not JTAG for debugging to avoid this conflict. SWD has essentially the same abilities as JTAG except for Boundary Scan.

These instructions are not for ULINKpro: they are on the next page.






Configure SWV:

1. Connect a ULINK2/ME, ULINKplus or J-Link to the 10 pin connector SWD J14.
2. μ Vision must be stopped and in Edit mode (not Debug mode).
3. Your debugger should be selected from other exercises in this tutorial.
4. For ULINK2/ME: select Flash: S32K144 Flash . ULINK2/ME is pre-selected.
5. Select Options for Target or ALT-F7 and select the Debug tab. Your debugger must be displayed beside Use:.
6. Select Settings: Settings on the right side of this window.
7. Confirm Port: is set to SW and SWJ box is enabled for SWD operation. SWV will not work with JTAG.
8. Click on the Trace tab. The window below is displayed.
9. In Core Clock: enter 96 MHz. Select Trace Enable. This value *must* be set correctly to your CPU speed.

TIP: To find Core Clock frequency: Enter the global variable SystemCoreClock in a Watch window and run the program.

10. Click on OK twice to return to the main μ Vision menu. SWV is now configured and ready to use.



Display Trace Records:

1. Select File/Save All or click .
2. Enter Debug mode. .
3. Click on the RUN icon. .
4. Open Trace Records window by clicking on the small arrow beside the Trace icon  and select Records: .
5. The Trace Records window will open:
6. If you see Exceptions as shown, SWV is working correctly. If not, the most probably cause is a wrong Core Clock:.
7. Double-click inside Trace Records to clear it.
8. Exception 15 is the SYSTICK timer. It is the timer provided for RTOS use.
9. All frames have a timestamp displayed.

You can see two exceptions happening:

1. Num 11 is SVCcall from the RTX calls.
2. Num 15 is the SysTick timer.
 - **Entry:** when the exception enters.
 - **Exit:** When it exits or returns.
 - **Return:** When all the exceptions have returned to the main program. This is useful to detect tail-chaining.



TIP: The only valid ITM frames are ITM 0 and ITM 31. If you see any other values, this nearly always means the Core Clock: value is incorrect. Since we are using a UART for SWO in this case, the frequency must be correct.




Type	Ovfl	Num	Address	Data	PC	Dly	Cycles	Time[s]
Exception Entry	15						1109639622	26.45921845
Exception Exit	15						1109639825	26.45922330
Exception Return	0						1109639833	26.45922349
Exception Entry	15						1109741562	26.46021845
Exception Exit	15						1109741765	26.46022330
Exception Return	0						1109741773	26.46022349
Exception Entry	15						1109783502	26.46121845
Exception Exit	15						1109783705	26.46122330

22) Serial Wire Viewer (SWV) Configuration with ULINKpro: (using the 1 bit SWO Port)






1) Configure SWV: (You can also use the 4 bit ETM Trace Port in suitably equipped NXP processors with a ULINKpro.)


1. μ Vision must be stopped and in Edit mode (not Debug mode). Blinky must be loaded.
2. Connect a ULINKpro to the 10 pin connector SWD J14. You will have already configured ULINKpro on page 9.
2. Select Options for Target  or ALT-F7 and select the Debug tab. ULINKpro must be visible in the dialog box.
3. Select Settings:  on the right side of this window.
4. Click on the Trace tab. The window below is displayed. Confirm these settings are correct.
5. Set Core Clock: to 96 MHz. ULINKpro uses this only to calculate timings displayed in some windows.
6. Select the Trace Enable box.
7. Unselect ETM Trace Enable.
8. In Trace Port, select Serial Wire Output - Manchester.
9. Select EXTRC to display exceptions and interrupts.
10. Click on OK twice to return to the main μ Vision menu. SWV is now configured and ready to use.
11. In this configuration, SWV data will be output on the 1 bit SWO pin.





TIP: If Sync Trace Port with 4-bit Data is chosen in Trace Port: box, SWV data is sent out the 4 bit Trace Port pins if available on your processor. The S32K144 does not have a Trace Port. This has much higher data throughput than the 1 bit SWO pin. It is easy to overflow trace data. A ULINKpro works the best at high SWO data rates. A ULINKplus provides high performance SWV capabilities for when there is no 4 bit Trace Port.


2) Display the Trace Data window:

1. Select File/Save All or click . It is not necessary to rebuild the project.
2. Enter Debug mode.  Click on the RUN icon. .
3. Open the Trace Data window by clicking on the small arrow beside the Trace icon: .
4. The Trace Data window shown below will open.
5. STOP  the program to display the Exceptions as shown below:



TIPS:

1. The Trace Data window is different than the Trace Records window provided with ULINK2.
2. Clear the Trace Data window by clicking .
3. The contents of the Trace Data window can be saved to a file. .
4. ULINKpro does not update the Trace Data window while the program is running.



Time	Address / Port	Instruction / Data	Src Code / Trigg...	Function
6.650 467 334 s		Exception Return		
6.651 462 160 s		Exception Entry - SysTick		
6.651 467 000 s		Exception Exit - SysTick		
6.651 467 191 s		Exception Return		
6.652 462 160 s		Exception Entry - SysTick		
6.652 467 000 s		Exception Exit - SysTick		
6.652 467 191 s		Exception Return		
6.653 462 160 s		Exception Entry - SysTick		
6.653 467 000 s		Exception Exit - SysTick		
6.653 467 191 s		Exception Return		

5. The Trace Port outputs SWV data faster than the 1 bit SWO with UART (ULINK2) or Manchester with ULINKpro. The 1 bit SWO port can still be useful for very high CPU speeds that ETM is unable to handle. (> ~ 100 MHz)


23) Displaying Exceptions (includes interrupts) with SWV:

This exercise needs a ULINK2, ULINK-ME, ULINK_{plus}, ULINK_{pro} or a J-Link. Does not work with OpenSDA.

The Trace Exceptions window displays exceptions firing with suitable timing information.

Display Trace Exceptions:

1. Select the Trace Exception tab (located beside the Watch and Memory windows).
2. Click in the Count column header to bring the active exceptions to the top as shown below:



#	Name	Count	Total Time	Min Time In	Max Time In	Min Time Out	Max Time Out	First Time [s]	Last Time [s]
15	SysTick	105419	484.661 ms	3.323 us	18.187 us	981.813 us	996.708 us	0.00170682	105.41970685
11	SVCall	9635	80.025 ms	7.083 us	18.042 us	6.583 us	19.999 ms	0.00074763	105.40372828
55	ADC0	5197	2.759 ms	406.250 ns	593.750 ns	19.960 ms	24.017 ms	0.00677968	105.40375051
2	NonMaskable	0	0 s						
3	HardFault	0	0 s						
4	MemoryMana...	0	0 s						

3. Note the various timings displayed. If you are using a ULINK_{pro} and RTX, you can see these in graphical form.

TIP: To quickly disable Trace Exceptions unselect EXCTRC: ☐ EXCTRC: Exception Tracing This is a quick way to disable Trace Exceptions if you have SWO overload. Exception frames are not captured and the bus load is less on the single bit SWO pin.


Display Trace Exceptions Graphically with a ULINK_{pro} and Event Viewer: **This needs a ULINK_{pro}.**

Event Viewer normally displays RTX threads and with a ULINK_{pro}, exception timings are added. You can clearly see when the interrupt handlers were active in relation to each other and how long they were active in their respective handler routines.

1. With a ULINK_{pro} connected and RTX5_Blinky running, select Debug/OS Support/Event Viewer. ☒ Event Viewer


2. This window opens up. Select a time of about 1 ms in Grid using the In and Out buttons.

3. You can see the three exceptions activated. The width of the blue bars indicate the exception handler execution times.



Measuring a Time:

1. Select Cursor and Timing Info.
2. Select Stop Update Screen. The Blinky program continues to run.
3. Find an ADC0 exception and click on it. This anchors it in the window.
4. Select In in the Zoom dialog until ADC0 is about as wide as in the screen below right:
5. Set the cursor by clicking on the left edge of the ADC0 blue block.
6. Hover the cursor on the block and it turns yellow/orange.
7. A box opens displaying various times as shown bottom left:



Current Slice: measures the yellow box time. **Cursors:** measures the cursor positions.




Timing of 'ADC0' (Interrupt #55)			
Current Slice:	Begin	End	Duration
No. 16959	343.9978 s	343.9978 s	0.6875 us
All Slices:	Min	Max	Average
Count: 16959	0.552083 us	0.760417 us	0.677083 us
Cursors:	Mouse	Reference	Difference
	343.9978 s	343.9978 s	0.6875 us = 1454545.454545 Hz

24) Using the Logic Analyzer (LA) with ULINK2, ULINK-ME, ULINKpro or J-Link:

This example will use a ULINK2, ULINKplus, ULINKpro or a J-Link with the Blinky example. Please connect your debug adapter to your S32K board and configure it for Serial Wire Viewer (SWV) trace as described previously on pages 18 or 19.



µVision has a graphical Logic Analyzer (LA) window. Up to four variables can be displayed in real-time using the Serial Wire Viewer as implemented in the S32K. LA uses the same comparators as Watchpoints so all can't be used at same time.

Configure and Use the Logic Analyzer:

1. SWV must be configured as found on pages 18 or 19 for the debug adapter you are using.
2. µVision must be in Debug mode.  If **Event Viewer** is open from the previous page, close it.
3. Run the program.  **TIP:** You can configure the LA while the program is running or stopped.
4. Open View/Analysis Windows and select Logic Analyzer or select the LA window on the toolbar. 
5. Locate the global variable **delay_val** in Blinky.c near line 34.
6. Right click on **delay_val** and select Add delay_val to... and select Logic Analyzer.

TIP: If an error results when adding counter to the LA, the most probable cause is SWV is not configured correctly.




7. In the LA, click on Setup and set Max: in Display Range to 0x150 and Min to 0x0. Click on Close.
8. The LA is now configured to display delay_val in a graphical format.
9. **delay_val** should still be in the Watch and Memory windows. It will be changing as you vary the Pot R13.
10. Adjust the Zoom OUT icon in the LA window to about 0.5 sec or so to display data in the LA as shown below:

TIP: If the LA is blank, exit and reenter Debug mode   to refresh the CoreSight comparators.

TIP: The Logic Analyzer can display up to four static and global variables, structures and arrays. It can't see locals: just make them static or global. To see Peripheral registers, enter them into the Logic Analyzer and write data to them.

View Data Write of delay_val:

When a variable is added to the Logic Analyzer, the data write frames are sent to the Trace Data or Records window.

1. Select Debug/Debug Settings. Select the Trace tab.
2. Select On Data R/W Sample.
3. Click OK twice. This adds execution addresses to the Src Code/Trigger Addr column.
4. Clear the Trace Data or Trace Records window. Double click for ULINK2 or for ULINKpro click: 
5. RUN the program.  STOP  the program.
6. Open the Trace Data or Trace Records window.
7. The window similar to this opens up: This one is for ULINKpro. ULINK2 is different and updates while the program is running.
8. In the Display box, select ITM Data Write:
For ULINK2, right click in the Trace Records window and unselect Exceptions.
9. The first line in **this** Trace Data window means:



The instruction at 0x0000 3428 caused a write of data 0xD7 to address 0x2000 0000 at the listed time in seconds.

10. If using a ULINKpro, in the Trace Data window, double click on a data write frame and the instruction causing this write will be highlighted in the Disassembly and the appropriate source window.

TIP: The Src Code/Trigger Addr column is activated when you selected On Data R/W Sample in Step 2. You can leave this unselected to save bandwidth on the SWO pin if you are not interested in it. With a ULINK2, this column is called PC.

TIP: The ULINK2 gives a different Trace window. It is the same Trace Records as shown elsewhere in this document.

TIP: Raw addresses can also be entered into the Logic Analyzer. An example is: *((unsigned long *)0x20000000)





Time	Address / Port	Instruction / Data	Src Code / Trigger Addr
1,697.235 755 365 s	W : 0x20000000	0x000000D7	X : 0x00003428
1,697.255 755 542 s	W : 0x20000000	0x000000D7	X : 0x00003428
1,697.275 755 365 s	W : 0x20000000	0x000000D7	X : 0x00003428
1,697.295 755 365 s	W : 0x20000000	0x000000D7	X : 0x00003428
1,697.315 755 396 s	W : 0x20000000	0x000000D7	X : 0x00003428
1,697.335 755 365 s	W : 0x20000000	0x000000D9	X : 0x00003428
1,697.355 755 542 s	W : 0x20000000	0x000000E0	X : 0x00003428
1,697.375 755 365 s	W : 0x20000000	0x000000F2	X : 0x00003428
1,697.395 755 365 s	W : 0x20000000	0x00000105	X : 0x00003428


25) *printf* using ITM 0 (Instrumentation Trace Macrocell) SWV is required:

ITM Port 0 is available for a *printf* type of instrumentation that requires minimal user code. After the write to the ITM port, zero CPU cycles are required to get the data out of the processor and into μ Vision for display in the Debug (*printf*) Viewer window. It is possible to send ITM data to a file: www.keil.com/appnotes/docs/apnt_240.asp.

1. Stop the program  and exit Debug mode .

Add STDOUT File (retarget_io.c):

1. Open the Manage Run-Time Environment window (MRTE) .
2. Expand Compiler and I/O as shown here: .
3. Select STDOUT and ITM. This adds the file retarget_io.c to the project.
4. Ensure all blocks are green and click OK to close the MRTE.




TIP: If you select EVR instead of ITM, *printf* will not require SWV.

Add *printf* to Blinky.c:




1. Inside the thread thrADC found starting near line 43, add this line at line 51: `printf("delay_val = %d\n", delay_val);`



Increase the thread stack size in RTX:

1. Open the file RTX_Config.h.
2. Select Configuration Wizard tab at its bottom.
3. Change Default Thread Stack size: to 320 bytes as shown below right:



Compile and Run the Project:

1. Select File/Save All or click .
2. Rebuild the source files  and enter Debug mode .
3. Click on View/Serial Windows and select Debug (*printf*) Viewer and click on RUN.
4. In the Debug (*printf*) Viewer you will see the *printf* statements appear as shown below right:
5. Right click on the Debug window and select Mixed Hex ASCII mode. Note other useful settings that are available.



Obtaining a character typed into the Debug *printf* Viewer window from your keyboard:

It is possible for your program to input characters from a keyboard with the function ITM_ReceiveChar in core.CM4.h.

This is documented here: www.keil.com/pack/doc/CMSIS/Core/html/group_ITM_Debug_gr.html

A working example can be found in the File System Demo in Keil Middleware. Download this using the Pack Installer.

TIP: ITM_SendChar is a useful function you can also use to send characters out ITM. It is found in core.CM4.h.

TIP: It is important to select as few options in the Trace configuration as possible to avoid overloading the SWO pin. Enable only those SWV features that you need. If you need higher performance SWV, a ULINKpro using 4 bit Trace Port or a ULINKplus using the SWO pin provides the fastest speed.

26) DSP SINE Example:



Arm CMSIS-DSP libraries are offered for Arm Cortex-M0, Cortex-M3, Cortex-M4 and Cortex-M7 processors. DSP libraries plus all sources are provided in MDK in C:\Keil_v5\ARM\Pack\ARM\CMSIS\.

See www.keil.com/cmsis and https://github.com/ARM-software/CMSIS_5.

This example creates a *sine* wave, then creates a second to act as *noise*, which are then added together (*disturbed*), and then the noise is filtered out (*filtered*). The waveform in each step is displayed in the Logic Analyzer using Serial Wire Viewer.



This example incorporates the Keil RTOS RTX. RTX has a BSD or Apache 2.0 license. All source code is provided.

This program will run with OpenSDA but to see the interesting and useful SWV features you need any ULINK or a J-Link.

1. Get the example from www.keil.com/appnotes/docs/apnt_299.asp. Copy it to C:\00MDK\Boards\NXP\S32K\DSP.
2. Open the project file C:\00MDK\Boards\NXP\S32K\DSP\sine.uvprojx.
3. **To use OpenSDA P&E:** connect a USB cable to USB connector. See page 7 to install P&E on the S32K board. No SWV including the LA will function with OpenSDA. The program must be stopped to update the Watch window.
4. **To use OpenSDA CMSIS-DAP:** connect a USB cable to USB connector. See page 8 to install CMSIS-DAP.
5. **For any ULINK or J-Link:** Connect it to the USB 8 pin connector J14 SWD connector on the S32K board.
6. Power the board by connecting a USB cable to your PC.
7. Select your debug adapter from the pull-down menu as shown here: 
8. Compile the source files by clicking on the Rebuild icon. .

9. Enter Debug mode by clicking on the Debug icon.  The Flash will be programmed.

TIP: The default Core Clock: is 80 MHz for use by the Trace configuration window under the Trace tab.

10. Click on the RUN icon.  Open the Logic Analyzer window  and the Watch 1 window: View/Watch/
11. This project has Serial Wire Viewer configured and the Logic Analyzer and Watch 1 loaded with the four variables.
12. If the variables in Watch 1 are changing, the program is running correctly. Stop the program if using P&E.
13. Four waveforms will be displayed in the Logic Analyzer using the Serial Wire Viewer as shown below. Adjust Zoom for an appropriate display. Displayed are 4 global variables: **sine**, **noise**, **disturbed** and **filtered**.

Trouble: If one or two variables display no waveform, disable ITM Stimulus Port 31 in the Trace Config window and/or Exceptions in the Trace Exceptions window. The SWO pin is probably overloaded if you are using a ULINK2. A ULINK*plus* or a ULINK*pro* handles SWV data faster than a ULINK2 or J-Link can. Make sure the Core Clock is set to 80.


14. Select View/Watch Windows and select Watch 1. The four variables are displayed updating as shown below:

15. Open the Trace Records window and the Data Writes to the four variables are displayed using Serial Wire Viewer. When you enter a variable in the LA, its data write is also displayed in the Trace window. With ULINK*pro* you must stop the program to display the data Trace Data window. J-Link does not display any data read or write frames. OpenSDA P&E has no SWV support.

16. Select View/Serial Windows/Debug (printf) Viewer. ASCII data is displayed from the printf statements in DirtyFilter.c. Not with P&E.

17. Leave the program running.


18. Close the Trace Records window if open.



Watch 1		
Name	Value	Type
sine	0xCF0E	short
noise	0x0800	short
disturbed	0xD336	short
filtered	0xC34F	short
<Enter expression>		

Signal Timings in Logic Analyzer (LA):

1. In the LA window, select Signal Info, Show Cycles, Amplitude and Cursor.
2. Click on STOP in the Update Screen box. You could also stop the program but leave it running in this case.
3. Click somewhere interesting in the LA to set a reference cursor line.
4. Note as you hover the cursor various timing information is displayed as shown below:



RTX System and Threads Viewer: This works with OpenSDA CMSIS-DAP, Keil ULINK and J-Link.

6. Click on Start in the Update Screen box to resume the collection of data. The program must be running.
7. Open Debug/OS Support and select RTX System and Thread Viewer. A window similar to below opens up. You may have to click on its header and drag it into the middle of the screen to comfortably view it.
8. As the various threads switch state this is displayed. Note most of the CPU time is spent in the idle daemon: it shows as Running. The processor spends relatively little time in other tasks. You will see this illustrated clearly on the next page. It is possible to adjust these timings to give more CPU time to various threads as needed.

NOTE: With OpenSDA in P&E mode, the program must be stopped to update this window.

9. Set a breakpoint in each of the four tasks in DirtyFilter.c by clicking in the left margin on a grey area. Do not select while(1) as this will not stop the program.
10. Click on Run and the program will stop at a thread and the System and Threads Viewer will be updated accordingly. In the screen below, the program stopped in the noise_gen task:
11. Clearly you can see that noise_gen was Running when the breakpoint was activated.
12. Each time you click on RUN, the next task will display as Running.
13. Remove all the breakpoints by clicking on each one. You can use Ctrl-B and select Kill All.
14. Stay in Debug mode for the next page.

System and Thread Viewer

Property

Value

System

Item

Value

Tick Timer:

1.000 mSec

Round Robin Timeout:

5.000 mSec

Default Thread Stack Size:

200

Thread Stack Overflow Check:

Yes

Thread Usage:

Available: 6, Used: 6 + 0...

Threads

ID

Name

Priority

State

Delay

Event Value

Event Mask

Stack Usage

1

main

Normal

Wait_DLY

32%

2

sine_gen

Normal

Wait_DLY

1

0x0000

0x0001

44%

3

noise_gen

Normal

Running

0x0000

0x0001

8%

4

disturb_gen

Normal

Wait_AND

65529

0x0000

0x0001

40%

5

filter_tsk

Normal

Wait_AND

65531

0x0000

0x0001

40%

6

sync_tsk

Normal

Wait_AND

0x0000

0x0001

40%

255

os_idle_demon

None

Ready

32%


TIP: You can set/unset hardware breakpoints while the program is running.



TIP: Recall this window uses CoreSight DAP read and write technology to update this window. Serial Wire Viewer is not used and is not required to be activated for this window to display and be updated.


The DSP example uses RTX4 and not RTX5 as used in the RTX5_Blinky example. This means the System and Thread Viewer has a different format.

The Event Viewer does use SWV and this is demonstrated on the next page.

RTX Event Viewer (EV): **ULINK2, ULINKplus, ULINKpro and J-Link: Not with OpenSDA.**

1. *If you are using a ULINKpro, skip this step unless you want to see SWV overload.:* Stop the program. Click on Setup... in the Logic Analyzer. Select Kill All to remove all variables and select Close. This is necessary because the SWO pin will likely be overloaded when the Event Viewer is opened up. Inaccuracies might/will occur.
2. Select Debug/Debug Settings.
3. Click on the Trace tab.
4. Enable ITM Stimulus Port 31. Event Viewer uses this port to collect its information.
5. Click OK.
6. Click on RUN .
7. Open Debug/OS Support and select Event Viewer. The window here opens up:

TIP: If Event Viewer is still blank, exit and re-enter Debug mode.  




Main Thread:

1. Select Stop in the Update Screen. Scroll to the beginning of the Event Viewer.
2. The first thread in this program was main() as depicted in the Event Viewer. The main thread is the main() function in DirtyFilter.c. It runs some RTX initialization code at the beginning and is stopped with osDelay(osWaitForever);.

TIP: If Event Viewer is blank or erratic, or the LA variables are not displaying or blank: this is likely because the Serial Wire Output pin is overloaded and dropping trace frames. Solutions are to delete some or all of the variables in the Logic Analyzer to free up some SWO or Trace Port bandwidth. Try turning off the exceptions with EXTRC.

3. The 5 running threads plus the idle daemon are displayed on the Y axis. Event Viewer shows which thread is running, when and for how long.
4. Click Stop in the Update Screen box.
5. Click on Zoom In so three or four threads are displayed as shown here:
6. Select Cursor. Position the cursor over one set of bars and click once. A red line is set here:
7. Move your cursor to the next set and total time and difference are displayed.
8. Since you enabled Show Cycles, the total cycles and difference is also shown.




The 1 msec shown is the SysTick timer value which is set in RTX_Conf_CM.c in the OS_CLOCK and OS_TICK variables.

Using a Keil ULINKpro to view Interrupt Handler execution times:

SWV Throughput: ULINKpro is much better with SWO bandwidth issues. It has been able to display both the EV and LA windows. The ULINKpro ETM and ULINKpro Manchester modes are preconfigured in Options for Target.

ULINKpro can also use the 4 bit Trace Port for even faster operation for SWV. Trace Port use is mandatory for ETM trace. A ULINKpro in ETM mode provides program flow debugging, Code Coverage and Performance Analysis. ULINKpro also supports ETB (Embedded Trace Buffer) as found in many Kinetis processors.

Exceptions: A ULINKpro displays exceptions at the bottom of the Event Viewer. Shown here are the SysTick and SVCALL exceptions. You can measure the duration of the time spent in the handlers. Any other exception events such as DMA will also be displayed here.



This is the end of the lab exercises !

27) Document Resources:

See www.keil.com/NXP

Books:

1. **NEW!** Getting Started with MDK 5: Obtain this free book here: www.keil.com/mdk5/
2. There is a good selection of books available on ARM: www.arm.com/support/resources/arm-books/index.php
3. μ Vision contains a window titled Books. Many documents including data sheets are located there.
4. **The Definitive Guide to the Arm Cortex-M0/M0+** by Joseph Yiu. Search the web for retailers.
5. **The Definitive Guide to the Arm Cortex-M3/M4** by Joseph Yiu. Search the web for retailers.
6. **Embedded Systems: Introduction to Arm Cortex-M Microcontrollers** (3 volumes) by Jonathan Valvano
7. MOOC: Massive Open Online Class: University of Texas: <http://users.ece.utexas.edu/~valvano/>

Application Notes:

1. **NEW!** Arm Compiler Qualification Kit: Compiler Safety Certification: www.keil.com/safety
2. Using Cortex-M3 and Cortex-M4 Fault Exceptions www.keil.com/appnotes/files/apnt209.pdf
3. CAN Primer using Keil MCB170: www.keil.com/appnotes/files/apnt_247.pdf
4. Segger emWin GUIBuilder with μ Vision™ www.keil.com/appnotes/files/apnt_234.pdf
5. Porting mbed Project to Keil MDK™ www.keil.com/appnotes/docs/apnt_207.asp
6. MDK-ARM™ Compiler Optimizations www.keil.com/appnotes/docs/apnt_202.asp
7. GNU tools (GCC) for use with μ Vision <https://launchpad.net/gcc-arm-embedded>
8. Barrier Instructions <http://infocenter.arm.com/help/topic/com.arm.doc.dai0321a/index.html>
9. Cortex-M Processors for Beginners: <http://community.arm.com/docs/DOC-8587>
10. Lazy Stacking on the Cortex-M4: www.arm.com and search for DAI0298A
11. Cortex Debug Connectors: www.keil.com/coresight/coresight-connectors
12. FlexMemory configuration using MDK www.keil.com/appnotes/files/apnt220.pdf
13. Sending ITM printf to external Windows applications: www.keil.com/appnotes/docs/apnt_240.asp
14. **NEW!** Migrating Cortex-M3/M4 to Cortex-M7 processors: www.keil.com/appnotes/docs/apnt_270.asp
15. **NEW!** ARMv8-M Architecture Technical Overview www.keil.com/appnotes/files/apnt_291.pdf
16. **NEW!** Determining Cortex-M CPU Frequency using SWV www.keil.com/appnotes/docs/apnt_297.asp

Keil Tutorials for NXP Boards:

www.keil.com/NXP

1. KL25Z Freedom www.keil.com/appnotes/docs/apnt_232.asp
2. K20D50M Freedom Board www.keil.com/appnotes/docs/apnt_243.asp
3. Kinetis K60N512 Tower www.keil.com/appnotes/docs/apnt_239.asp
4. Kinetis K60D100M Tower www.keil.com/appnotes/docs/apnt_249.asp
5. Kinetis FRDM-K64F Freedom www.keil.com/appnotes/docs/apnt_287.asp
6. Kinetis K64F120M Tower www.keil.com/appnotes/docs/apnt_288.asp
7. A lab for the S32K-148 EVB using ETM: www.keil.com/appnotes/docs/apnt_305.asp
8. NXP Cookbook Example Ports for MDK: www.keil.com/appnotes/docs/apnt_304.asp

Useful Arm Websites:

1. **NEW!** CMSIS 5 Standards: https://github.com/ARM-software/CMSIS_5 and www.keil.com/cmsis/
2. Forums: www.keil.com/forum <http://community.arm.com/groups/tools/content> <https://developer.arm.com/>
3. Arm University Program: www.arm.com/university. Email: university@arm.com
4. mbed™: <http://mbed.org>

28) Keil Products and contact information: See www.keil.com/NXP

Keil Microcontroller Development Kit (MDK-ARM™) for NXP processors:

- **MDK-Lite™** (Evaluation version) up to 32K Code and Data Limit - \$0
- **New MDK-ARM-Essential™** For all Cortex-M series processors – unlimited code limit
- **New MDK-Plus™** MiddleWare Level 1. ARM7™, ARM9™, Cortex-M, SecureCore®.
- **New MDK-Professional™** MiddleWare Level 2. For details: www.keil.com/mdk5/version520.

For the latest MDK details see: www.keil.com/mdk5/selector/

Keil Middleware includes Network, USB, Graphics and File System. www.keil.com/mdk5/middleware/

USB-JTAG/SWD Debug Adapter (for Flash programming too)

- **ULINK2** - (ULINK2 and ME - SWV only – no ETM) **ULINK-ME** is equivalent to a ULINK2.
- **New ULINKplus-** Cortex-Mx High performance SWV & power measurement.
- **ULINKpro** - Cortex-Mx SWV & ETM instruction trace. Code Coverage and Performance Analysis.
- **ULINKpro D** - Cortex-Mx SWV no ETM trace ULINKpro also works with Arm DS-5.

You can use OpenSDA on the S32K board. For Serial Wire Viewer (SWV), a ULINK2, ULINK-ME or a J-Link is needed. For ETM support, a ULINKpro is needed. OS-JTAG or OpenSDA do not support either SWV or ETM. Call Keil Sales for more details on current pricing. All products are available.

For the Arm University program: go to www.arm.com/university Email: university@arm.com

All software products include Technical Support and Updates for 1 year. This can easily be renewed.

Keil RTX™ Real Time Operating System

- RTX is provided free as part of Keil MDK.
- No royalties are required. It has a BSD or Apache 2.0 license.
- RTX source code is included with all versions of MDK.
- Kernel Awareness visibility windows are integral to µVision.
- https://github.com/ARM-software/CMSIS_5

For the entire Keil catalog see www.keil.com or contact Keil or your local distributor. For NXP support: www.keil.com/NXP

For Linux, Android, bare metal (no OS) and other OS support on NXP i.MX and Vybrid series processors please see DS-5 and DS-MDK at www.arm.com/ds5/ and www.keil.com/ds-mdk.

Getting Started with DS-MDK: www.keil.com/mdk5/ds-mdk/install/



For more information:

Sales In Americas: sales.us@keil.com or 800-348-8051. Europe/Asia: sales.intl@keil.com +49 89/456040-20

Keil Technical Support in USA: support.us@keil.com or 800-348-8051. Outside the US: support.intl@keil.com.

Global Inside Sales Contact Point: Inside-Sales@arm.com Arm Keil World Distributors: www.keil.com/distis

Forums: www.keil.com/forum <http://community.arm.com/groups/tools/content> <https://developer.arm.com/>

