



User-based Licensing

Version 1.2022011

License Server Administration Guide

Non-Confidential

Copyright © 2022 Arm Limited (or its affiliates).
All rights reserved.

Issue 00

107573_1.2022011_00_en



User-based Licensing License Server Administration Guide

Copyright © 2022 Arm Limited (or its affiliates). All rights reserved.

Release information

Document history

Issue	Date	Confidentiality	Change
1.2022010-00	21 June 2022	Non-Confidential	New document for v1.2022010 Beta
1.2022011-00	22 July 2022	Non-Confidential	Updated document for v1.2022011

Proprietary Notice

This document is protected by copyright and other related rights and the practice or implementation of the information contained in this document may be protected by one or more patents or pending patent applications. No part of this document may be reproduced in any form by any means without the express prior written permission of Arm. No license, express or implied, by estoppel or otherwise to any intellectual property rights is granted by this document unless specifically stated.

Your access to the information in this document is conditional upon your acceptance that you will not use or permit others to use the information for the purposes of determining whether implementations infringe any third party patents.

THIS DOCUMENT IS PROVIDED "AS IS". ARM PROVIDES NO REPRESENTATIONS AND NO WARRANTIES, EXPRESS, IMPLIED OR STATUTORY, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY, SATISFACTORY QUALITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE WITH RESPECT TO THE DOCUMENT. For the avoidance of doubt, Arm makes no representation with respect to, has undertaken no analysis to identify or understand the scope and content of, third party patents, copyrights, trade secrets, or other rights.

This document may include technical inaccuracies or typographical errors.

TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL ARM BE LIABLE FOR ANY DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF ANY USE OF THIS DOCUMENT, EVEN IF ARM HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

This document consists solely of commercial items. You shall be responsible for ensuring that any use, duplication or disclosure of this document complies fully with any relevant export laws and regulations to assure that this document or any portion thereof is not exported, directly or indirectly, in violation of such export laws. Use of the word “partner” in reference to Arm’s customers is not intended to create or refer to any partnership relationship with any other company. Arm may make changes to this document at any time and without notice.

This document may be translated into other languages for convenience, and you agree that if there is any conflict between the English version of this document and any translation, the terms of the English version of the Agreement shall prevail.

The Arm corporate logo and words marked with ® or ™ are registered trademarks or trademarks of Arm Limited (or its subsidiaries) in the US and/or elsewhere. All rights reserved. Other brands and names mentioned in this document may be the trademarks of their respective owners. Please follow Arm’s trademark usage guidelines at <https://www.arm.com/company/policies/trademarks>.

Copyright © 2022 Arm Limited (or its affiliates). All rights reserved.

Arm Limited. Company 02557590 registered in England.

110 Fulbourn Road, Cambridge, England CB1 9NJ.

(LES-PRE-20349)

Confidentiality Status

This document is Non-Confidential. The right to use, copy and disclose this document may be subject to license restrictions in accordance with the terms of the agreement entered into by Arm and the party that Arm delivered this document to.

Unrestricted Access is an Arm internal classification.

Product Status

The information in this document is Final, that is for a developed product.

Feedback

Arm® welcomes feedback on this product and its documentation. To provide feedback on the product, create a ticket on <https://support.developer.arm.com>

To provide feedback on the document, fill the following survey: <https://developer.arm.com/documentation-feedback-survey>.

Inclusive language commitment

Arm values inclusive communities. Arm recognizes that we and our industry have used language that can be offensive. Arm strives to lead the industry and create change.

We believe that this document contains no offensive language. To report offensive language in this document, email terms@arm.com.

Contents

1. Introduction.....	6
1.1 Conventions.....	6
1.2 Other information.....	7
2. Getting started with user-based licensing.....	8
2.1 Hardware and software requirements.....	8
2.2 Install your license server.....	9
2.3 Configure your license server.....	11
2.4 Register your license server.....	12
2.5 User license activation.....	14
3. License server administration.....	16
3.1 Stop the license server.....	16
3.2 Start the license server.....	16
3.3 Restart the license server.....	16
3.4 Finding the license server status.....	17
3.5 List licenses and usage.....	17
3.6 Modify number of licenses.....	18
3.7 List users.....	19
3.8 Find your license server version.....	20
3.9 Change the administrator password.....	20
3.10 Monitoring the license server.....	21
4. Obsoleting the license server.....	22
4.1 Obsolete a license server.....	22

1. Introduction

This guide describes how to install and manage a license server for Arm software products licensed under the user-based licensing model.

1.1 Conventions

The following subsections describe conventions used in Arm documents.




Glossary




The Arm Glossary is a list of terms used in Arm documentation, together with definitions for those terms. The Arm Glossary does not contain terms that are industry standard unless the Arm meaning differs from the generally accepted meaning.

See the Arm® Glossary for more information: developer.arm.com/glossary.

Typographic conventions

Arm documentation uses typographical conventions to convey specific meaning.

Convention	Use
<i>italic</i>	Citations.
bold	Interface elements, such as menu names. Terms in descriptive lists, where appropriate.
monospace	Text that you can enter at the keyboard, such as commands, file and program names, and source code.
monospace <u>underline</u>	A permitted abbreviation for a command or option. You can enter the underlined text instead of the full command or option name.
<and>	Encloses replaceable terms for assembler syntax where they appear in code or code fragments. For example: <pre>MRC p15, 0, <Rd>, <CRn>, <CRm>, <Opcode_2></pre>
SMALL CAPITALS	Terms that have specific technical meanings as defined in the <i>Arm® Glossary</i> . For example, IMPLEMENTATION DEFINED , IMPLEMENTATION SPECIFIC , UNKNOWN , and UNPREDICTABLE .
 Caution	Recommendations. Not following these recommendations might lead to system failure or damage.
 Warning	Requirements for the system. Not following these requirements might result in system failure or damage.
 Danger	Requirements for the system. Not following these requirements will result in system failure or damage.

Convention	Use
 Note	An important piece of information that needs your attention.
 Tip	A useful tip that might make it easier, better or faster to perform a task.
 Remember	A reminder of something important that relates to the information you are reading.

1.2 Other information

See the Arm website for other relevant information.

- [Arm® Developer](#).
- [Arm® Documentation](#).
- [Technical Support](#).
- [Arm® Glossary](#).

2. Getting started with user-based licensing

Describes how to install, configure, and register the license server for Arm software products licensed under the user-based licensing model.



Note

The user-based licensing license server software is different from, and incompatible with, other license models used by Arm software products, including:

- FlexNet Publisher node-locked and floating
- Keil® node-locked and floating
- Allinea node-locked and floating

2.1 Hardware and software requirements

The hardware and software requirements presented in this section are for the Arm user-based licensing license server software. In a typical deployment setup, the license server software runs on a dedicated license-managed device, separate from Arm software products running on client devices.

Hardware requirements

The license server has the following minimum hardware requirements:

- Processor: A dual core 64-bit x86 2GHz processor (or equivalent)
- Memory: 4GB
- Storage: 500MB

Supported operating systems

The license server is supported on the following operating systems:

- Red Hat Enterprise Linux or CentOS 7
- Red Hat Enterprise Linux or CentOS 8
- Ubuntu 20.04 LTS

Required system software

The license server and utilities require the following software to be installed and, where applicable, running:

- Common Linux utilities: `bash`, `tar`, `sed`, `getopt`, `uname`, `sleep`, and `grep`
- `systemd` Linux service manager
- Python 3.6 or higher
- One of the following Java Virtual Machine (JVM) implementations:
 - Oracle Java SE 8

- OpenJDK 8
- OpenJDK 11

2.2 Install your license server

To install the license server, use the following procedure.

Before you begin

Download the license server Linux installation package from <https://lm.arm.com/downloads>.

The installation requires elevated privileges to:

- Create a new `flexnetls` group and user for the license server service
- Create the installation directory (`/opt/flexnetls-armlmd` by default)
- Create the data storage directory (`/var/opt/flexnetls-armlmd` by default)
- Register the license server service with `systemd` and start the service

Procedure

1. From the command line, change directory to the directory containing the downloaded software bundle and then extract it using the following command:

```
tar -xf flexnetls-armlmd-<version>.tar.gz
```

The extraction creates the installer directory, `flexnetls-armlmd-<version>`.



The `flexnetls-armlmd-<version>` installation directory can be placed in any disk location and can be deleted after the installation process has completed.

2. Install the license server by running the following command as root:

```
sudo [-E] flexnetls-armlmd-<version>/install_license_server [--port <port>] [--install-dir <installation_directory>] [--data-dir <data_directory>]
```

Where:

- The `-E` parameter preserves the environment of the current user when running the command as root. This might be required if the location of the Java Virtual Machine (JVM) relies on the `JAVA_HOME` environment variable set in the environment of the current user.
- `<port>` specifies the TCP network port that the license server listens on. If the `--port` parameter is not specified, the port defaults to 7070.



You cannot specify a port number of 1024 or lower because this port range is reserved for processes running as `root`. For security reasons, the license server runs as the `flexnetls` user and Arm does not recommend changing this user to `root`.

- `<installation_directory>` is the installation directory for the license server software. If the `--install-dir` parameter is not specified, the installation directory defaults to `/opt/flexnetls-armlmd`.
- `<data_directory>` is the directory used to store the license server state files and logs. If the `--data-dir` parameter is not specified, the data directory defaults to `/var/opt/flexnetls-armlmd`.

The license server is automatically started after the installation process completes. The license server also starts automatically when the server device is restarted.

3. You must change the default installed administrator user (`admin`) password because you cannot use this password to perform administration tasks:
 - a) From the command line, change to the `bin` directory in the license server installation directory, for example:

```
cd /var/opt/flexnetls-armlmd/bin
```

- b) Run the following command:

```
./armlm_change_default_admin_password
```

The new password must meet the following criteria:

- Between 8 and 64 characters
- At least one digit
- At least one uppercase character
- At least one special character (for example, `^*$-+?_&=!%{}/#@`)
- No whitespace characters

You are asked to confirm the new password by entering it again.

The following is output when the administration password is successfully changed:

```
New password for 'admin':
{
  "id" : 2,
  "user" : "admin",
  "enabled" : true,
  "userExpiry" : "permanent",
  "roles" : [ {
    "id" : 6,
    "role" : "ROLE_DROPCLIENT"
  }, {
    "id" : 3,
    "role" : "ROLE_RESERVATIONS"
  }, {
    "id" : 7,
    "role" : "ROLE_ADMIN"
  } ]
}
```

```
    }, {  
      "id" : 4,  
      "role" : "ROLE_READ"  
    } ]  
  }  
}
```

Results

After the license server is installed, it starts automatically. The license server service is configured to start and stop automatically with the operating system.

The installation directory has the following content:

- `bin` contains the administration utilities.
- `server` contains the license server daemon and related configuration files.
- `license_terms` contains the software license agreement.

Next steps

[Configure your license server](#)

2.3 Configure your license server

After the license server has been installed, you must configure the server.

Before you begin

- [Install your license server](#)

Procedure

1. The port number that the license server uses can be set on installation. If not set, the port number defaults to 7070. You can change the port number as follows:
 - a) Edit the `<installation_directory>/server/local-configuration.yaml` file.
 - b) Modify the `port` value, for example:
`port: 7071`
 - c) Restart the license server using the following command:

```
sudo systemctl restart flexnetls-armlmd
```

2. Set the following environment variables on the license server device:

- `PATH`

Update this environment variable to include the `bin` directory in the license server installation directory.

- `FLEXNETLS_BASEURL`

This environment variable must be set to:

`http://localhost:<port>/api/1.0/instances/~`

Where <port> is the license server port number. For example:

```
export FLEXNETLS_BASEURL=http://localhost:7070/api/1.0/instances/~
```

Next steps

[Register your license server](#)

2.4 Register your license server

You must register your license server on the Arm licensing portal, so you can add product licenses to the server.

Before you begin

- [Install your license server](#)
- [Configure your license server](#)

Procedure

1. Make sure the license server is running using the following command:

```
systemctl status flexnetls-armlmd
```

If the server is not running, start it using the following command:

```
sudo systemctl start flexnetls-armlmd
```

2. When you install the license server, the installation process selects a hostid. Several other hostids could be available, depending on the hardware configuration of the host. You must check that the selected hostid is appropriate, for example to ensure the most stable hostid is used.



The licenses generated for a license server are locked to the hostid of the license server. You cannot change the license server hostid after you have registered your license server.

Use the following command to review the selected hostid:

```
armlm_show_hostid
```

The password for `admin` is requested. The output shows the selected hostid and the available hostids. For example:

```
{  
  "selected" : {
```

```

    "hostidType" : "ETHERNET",
    "hostidValue" : "0800270AA6FF"
  },
  "hostids" : [ {
    "hostidType" : "ETHERNET",
    "hostidValue" : "0800270AA6FF"
  }, {
    "hostidType" : "ETHERNET",
    "hostidValue" : "080027503FFF"
  } ]
}

```

If you want to change the hostid used by the license server:

- a) Edit the <installation_directory>/server/local-configuration.yaml file.
- b) Uncomment the following line:


```
#active-hostid:
```
- c) Add one of the hostids identified by `armlm_show_hostid` command as the `active-hostid` value in the format <hostid>/ETHERNET. For example:


```
active-hostid: 080027503FFF/ETHERNET
```
3. Create an identity file, `identity.bin`, for the license server using the following command:

```
armlm_generate_server_identity --identity-file identity.bin
```

The password for `admin` is requested.

4. Register your license server with Arm:
 - a) Access the Arm user-based licensing portal on <https://developer.arm.com/support/licensing/user-based>.
 - b) Click **Manage License Servers** and then click **Register Local License Server**.
 - c) Click **Browse**, select the `identity.bin` file and then click **Open**.
 - d) Click **Upload**. After a short while, you are returned to the **Manage License Servers** page with your license server shown in the list of license servers. The name of the server is the license server hostid.
5. Allocate licenses to the license server:
 - a) Click **Manage Server** on the required license server.
 - b) The server page displays any product licenses associated with server. For your new license server, this should be empty. Click **Add Products**.
 - c) The **Add Products to License Server** page shows the available products with used licenses and expiry date. In the **Quantity** field for each required product, enter the number of licenses to transfer to your license server. Click **Add Products** to return to the server page.
 - d) Click **Download all licenses allocated to this server** and a license file containing the license data is downloaded. The license file name has the following format:

```
licenses-<server_ID>-<timestamp>.bin
```

Where <server_ID> is the license server name and <timestamp> is the date and time the license file was created.

- e) If the license file was not downloaded to the license server device, transfer the file to this device.
- f) Use the following license command to load the license data:

```
armlm_update_licenses --data-file <license_file>
```

Where <license_file> is the name of the license file. The password for `admin` is requested.

The output from the command is as follows, confirming no further action is required when adding licenses:

```
{
  "confirmationRequestNeeded" : false
}
```

Next steps

[User license activation](#)

Related information

[List licenses and usage](#) on page 17

[Modify number of licenses](#) on page 17

2.5 User license activation

After the license server has been registered, you must inform your users how to activate the licenses for their Arm products. In this case, a user could be a human using an Arm product or an automated process. Users can license a product using one of the following methods:

- Use one of the following methods to manually activate the license:
 - [Activate your product from the command line](#)
 - [Activate your product in the License Manager](#)
- Dynamically activate the license by setting the `ARMLM_ONDEMAND_ACTIVATION` environment variable to the following:

```
<product_code>@<server_URL>
```

Where `<product_code>` is the product code and `<server_URL>` is the URL to access the license server. For example, `HWSKT-STD0@https://license.serv.mycom.com`.



This method might not be suitable where a large number of parallel processes can make initial license requests, as the license server could time-out some of the requests.

After activation, the user is assigned to the license for 30 days. Subsequent use of any Arm product that supports user-based licensing on the same device by that user renews the license for the next 30 days by contacting the license server. If the license cannot be extended, for example there is no connection to the license server, you can still use the product as licensed until the 30-day limit expires.

Activating licenses on multiple devices

The license assigned to a user can be used on multiple devices. You can make the license assigned to a user available on another device using one of the following methods:

- On the new device, activate the license for an Arm product that has the same user.
- The cached Arm license details are stored in the `.arm1m` directory. Other devices using Arm products can use the cached license by, for example:
 - Copying the `.arm1m` directory to a local directory on the new device.
 - Copying the `.arm1m` directory to a network directory. On the new device, set the `ARMLM_CACHED_LICENSES_LOCATION` environment variable to the location of `.arm1m` on the network drive.

3. License server administration

Describes how you can administer the Arm user-based licensing license server, including the available license server commands.

3.1 Stop the license server

The license server is automatically started after installation and when the server device is restarted.

Procedure

Stop the license server with the following command:

```
sudo systemctl stop flexnetls-armlmd
```

Related information

[Finding the license server status](#) on page 17

[Start the license server](#) on page 16

3.2 Start the license server

The license server is automatically started after installation and when the server device is restarted.

Before you begin

The license server has been [stopped](#) by the administrator.

Procedure

Start the license server with the following command:

```
sudo systemctl start flexnetls-armlmd
```

Related information

[Finding the license server status](#) on page 17

3.3 Restart the license server

Use this procedure to restart the license server.

Before you begin

The license server must be running.

Procedure

Restart the license server using the following command:

```
sudo systemctl restart flexnetls-armlmd
```

Related information

[Finding the license server status](#) on page 17

3.4 Finding the license server status

Use this procedure to find the status of your license server.

Procedure

Check the license server service status using the following command:

```
systemctl status flexnetls-armlmd
```

Related information

[Restart the license server](#) on page 16

[Stop the license server](#) on page 16

[Start the license server](#) on page 16

3.5 List licenses and usage

Use this procedure to list the product licenses and their usage on your license server.

Before you begin

The license server must be running.

Procedure

List the licenses on your license server using the following command:

```
armlm_list_products
```

The following is an example of the output from this command:

```
3 product(s) found on license server
Hardware Success Kit Standard, HWSKT-STD0, 60 seat(s), 33 seat(s) used
  Order 273591004, valid until: 2023-02-24, 50 seat(s), 28 seat(s) used
  Order 273591034, valid until: 2023-12-31, 10 seat(s), 5 seat(s) used
Keil MDK Professional, KEMDK-PRO0, 20 seat(s), 12 seat(s) used
  Order 273591003, valid until: 2023-02-15, 20 seat(s), 12 seat(s) used
```

Related information

[List users](#) on page 19

3.6 Modify number of licenses

Use the following procedure to modify the number of licenses available on the license server.

Before you begin

The license server must be running.

Procedure

1. On the Arm user-based licensing portal, modify the number of licenses allocated to the license server as follows:
 - a) Access the user-based licensing portal on <https://developer.arm.com/support/licensing/user-based>.
 - b) Click **Manage License Servers** to display the list of servers.
 - c) Click **Manage Server** on the required license server. The server page displays any product licenses associated with server.
 - d) Click **Edit seats** on the required product.
 - e) The number of seats currently allocated for this product are shown under **Total seat count**. Modify the number of licenses under **Total seat count** and then click **Confirm Changes**. If the number of licenses has been reduced, a warning dialog is shown and you need to click **Confirm Changes** in this dialog.

A file containing the new license data is downloaded. This file has the following filename:

`licenses-<server_ID>-<timestamp>.bin`

Where `<server_ID>` is the identifier of the server and `<timestamp>` is the time the file was created.



If you have reduced the number of licenses for a product, you cannot make changes to the number of licenses for that product until a confirmation file is uploaded (see step 3).

2. Transfer the file to the license server device and use the following license command to load the modified license data:

```
armlm_update_licenses --data-file licenses-<server_ID>-<timestamp>.bin
```

The password for `admin` is requested. The output determines if further action is required:

- If licenses are removed, the following output confirms that further action is required:

```
{
  "confirmationRequestNeeded" : true
}
```

- If licenses are added, the following output confirms that no further action is required:

```
{
  "confirmationRequestNeeded" : false
}
```

3. If licenses have been removed, a confirmation is required:

a) Use the following license server command to generate a confirmation file:

```
armlm_generate_server_confirmation --confirmation-file confirmation.bin
```

The password for `admin` is requested.

b) Access the user-based licensing portal on <https://developer.arm.com/support/licensing/user-based>.

c) Click **Manage License Servers** to display the list of servers.

d) Click **Manage Server** on the required license server. The server page displays any product licenses associated with server.

e) For a product that has reduced licenses, click **Edit Seats**.

f) In Server Configuration File, click browse to select the `confirmation.bin` file. Click **Upload Confirmation**.

When file has been uploaded successfully, a "Capability request accepted, seat changes confirmed" message is displayed.

Related information

[List licenses and usage](#) on page 17

3.7 List users

Use this procedure to list the users on your license server and their associated products.

Before you begin

The license server must be running.

Procedure

List the users on your license server using the following command:

```
armlm_list_users
```

The following is an example of the output from this command:

User	Product Code	Product Name	Last Access	Held Until
adlxho	HWSKT-STD0	Hardware Success Kit	2022-Apr-19 10:13:19 UTC	2022-May-19
hxyiso	HWSKT-STD0	Hardware Success Kit	2022-Apr-14 09:08:38 UTC	2022-May-14
jxycot	HWSKT-STD0	Hardware Success Kit	2022-Apr-12 09:58:42 UTC	2022-May-12
jxyche	HWSKT-STD0	Hardware Success Kit	2022-Apr-03 00:25:09 UTC	2022-May-03

Related information

[List licenses and usage](#) on page 17

3.8 Find your license server version

Use this procedure to find the version of your license server.

Before you begin

The license server must be running.

Procedure

Print the license server version using the following command:

```
flexnetlsadmin -version
```

3.9 Change the administrator password

You can change the administrator password from the command line.

Before you begin

The license server must be running.

Procedure

1. From the command line, change to the `bin` directory in the license server installation directory.
For example:

```
cd /var/opt/flexnetls-armlmd/bin
```

2. Run the following command:

```
./armlm_change_admin_password
```

3. Enter the existing password.
4. Enter the new password. The new password must meet the following criteria:
 - Between 8 and 64 characters
 - At least one digit
 - At least one uppercase character
 - At least one special character (for example, `^*$-+?_&=!%{}/#@`)
 - No whitespace characters
5. Confirm the new password by entering it again.

Results

The following is output when the administration password is successfully changed:

```
New password for 'admin':
{
  "id" : 2,
  "user" : "admin",
  "enabled" : true,
  "userExpiry" : "permanent",
  "roles" : [ {
```

```
    "id" : 6,  
    "role" : "ROLE_DROPCLIENT"  
  }, {  
    "id" : 3,  
    "role" : "ROLE_RESERVATIONS"  
  }, {  
    "id" : 7,  
    "role" : "ROLE_ADMIN"  
  }, {  
    "id" : 4,  
    "role" : "ROLE_READ"  
  } ]  
}
```

3.10 Monitoring the license server

Log files for the Arm user-based licensing license server are stored in the <data_directory>/logs directory, where <data_directory> is the data directory set up when the license server was installed. If no data directory was specified during installation, the logs are stored in /var/opt/flexnetls-armlmd/logs.

4. Obsoleting the license server

Describes how to obsolete the Arm® user-based licensing license server so that the Arm product licenses are made available for use on another server.

4.1 Obsolete a license server

When the license server is no longer required, you must delete the licenses on the license server device and in the Arm® user-based licensing portal. This process ensures that the Arm product licenses become available for other servers.

Before you begin

- The license server must be running.
- If your Arm users accessing the license server to be deleted still need to use Arm products, you must set up an alternative license server. For details see [Install your license server](#).

Procedure

1. Review the licenses on the license server. For further details, see [List licenses and usage](#).
2. Remove all Arm product licenses from the license server, including uploading confirmation files into Arm user-based licensing portal for all products on your server.
For further details, see [Modify number of licenses](#).
3. In the licensing portal, delete the license server as follows:
 - a) At the top level, click **Manage License Servers**.
 - b) In the list of servers on this page, click **Manage Server** on the server to obsolete.
 - c) Click **Obsolete Server** to remove the server from the Arm user-based licensing portal.

4. Stop the license server service with the following command:

```
sudo systemctl stop flexnetls-armlmd
```

5. Stop the license server service being restarted when your server device is rebooted with the following command:

```
sudo systemctl disable flexnetls-armlmd
```

6. Remove the license server files using the following commands:

```
sudo rm /etc/systemd/system/flexnetls-armlmd.service
sudo rm -r /etc/systemd/system/flexnetls-armlmd.service.d
sudo rm -r <data_directory>
sudo rm -r <installation_directory>
```

Where:

- <installation_directory> is the installation directory. If not specified during installation, this directory defaults to /opt/flexnetls-armlmd.
- <data_directory> is the directory used to store the license server state and log files. If not specified during installation, this directory defaults to /var/opt/flexnetls-armlmd.