





TROUBLE DIAGNOSIS

TROUBLE DIAGNOSIS

Wiring Diagram —A/C— CR Engine Models




ATC-A/C-01



REFER TO THE FOLLOWING.

(M16) - FUSE BLOCK-
JUNCTION BOX (J/B)

ATC-A/C-02



REFER TO THE FOLLOWING.




(M1), (F1) -SUPER

MULTIPLE JUNCTION (SMJ)

(E49), (F2) -ELECTRICAL UNITS

TROUBLE DIAGNOSIS

ATC-A/C-03



REFER TO THE FOLLOWING.



(M16) -FUSE BLOCK-
JUNCTION BOX (J/B)

TROUBLE DIAGNOSIS

ATC-A/C-04

— : DATA LINE

REFER TO PG-POWER.







REFER TO THE FOLLOWING.

(M1), (F1) -SUPER
MULTIPLE JUNCTION (SMJ)
(M48), (M49)
-ELECTRICAL UNITS

TROUBLE DIAGNOSIS

Wiring Diagram —A/C— K9K Engine Models



ATC-A/C-05



REFER TO THE FOLLOWING.

(M16) -FUSE BLOCK-
JUNCTION BOX (J/B)

ATC-A/C-06



REFER TO THE FOLLOWING.




(M1), (F101) -SUPER

MULTIPLE JUNCTION (SMJ)

(E61), (F134) -ELECTRICAL UNITS

TROUBLE DIAGNOSIS

ATC-A/C-07



REFER TO THE FOLLOWING.



(M16) -FUSE BLOCK-JUNCTION BOX (J/B)

TROUBLE DIAGNOSIS

ATC-A/C-08


— : DATA LINE

REFER TO PG-POWER.



REFER TO THE FOLLOWING.

(M1), (F101) -SUPER
MULTIPLE JUNCTION (SMJ)
(M48), (M49)
-ELECTRICAL UNITS



TROUBLE DIAGNOSIS

Ambient Sensor System

1. CHECK POWER SUPPLY CIRCUIT

To ESM


Disconnect ambient sensor connector, turn ignition switch ON, and check voltage between the terminal 1 and ground.

| Connector terminal | | Voltage |
|--------------------|--------|------------|
| Ambient sensor | Ground | Approx. 5V |
| 1 | | |

OK or NG

OK >> GO TO 2.

NG >> GO TO 4.



2. CHECK CIRCUIT CONTINUITY


1. Disconnect the A/C auto amp. connector.
2. Check continuity between ambient sensor terminal 2 and A/C auto amp. terminal 6.

| Connector terminal | | Continuity |
|--------------------|---------------|------------|
| Ambient sensor | A/C auto amp. | Yes |
| 2 | 6 | |

Does continuity exist?

YES >> GO TO 3.

NO >> Repair harness or connector.



3. CHECK AMBIENT SENSOR

Check resistance between terminals 1 and 2 on ambient sensor.


OK or NG

OK >> 1. Replace A/C auto amp.

2. Perform self-diagnosis step 2. Make sure result is normal. Refer to ATC-33, "Self-Diagnosis Function" on ESM.

NG >> 1. Replace ambient sensor.

2. Perform self-diagnosis step 2. Make sure result is normal. Refer to ATC-33, "Self-Diagnosis Function" on ESM.



TROUBLE DIAGNOSIS

4. CHECK CIRCUIT CONTINUITY

1. Disconnect the A/C auto amp. connector.
2. Check continuity between ambient sensor terminal 1 and A/C auto amp. terminal 4.

| Connector terminal | | Continuity |
|--------------------|---------------|------------|
| Ambient sensor | A/C auto amp. | Yes |
| 1 | 4 | |

3. Check continuity between ambient sensor terminal 1 and ground.

| Connector terminal | | Continuity |
|--------------------|--------|------------|
| Ambient sensor | Ground | None |
| 1 | | |

OK or NG

OK >> 1. Replace A/C auto amp.

2. Perform self-diagnosis step 2. Make sure result is normal. Refer to ATC-33, "Self-Diagnosis Function" on ESM.

NG >> Repair harness or connector.

Blower Motor System

To ESM

Symptom: Operation malfunction of blower motor

1. CHECK POWER SUPPLY CIRCUIT (BLOWER MOTOR)

Turn ignition switch ON, and check voltage between blower motor terminal 2 and ground.

| Connector terminal | | Voltage |
|--------------------|--------|-----------------|
| Blower motor | Ground | Battery voltage |
| 2 | | |

OK or NG

OK >> GO TO 2.

NG >> Check power supply circuit and 15A fuses [Nos. 9 and 10, located in the fuse block (J/B)]. Refer to PG-4, "POWER SUPPLY ROUTING" on ESM.

- If OK, check for open circuit in wiring harness. Repair or replace as necessary.
- If NG, replace fuse and check wiring harness for short circuit. Repair or replace as necessary.

2. CHECK POWER SUPPLY CIRCUIT (A/C AUTO AMP.)




1. Disconnect A/C auto amp. connector.
2. Turn ignition switch ON, and check voltage between A/C auto amp. terminal 8 and ground.

| Connector terminal | | Voltage |
|--------------------|--------|-----------------|
| A/C auto amp. | Ground | Battery voltage |
| 8 | | |

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



TROUBLE DIAGNOSIS

3. CHECK POWER SUPPLY CIRCUIT (FAN CONTROL AMP.)


1. Disconnect the fan control amp. connector.
2. Turn ignition switch ON, and check voltage between fan control amp. terminal 1, 5 and ground.

| Connector terminal | | Voltage |
|--------------------|--------|-----------------|
| Fan control amp. | Ground | Battery voltage |
| 1 | | |
| 5 | | |

OK or NG

OK >> GO TO 4.

- NG >> ● Between terminal 1 and ground: Repair the harness or connector.
- Between terminal 5 and ground: GO TO 7.



4. CHECK BLOWER MOTOR FEEDBACK SIGNAL


Turn ignition switch ON, and check voltage between A/C auto amp. terminal 9 and ground.

| Connector terminal | | Voltage |
|--------------------|--------|-------------|
| A/C auto amp. | Ground | Approx. 12V |
| 9 | | |

OK or NG

OK >> GO TO 5.

NG >> GO TO 9.



5. CHECK GROUND CIRCUIT


Check continuity between fan control amp. terminal 2 and ground.

| Connector terminal | | Continuity |
|--------------------|--------|------------|
| Fan control amp. | Ground | Yes |
| 2 | | |

Does continuity exist?

YES >> GO TO 6.





NO >> Repair harness or connector.



TROUBLE DIAGNOSIS

6. CHECK 1: FAN CONTROL AMP. CONTROL SIGNAL

Check waveform between fan control amp. terminal 3 and ground.

| Fan speed | First | Second | Third | Fourth |
|------------------------------|---|---|--|---|
| Terminal 3 (Oscilloscope) |  |  |  |  |
| | T1: Approx. 0.37 ms Duty ratio: Approx. 27% | T2: Approx. 0.29 ms Duty ratio: Approx. 42% | T3: Approx. 0.19 ms Duty ratio: Approx. 62% | T4: Approx. 0.04 ms Duty ratio: Approx. 92% |

NOTE: Duty ratio = $\frac{\text{Approx. 0.5 ms} - T_x}{\text{Approx. 0.5 ms}} \times 100 (\%)$

MJIA0103E

OK or NG

- OK >> Replace the fan control amp.
 NG >> ● Fan speed is stuck at speed 4: GO TO 11.
 ● Fan speed is stuck at speed 1: GO TO 12.


7. CHECK BLOWER MOTOR

- Remove the blower motor.
- Check continuity between blower motor terminal 1 and terminal 2.

| Connector terminal | | Continuity |
|--------------------|---|------------|
| Blower motor | | Yes |
| 1 | 2 | |

Does continuity exist?

- YES >> GO TO 8.
 NO >> Replace the blower motor.




8. CHECK CIRCUIT CONTINUITY

- Disconnect the blower motor and fan control amp. connectors.
- Check continuity between the blower motor terminal 1 and fan control amp. terminal 5.

| Connector terminal | | Continuity |
|--------------------|------------------|------------|
| Blower motor | Fan control amp. | Yes |
| 1 | 5 | |

Does continuity exist?

- YES >> End of trouble diagnosis
 NO >> Repair harness or connector.



TROUBLE DIAGNOSIS

9. CHECK CIRCUIT CONTINUITY


1. Disconnect the fan control amp. and A/C auto amp. connectors.
2. Check continuity between fan control amp. terminal 4 and A/C auto amp. terminal 9.

| Connector terminal | | Continuity |
|--------------------|---------------|------------|
| Fan control amp. | A/C auto amp. | |
| 4 | 9 | Yes |

Does continuity exist?

YES >> GO TO 10.

NO >> Repair harness or connector.



10. CHECK FAN CONTROL AMP.


Check continuity between fan control amp. terminals 4 and 5.

| Connector terminal | | Continuity |
|--------------------|---|------------|
| Fan control amp. | | |
| 4 | 5 | Yes |

Does continuity exist?

YES >> End of trouble diagnosis

NO >> Replace the fan control amp.



11. CHECK CIRCUIT CONTINUITY


1. Disconnect the fan control amp. and A/C auto amp. connectors.
2. Check continuity between fan control amp. terminal 3 and A/C auto amp. terminal 10.

| Connector terminal | | Continuity |
|--------------------|---------------|------------|
| Fan control amp. | A/C auto amp. | |
| 3 | 10 | Yes |

Does continuity exist?

YES >> Replace the fan control amp.

NO >> Repair harness or connector.



12. CHECK 2: FAN CONTROL AMP. CONTROL SIGNAL

1. Disconnect the A/C auto amp. connector.
2. Turn ignition switch ON, and check voltage between A/C auto amp. terminal 10 and ground.

| Connector terminal | | Condition | Voltage |
|--------------------|--------|-------------------------------------|-----------------|
| A/C auto amp. | Ground | Fan speed : Speed 1 through Speed 3 | Battery voltage |
| 10 | | | |

OK or NG

OK >> Replace A/C auto amp.

NG >> Replace the fan control amp.

