

SECTION **IDX**
ALPHABETICAL INDEX

A
B
C
D
E
F
G
H
I
J
K
L

ALPHABETICAL INDEX

A

A/C - Wiring diagram [MTC-24](#), [MTC-26](#), [MTC-28](#)
 A/C component layout [MTC-65](#)
 A/C compressor clutch removal and installation [MTC-69](#)
 A/C compressor precaution [ATC-7](#), [MTC-6](#)
 A/C compressor special service tool [MTC-10](#)
 A/C HFC134a (R134a) system precaution [ATC-4](#), [MTC-3](#)
 A/C HFC134a (R134a) system service tools .. [MTC-10](#)
 A/C HFC134a system service equipment precaution ... [ATC-8](#), [MTC-7](#)
 A/C lubricant (R134a) [ATC-102](#), [MTC-82](#)
 A/C service data specification [ATC-102](#), [MTC-82](#)
 A/C trouble diagnoses (manual A/C) [MTC-17](#)
 A/C, M - Wiring diagram ... [MTC-24](#), [MTC-26](#), [MTC-28](#)
 A/T fluid checking [AT-18](#), [MA-67](#)
 A/T fluid replacement [AT-19](#), [MA-67](#)
 A/T fluid temperature sensor [AT-119](#)
 A/T shift control system [AT-334](#)
 A/T shift lock system [AT-340](#)
 A/T shift lock system - Wiring diagram [AT-341](#)
 A/T trouble diagnoses [AT-46](#)
 A/T Wiring diagram AT - BA/FTS [AT-186](#), [AT-241](#)
 A/T Wiring diagram AT - CAN [AT-108](#), [AT-263](#)
 A/T Wiring diagram AT - ENG SS [AT-127](#), [AT-247](#)
 A/T Wiring diagram AT - FTS [AT-116](#)
 A/T Wiring diagram AT - LPSV [AT-159](#), [AT-257](#)
 A/T Wiring diagram AT - MAIN [AT-199](#), [AT-266](#)
 A/T Wiring diagram AT - NONDTC [AT-299](#)
 A/T Wiring diagram AT - OVRCSV [AT-177](#), [AT-231](#)
 A/T Wiring diagram AT - PNP/SW [AT-111](#)
 A/T Wiring diagram AT - PT/SEN [AT-192](#), [AT-251](#)
 A/T Wiring diagram AT - SSV/A [AT-165](#), [AT-221](#)
 A/T Wiring diagram AT - SSV/B [AT-170](#), [AT-226](#)
 A/T Wiring diagram AT - TCV [AT-148](#), [AT-236](#)
 A/T Wiring diagram AT - VSS A/T [AT-122](#), [AT-210](#)
 A/T Wiring diagram AT - VSSMTR [AT-182](#), [AT-215](#)
 A/WIP - Wiring diagram [WW-68](#)
 ABS - Wiring diagram [BRC-13](#), [BRC-17](#)
 ABS input/output signal inspection [BRC-21](#)
 ABS sensor rotor [RAX-5](#)
 Accelerator pedal position (APP) sensor [EC-380](#), [EC-389](#), [EC-405](#), [EC-696](#), [EC-705](#), [EC-721](#), [EC-1172](#), [EC-1181](#), [EC-1197](#), [EC-1495](#), [EC-1504](#), [EC-1519](#)
 Accelerator pedal released position learning [EC-49](#), [EC-479](#), [EC-858](#), [EC-1283](#)
 Air bag [SRS-3](#), [SRS-37](#), [SRS-41](#), [SRS-42](#), [SRS-44](#)
 Air bag disposal [SRS-50](#)
 Air bleeding (hydraulic clutch) [CL-9](#)
 Air bleeding for brake system [BR-10](#)
 Air cleaner and air duct [EM-119](#), [EM-247](#)
 Air cleaner filter [EM-120](#), [EM-249](#)
 Air cleaner filter replacement(CR) [MA-45](#)
 Air cleaner filter replacement(HR) [MA-55](#)
 Air cleaner filter replacement(K9K) [MA-63](#)
 Air conditioner - Wiring diagram [MTC-24](#), [MTC-26](#), [MTC-28](#)

Air conditioner cut control [EC-36](#), [EC-467](#), [EC-819](#), [EC-1256](#)
 Air flow meter - See Mass air flow sensor [EC-935](#), [EC-1359](#)
 Air mix door control linkage adjustment [MTC-58](#)
 Alternator [SC-16](#)
 Angular tightening application [EM-106](#), [EM-227](#)
 Antenna [AV-18](#)
 AP/SEN - Wiring diagram .. [EC-152](#), [EC-335](#), [EC-554](#), [EC-653](#)
 APPS1 - Wiring diagram .. [EC-382](#), [EC-698](#), [EC-1174](#), [EC-1497](#)
 APPS2 - Wiring diagram .. [EC-391](#), [EC-707](#), [EC-1183](#), [EC-1506](#)
 APPS3 - Wiring diagram .. [EC-407](#), [EC-723](#), [EC-1199](#), [EC-1521](#)
 Audio [AV-4](#)
 AUDIO - Wiring diagram [AV-5](#), [AV-9](#)
 Auto wiper [WW-51](#)
 Autolamp [LT-72](#)
 Automatic transaxle number [GI-50](#)
 Automatic transmission fluid replacement [MA-67](#)
 Axle [MA-70](#)

B

Back door trim [EI-22](#)
 Back door window [GW-12](#)
 Back window [GW-12](#)
 BACK/L - Wiring diagram [LT-205](#)
 Back-up lamp [LT-205](#), [LT-208](#)
 Basic inspection [EC-83](#), [EC-497](#), [EC-852](#), [EC-1277](#)
 Battery [SC-6](#)
 BCM (Body control module) [BCS-3](#)
 Blower motor [MTC-32](#), [MTC-53](#)
 Blower resistor [MTC-54](#)
 Board computer [DI-38](#)
 Board-on lift [GI-40](#)
 Bose speaker amp. [AV-4](#)
 Brake booster [BR-17](#)
 Brake fluid change [BR-9](#)
 Brake fluid level [MA-68](#)
 Brake fluid level and line check [BR-9](#)
 Brake hydraulic line [BR-11](#)
 Brake inspection [MA-69](#)
 Brake lines and cables inspection [MA-68](#)
 Brake master cylinder [BR-14](#)
 Brake pedal [BR-6](#)
 Brake switch [EC-374](#), [EC-690](#), [EC-1167](#), [EC-1490](#)
 BRK/SW - Wiring diagram [EC-376](#), [EC-692](#), [EC-1168](#), [EC-1491](#)
 Bulb specifications [LT-280](#)
 Bumper, front [EI-5](#)
 Bumper, rear [EI-8](#)

C

Camshaft [EM-152](#)
 Camshaft inspection [EM-158](#), [EM-328](#)

ALPHABETICAL INDEX

Camshaft position sensor (PHASE) . [EC-254](#), [EC-611](#), [EC-1050](#), [EC-1417](#)

CAN - Wiring diagram [EC-133](#), [EC-546](#), [EC-927](#), [EC-1350](#), [LAN-21](#), [LAN-52](#), [LAN-81](#), [LAN-110](#), [LAN-137](#), [LAN-166](#), [LAN-193](#), [LAN-224](#), [LAN-253](#), [LAN-282](#), [LAN-309](#), [LAN-338](#), [LAN-365](#), [LAN-394](#)

CAN (Controller Area Network) [AT-39](#), [BRC-55](#), [WW-113](#), [LAN-7](#), [LAN-20](#), [LAN-51](#), [LAN-80](#), [LAN-109](#), [LAN-136](#), [LAN-165](#), [LAN-192](#), [LAN-223](#), [LAN-252](#), [LAN-281](#), [LAN-308](#), [LAN-337](#), [LAN-364](#), [LAN-393](#)

CAN communication [EC-38](#), [EC-132](#), [EC-469](#), [EC-545](#), [EC-820](#), [EC-926](#), [EC-929](#), [EC-1257](#), [EC-1349](#), [EC-1352](#), [AT-39](#), [AT-107](#), [BRC-55](#), [WW-113](#), [LAN-7](#), [LAN-20](#), [LAN-51](#), [LAN-80](#), [LAN-109](#), [LAN-136](#), [LAN-165](#), [LAN-192](#), [LAN-223](#), [LAN-252](#), [LAN-281](#), [LAN-308](#), [LAN-337](#), [LAN-364](#), [LAN-393](#)

Canister-See EVAP canister [EC-447](#), [EC-799](#), [EC-828](#), [EC-1265](#)

CD/CHG - Wiring diagram [AV-5](#), [AV-9](#)

CHARGE - Wiring diagram [SC-17](#), [SC-18](#), [SC-19](#)

Charging system [SC-16](#)

Chassis and body maintenance [MA-66](#)

CIGAR - Wiring diagram [WW-136](#)

Circuit breaker [PG-18](#)

Closed loop control [EC-34](#), [EC-465](#), [EC-816](#), [EC-1253](#)

Clutch cover [CL-12](#), [CL-13](#)

Clutch disc [CL-12](#)

Clutch master cylinder [CL-10](#)

Clutch pedal [CL-6](#)

Coil spring (front) [FSU-8](#)

Coil spring (rear) [RSU-9](#)

Collision diagnosis [SRS-57](#)

Combination switch [LT-210](#)

COMBSW - Wiring diagram [LT-215](#)

COMM - Wiring diagram [DI-55](#)

Component Location (manual A/C) [MTC-20](#)

Compression pressure [EM-174](#)

Compressor clutch removal and installation ... [MTC-69](#)

Compressor precaution [ATC-7](#), [MTC-6](#)

Compressor special service tool [MTC-10](#)

Condenser [MTC-74](#)

Connecting rod [EM-208](#), [EM-330](#)

Connecting rod bearing clearance [EM-211](#)

Connecting rod bushing clearance [EM-208](#)

CONSULT for ABS [BRC-22](#)

CONSULT for engine [EC-104](#), [EC-518](#)

CONSULT for VDC [BRC-74](#)

CONSULT general information [GI-34](#)

CONSULT-II for engine [EC-891](#), [EC-1316](#)

Control unit [MTC-46](#)

Control units (terminal arrangement) [PG-122](#)

Controller Area Network (CAN) [AT-39](#), [BRC-55](#), [WW-113](#), [LAN-7](#), [LAN-20](#), [LAN-51](#), [LAN-80](#), [LAN-109](#), [LAN-136](#), [LAN-165](#), [LAN-192](#), [LAN-223](#), [LAN-252](#), [LAN-281](#), [LAN-308](#), [LAN-337](#), [LAN-364](#), [LAN-393](#)

Converter housing installation [AT-359](#), [AT-466](#)

COOL/F - Wiring diagram . [EC-345](#), [EC-662](#), [EC-1139](#), [EC-1462](#)

Coolant mixture ratio [MA-37](#)

Coolant replacement [MA-60](#)

Cooling circuit (engine) [CO-8](#), [CO-33](#)

Cooling fan [CO-16](#), [CO-41](#), [CO-66](#)

Cooling fan motor [EC-355](#), [EC-672](#), [EC-1134](#), [EC-1149](#), [EC-1457](#), [EC-1472](#)

Cooling fan relay [EC-1134](#), [EC-1457](#)

Cowl top [EI-13](#)

Crankcase ventilation system - See Positive crankcase ventilation [EC-448](#), [EC-800](#), [EC-830](#), [EC-1267](#)

Crankshaft [EM-190](#), [EM-211](#), [EM-331](#)

Crankshaft position sensor (POS) [EC-248](#), [EC-604](#), [EC-1042](#), [EC-1409](#)

Cylinder block [EM-190](#), [EM-332](#)

Cylinder head [EM-174](#), [EM-179](#), [EM-277](#)

Cylinder head bolt tightening [EM-177](#), [EM-278](#), [EM-324](#)

D

Data link connector [EC-442](#), [EC-794](#), [EC-893](#), [EC-901](#), [EC-1317](#)

Data link connector for Consult [EC-106](#), [EC-520](#)

Daytime light system [LT-42](#)

Diagnosis sensor unit [SRS-49](#)

Diagnostic trouble code (DTC) for OBD system [EC-19](#), [EC-57](#), [EC-452](#), [EC-484](#), [EC-804](#), [EC-834](#), [EC-1241](#), [EC-1270](#)

Diagnostic trouble code (DTC) inspection priority chart [EC-80](#), [EC-495](#), [EC-870](#), [EC-1295](#)

Dimensions [GI-50](#)

Door glass ... [GW-6](#), [GW-74](#), [GW-77](#), [GW-88](#), [GW-170](#)

Door mirror [GW-80](#), [GW-177](#)

Door trim [EI-20](#)

Drive belt [EM-115](#), [EM-244](#)

Drive belt inspection [MA-60](#)

Drive computer [DI-38](#), [DI-55](#)

Drive shaft (front) [FAX-10](#)

Driver air bag [SRS-37](#)

Dropping resistor (A/T) [AT-163](#), [AT-261](#)

DTC work support [EC-112](#), [EC-899](#)

DTRL - Wiring diagram [LT-58](#)

Duct and grilles [MTC-60](#)

E

ECM input/output signal [EC-97](#), [EC-511](#), [EC-884](#), [EC-903](#), [EC-1309](#), [EC-1326](#)

ECM power supply [EC-126](#), [EC-276](#), [EC-539](#), [EC-621](#), [EC-919](#), [EC-1342](#)

ECM/PW - Wiring diagram [EC-277](#), [EC-622](#)

ECTS - Wiring diagram [EC-164](#), [EC-561](#), [EC-949](#), [EC-1368](#)

Electric throttle control actuator [EC-285](#), [EC-287](#), [EC-299](#), [EC-631](#), [EC-634](#), [EC-646](#), [EC-1082](#), [EC-1084](#), [EC-1434](#), [EC-1437](#)

Electrical diagnoses [GI-10](#)

Electrical load signal circuit [EC-441](#), [EC-793](#), [EC-1207](#), [EC-1529](#)

Electrical unit [PG-122](#)

Electrical units location [PG-114](#)

ALPHABETICAL INDEX

Electronic ignition (EI) system [EC-35](#), [EC-466](#), [EC-817](#), [EC-1254](#)
Engine control circuit diagram [EC-95](#), [EC-509](#), [EC-882](#), [EC-1307](#)
Engine control component parts location [EC-90](#), [EC-504](#), [EC-876](#), [EC-1301](#)
Engine control module (ECM) [EC-273](#), [EC-618](#), [EC-929](#), [EC-1072](#), [EC-1075](#), [EC-1352](#), [EC-1424](#), [EC-1427](#)
Engine control system diagram [EC-814](#), [EC-1251](#)
Engine control system diagram and chart [EC-31](#), [EC-462](#)
Engine coolant [CO-9](#), [CO-34](#), [CO-61](#)
Engine coolant temperature sensor (ECTS) ... [EC-162](#), [EC-559](#), [EC-947](#), [EC-1366](#)
Engine fail-safe system [EC-81](#), [EC-496](#), [EC-871](#), [EC-1296](#)
Engine oil [LU-6](#), [LU-16](#), [LU-24](#)
Engine oil filter replacement(CR) [MA-46](#)
Engine oil filter replacement(HR) [MA-57](#)
Engine oil filter replacement(K9K) [MA-65](#)
Engine oil precautions [GI-7](#)
Engine oil replacement(CR) [MA-45](#)
Engine oil replacement(HR) [MA-56](#)
Engine oil replacement(K9K) [MA-64](#)
Engine removal [EM-185](#), [EM-280](#)
Engine room cover [EM-122](#), [EM-241](#)
Engine serial number [GI-49](#)
ETC1 - Wiring diagram [EC-288](#), [EC-635](#), [EC-1085](#), [EC-1438](#)
ETC2 - Wiring diagram [EC-295](#), [EC-642](#), [EC-1093](#), [EC-1446](#)
ETC3 - Wiring diagram [EC-300](#), [EC-647](#), [EC-1098](#), [EC-1451](#)
EVAP canister [EC-447](#), [EC-799](#), [EC-828](#), [EC-1265](#)
EVAP canister purge volume control solenoid valve [EC-264](#), [EC-444](#), [EC-769](#), [EC-796](#), [EC-1063](#), [EC-1531](#)
EVAP vapor lines inspection(CR) [MA-48](#)
EVAP vapor lines inspection(HR) [MA-59](#)
Evaporative emission (EVAP) system [EC-444](#), [EC-796](#), [EC-825](#), [EC-1262](#)
Evaporator [MTC-76](#)
Exhaust manifold [EM-125](#), [EM-258](#)
Exhaust system inspection [EX-4](#), [MA-66](#)
Expansion valve [MTC-78](#)

F

F/FOG - Wiring diagram [LT-112](#)
F/PUMP - Wiring diagram [EC-432](#), [EC-784](#), [EC-1216](#), [EC-1545](#)
Floor trim [EI-30](#)
Flow charts [GI-24](#)
Fluid temperature sensor (A/T) [AT-119](#)
Fluids [MA-35](#)
Fluorescent leak detector [MTC-79](#)
Flywheel (clutch) [CL-14](#)
Flywheel runout [EM-214](#)
Freeze frame data . [EC-58](#), [EC-485](#), [EC-835](#), [EC-894](#),

[EC-1271](#), [EC-1319](#)
FRO2 - Wiring diagram [EC-732](#), [EC-747](#), [EC-1551](#), [EC-1560](#)
Front axle [FAX-6](#)
Front bumper [EI-5](#)
Front disc brake [BR-21](#)
Front fog lamp [LT-98](#)
Front passenger air bag [SRS-41](#)
Front seat [SE-9](#)
Front seat belt [SB-3](#), [SB-5](#)
Front seat belt pre-tensioner [SB-2](#), [SB-3](#), [SB-5](#), [SRS-3](#)
Front side air bag [SRS-42](#)
Front suspension [FSU-5](#)
Front washer [WW-6](#), [WW-51](#)
Front wiper [WW-6](#), [WW-51](#)
FUEL - Wiring diagram [EC-219](#), [EC-227](#), [EC-1014](#), [EC-1021](#)
Fuel check valve [EC-444](#), [EC-796](#)
Fuel cut control (at no load high engine speed) [EC-37](#), [EC-468](#), [EC-818](#), [EC-1255](#)
Fuel filter replacement [FL-24](#)
Fuel gauge [FL-27](#)
Fuel injection system [EC-217](#), [EC-225](#), [EC-1012](#), [EC-1019](#)
Fuel injector [EC-1209](#), [EC-1538](#)
Fuel injector and fuel tube [EM-136](#)
Fuel line inspection [FL-3](#), [FL-13](#)
Fuel line inspection(CR) [MA-44](#)
Fuel line inspection(HR) [MA-55](#)
Fuel line inspection(K9K) [MA-63](#)
Fuel precautions [GI-5](#)
Fuel pressure check [EC-51](#), [EC-482](#), [EC-861](#), [EC-1286](#)
Fuel pressure release [EC-51](#), [EC-482](#), [EC-861](#), [EC-1286](#)
Fuel pump [EC-431](#), [EC-783](#), [EC-1215](#), [EC-1544](#)
Fuel pump and gauge [FL-4](#), [FL-14](#)
Fuel system [FL-3](#), [FL-13](#), [FL-23](#)
Fuel tank [FL-8](#), [FL-18](#), [FL-29](#)
Fuel tank vacuum relief valve [EC-828](#), [EC-1265](#)
Fuse [PG-18](#)
Fuse and fusible link box [PG-128](#)
Fusible link [PG-18](#)

G

Garage jack and safety stand [GI-38](#)
Generator [SC-16](#)
Generator - See Alternator [SC-16](#)
Generic scan tool (GST) [EC-114](#), [EC-901](#)
Glow plug [EM-268](#)
Grease [MA-35](#)
Grille - See Exterior [EI-11](#)
Ground distribution [PG-55](#)

H

H/AIM - Wiring diagram [LT-95](#)
H/LAMP - Wiring diagram [LT-22](#)
Harness connector [PG-119](#)

ALPHABETICAL INDEX

Harness layout [PG-70](#)
Hazard warning lamp [LT-141](#), [LT-211](#)
Headlamp [LT-7](#)
Headlamp aiming control [LT-95](#)
Headlamp washer [WW-112](#)
Headlining - See Roof trim [EI-33](#)
Heated oxygen sensor 1 [EC-175](#), [EC-183](#), [EC-193](#),
[EC-304](#), [EC-310](#), [EC-572](#), [EC-579](#), [EC-746](#), [EC-958](#),
[EC-965](#), [EC-975](#), [EC-1102](#), [EC-1108](#), [EC-1377](#),
[EC-1385](#), [EC-1550](#)
Heated oxygen sensor 1 heater [EC-139](#), [EC-731](#),
[EC-983](#), [EC-1559](#)
Heated oxygen sensor 2 [EC-201](#), [EC-208](#), [EC-316](#),
[EC-325](#), [EC-586](#), [EC-753](#), [EC-989](#), [EC-996](#), [EC-1114](#),
[EC-1123](#), [EC-1392](#), [EC-1565](#)
Heated oxygen sensor 2 heater [EC-145](#), [EC-736](#),
[EC-1005](#), [EC-1571](#)
Heated seat [SE-4](#)
HEATER - Wiring diagram [MTC-23](#)
Heater system - Wiring diagram [MTC-23](#)
Heater unit (heater core) [MTC-52](#)
Height (Dimensions) [GI-50](#)
HFC134a (R134a) system precaution .. [ATC-4](#), [MTC-3](#)
HFC134a (R134a) system service procedure [MTC-64](#)
HFC134a (R134a) system service tools [MTC-10](#)
HFC134a system service equipment precaution
[ATC-8](#), [MTC-7](#)
HLC - Wiring diagram [WW-126](#), [WW-134](#)
HO2S1 - Wiring diagram [EC-177](#), [EC-186](#), [EC-196](#),
[EC-574](#), [EC-581](#), [EC-960](#), [EC-968](#), [EC-978](#), [EC-1379](#),
[EC-1387](#)
HO2S1H - Wiring diagram [EC-141](#), [EC-985](#)
HO2S2 - Wiring diagram [EC-203](#), [EC-211](#), [EC-319](#),
[EC-328](#), [EC-588](#), [EC-991](#), [EC-999](#), [EC-1117](#), [EC-1126](#),
[EC-1394](#)
HO2S2H - Wiring diagram [EC-147](#), [EC-1007](#)
Horn [WW-134](#)
HORN - Wiring diagram [WW-134](#)
How to erase DTC for OBD system [EC-66](#), [EC-486](#),
[EC-842](#), [EC-1272](#)
HSEAT - Wiring diagram [SE-5](#)

I

IATS - Wiring diagram [EC-159](#), [EC-944](#)
IATSEN - Wiring diagram [EC-742](#), [EC-1578](#)
Identification [ATC-10](#), [MTC-9](#)
Identification plate [GI-48](#)
Idle air volume learning [EC-49](#), [EC-479](#), [EC-859](#),
[EC-1284](#)
Idle speed [EC-83](#), [EC-497](#), [EC-852](#), [EC-857](#), [EC-1277](#),
[EC-1282](#)
Ignition coil [EM-133](#), [EC-415](#), [EC-759](#), [EC-1221](#),
[EC-1582](#)
Ignition control system [EC-415](#), [EC-759](#), [EC-1221](#),
[EC-1582](#)
Ignition timing [EC-83](#), [EC-497](#), [EC-852](#), [EC-857](#),
[EC-1277](#), [EC-1282](#)
IGNSYS - Wiring diagram . [EC-416](#), [EC-760](#), [EC-1222](#),

[EC-1583](#)
ILL - Wiring diagram [LT-272](#)
Illumination [LT-256](#)
INJECT - Wiring diagram . [EC-426](#), [EC-778](#), [EC-1210](#),
[EC-1539](#)
Injector [EC-425](#), [EC-777](#), [EC-1209](#), [EC-1538](#)
INT/L - Wiring diagram [LT-239](#)
Intake air system [EC-334](#), [EC-651](#)
Intake air temperature sensor [EC-157](#), [EC-741](#),
[EC-942](#), [EC-1577](#)
Intake door control linkage adjustment [MTC-56](#)
Intake manifold [EM-121](#)
Intake valve timing control . [EC-135](#), [EC-548](#), [EC-931](#),
[EC-1354](#)
Intake valve timing control solenoid valve [EC-280](#),
[EC-625](#), [EC-931](#), [EC-1077](#), [EC-1354](#), [EC-1429](#)
Interior lamp [LT-223](#)
IPDM (Intelligent power distribution module engine
room) [PG-19](#)
ISO 15031-2 Terminology [GI-51](#)
ISO 15031-5 Mode 1 - 9 [EC-54](#)
ISO 15031-5 Service \$01 - 09 [EC-832](#)
IVC - Wiring diagram [EC-281](#), [EC-627](#), [EC-1078](#),
[EC-1430](#)

K

Keyless entry system - See Multi-remote control system
[BL-154](#)
Knock sensor (KS) [EC-244](#), [EC-600](#), [EC-1038](#),
[EC-1405](#)
Knuckle spindle [FAX-6](#)
KS - Wiring diagram [EC-245](#), [EC-601](#), [EC-1039](#),
[EC-1406](#)

L

Length (Dimensions) [GI-50](#)
License lamp [LT-169](#)
Line pressure test (A/T) [AT-61](#)
Liquid gasket application [EM-107](#), [EM-228](#), [LU-3](#),
[LU-13](#), [CO-3](#), [CO-28](#)
Location of electrical units [PG-114](#)
Lubricant (R134a) A/C [ATC-5](#), [ATC-102](#), [MTC-4](#),
[MTC-15](#), [MTC-82](#)
Lubricants [MA-35](#)
Lubrication circuit (engine) [LU-5](#), [LU-15](#)
Lubrication oil A/C [ATC-102](#), [MTC-82](#)
Lubrication-locks, hinges and hood latches [MA-71](#)
Luggage compartment trim [EI-40](#)

M

MAFS - Wiring diagram [EC-937](#), [EC-1361](#)
Magnet clutch [MTC-34](#)
MAIN - Wiring diagram [EC-126](#), [EC-539](#), [EC-919](#),
[EC-1342](#)
Malfunction indicator (MI) [EC-67](#), [EC-487](#), [EC-843](#),
[EC-1273](#)

ALPHABETICAL INDEX

Manifold absolute pressure (MAP) sensor [EC-151](#), [EC-553](#)
 Manual air conditioner - Wiring diagram [MTC-24](#), [MTC-26](#), [MTC-28](#)
 Mass air flow sensor (MAFS) [EC-935](#), [EC-1359](#)
 Master cylinder (brake) [BR-14](#)
 MI & data link connectors circuit [EC-1237](#), [EC-1599](#)
 MI/DL - Wiring diagram [EC-1237](#), [EC-1599](#)
 MIL/DL - Wiring diagram [EC-442](#), [EC-794](#)
 Mirror, door [GW-80](#), [GW-177](#)
 Mirror, out side [GW-80](#), [GW-177](#)
 Misfire [EC-239](#), [EC-1032](#)
 Mode door control linkage adjustment [MTC-57](#)
 Model variation [GI-44](#)
 Molding - See Exterior . [RF-163](#), [RF-170](#), [EI-15](#), [EI-16](#), [EI-18](#)
 Multiport fuel injection (MFI) system ... [EC-33](#), [EC-464](#), [EC-815](#), [EC-1252](#)
 Multiport fuel injection precautions [GI-6](#)
 Multi-remote control system [BL-154](#)

N

NATS - Wiring diagram [BL-287](#)
 NATS (Nissan anti-theft system) precautions [GI-3](#)
 Navigation system [AV-20](#)
 NVH troubleshooting (BR) [BR-5](#), [PB-2](#)
 NVH troubleshooting (RSU) [RSU-4](#)
 NVH troubleshooting (ST) [PS-4](#)

O

Oil cooler (engine) [LU-28](#)
 Oil filter [LU-9](#), [LU-19](#), [LU-26](#)
 Oil pan (engine) [EM-128](#), [EM-265](#)
 Oil pressure (engine) [LU-6](#), [LU-16](#), [LU-24](#)
 Oil pump (engine) [LU-10](#), [LU-27](#)
 Oil seal replacement (engine) [EM-171](#)
 On board diagnostic system [EC-54](#), [EC-484](#), [EC-832](#), [EC-1269](#)
 Out side mirror [GW-80](#), [GW-177](#)
 Overdrive control switch [AT-202](#), [AT-207](#), [AT-293](#), [AT-298](#)
 Overheat [EC-341](#), [EC-658](#), [EC-1134](#), [EC-1457](#)
 Oversize piston [EM-210](#)

P

Park/Neutral position switch [EC-367](#), [EC-684](#), [EC-1161](#), [EC-1484](#)
 Park/neutral position switch (A/T) [AT-110](#), [AT-202](#), [AT-293](#)
 Parking brake control [PB-3](#)
 Parking lamp [LT-169](#)
 PCV (positive crankcase ventilation) [EC-448](#), [EC-800](#), [EC-830](#), [EC-1267](#)
 PGC/V - Wiring diagram . [EC-266](#), [EC-1065](#), [EC-1532](#)
 PHASE - Wiring diagram . [EC-255](#), [EC-613](#), [EC-1052](#), [EC-1419](#)

Piston assembly [EM-210](#), [EM-329](#)
 Piston pin inspection [EM-329](#)
 Piston ring inspection [EM-207](#), [EM-330](#)
 Piston to bore clearance [EM-210](#)
 PNP/SW - Wiring diagram [EC-369](#), [EC-685](#), [EC-1163](#), [EC-1486](#)
 POS - Wiring diagram [EC-249](#), [EC-606](#), [EC-1044](#), [EC-1411](#)
 POWER - Wiring diagram [PG-6](#)
 Power door lock [BL-16](#)
 Power socket [WW-136](#)
 Power steering gear [PS-9](#)
 Power supply routing [PG-5](#)
 Power window [GW-50](#), [GW-74](#), [GW-77](#), [GW-131](#), [GW-170](#)
 Precautions for Leak detection dye [ATC-10](#), [MTC-9](#)
 Precautions (General) [GI-4](#)
 PRGVLV - Wirng diagram [EC-770](#)

R

R/FOG - Wiring diagram [LT-135](#)
 Radiator [CO-13](#), [CO-19](#), [CO-38](#), [CO-44](#), [CO-64](#)
 Radiator fan - See Cooling fan [CO-66](#)
 Radio - See Audio [AV-4](#)
 Rain sensor [WW-51](#)
 Rear axle [RAX-5](#)
 Rear bumper [EI-8](#)
 Rear drum brake [BR-27](#)
 Rear fog lamp [LT-121](#), [LT-208](#)
 Rear seat [SE-15](#)
 Rear seat belt [SB-5](#)
 Rear side window [GW-10](#), [GW-174](#)
 Rear suspension [RSU-5](#)
 Rear washer [WW-83](#)
 Rear window defogger [GW-16](#), [GW-96](#)
 Rear wiper [WW-83](#)
 Refrigerant connection precaution [ATC-5](#), [MTC-4](#)
 Refrigerant general precaution [ATC-4](#), [MTC-3](#)
 Refrigerant lines [MTC-64](#)
 Refrigerant pressure sensor [EC-436](#), [EC-788](#), [EC-1231](#), [EC-1592](#), [MTC-73](#)
 Refrigeration cycle [ATC-14](#), [MTC-14](#)
 Removal and installation (A/T) [AT-357](#)
 Road test [AT-63](#), [AT-66](#), [AT-69](#), [AT-70](#)
 Road wheel size [GI-50](#)
 Rocker cover [EM-141](#), [EM-271](#)
 Roof trim [EI-33](#)
 RP/SEN - Wiring diagram [EC-437](#), [EC-789](#), [EC-1232](#), [EC-1593](#)
 RRO2 - Wiring diagram ... [EC-737](#), [EC-754](#), [EC-1566](#), [EC-1572](#)

S

S/LOCK - Wiring diagram [BL-35](#), [BL-42](#), [BL-100](#), [BL-107](#)
 Seat belt inspection [SB-6](#), [MA-71](#)
 Seat belt pre-tensioner [SB-3](#), [SB-5](#)

ALPHABETICAL INDEX

Seat belt pre-tensioner disposal	SRS-50
Seat belt, front	SB-3, SB-5
Seat belt, rear	SB-5
Seat, front	SE-9
Seat, rear	SE-15
Self-diagnostic results	EC-894, EC-1318
SEN/PW - Wiring diagram	EC-361, EC-678, EC-1155, EC-1478
Shift warning system	BL-259
SHIFT - Wiring diagram	AT-341
Shift lock system	AT-340
Shift schedule	AT-72, AT-475
Shock absorber (front)	FUSU-8
Shock absorber (rear)	RSU-7
Side air bag	SRS-42, SRS-44
Side air bag (satellite) sensor	SRS-47
Side curtain air bag	SRS-44
Side trim	EI-25
Side window - See Rear side window	GW-10, GW-174
SMJ (super multiple junction)	PG-124
Spare tire size	GI-50
Spark plug	EM-134
Spark plug replacement(CR)	MA-47
Spark plug replacement(HR)	MA-58
Specification value	EC-120, EC-533, EC-908, EC-1331
Spiral cable	SRS-39
SROOF - Wiring diagram	RF-8
SRS - See Supplemental Restraint System	SRS-5
SRS - Wiring diagram	SRS-11, SRS-12
SRS Trouble diagnoses	SRS-8
Stabilizer bar (front)	FUSU-11
Stall test (A/T)	AT-58
Standardized relay	PG-125
START - Wiring diagram	SC-47, SC-49
Starter	SC-46
Starting system	SC-46
Steering gear and linkage inspection	MA-70
Steering linkage	PS-9
Steering wheel and column	PS-5, PS-7
Steering wheel play	PS-5
Steering wheel turning force	PS-5
Stop lamp	LT-201, LT-208
Stop lamp switch	EC-374, EC-690, EC-1167, EC-1490
STOP/L - Wiring diagram	LT-201
Sunroof	RF-7
Super lock	BL-80
Supplemental Restraint System	SRS-5
Supplemental restraint system - Wiring diagram	SRS-11, SRS-12
Suspension	MA-70
Symbols and abbreviations	GI-10, GI-22
Symptom matrix chart	EC-86, EC-500, EC-872, EC-1297
SYSTEM	BRC-6
System readiness test (SRT) code	EC-58, EC-836
T	
Tail lamp	LT-169, LT-208
TAIL/L - Wiring diagram	LT-185
TCM inspection table	AT-85
THEFT - Wiring diagram	BL-264
Thermostat	CO-25, CO-50
Three way catalyst function	EC-260, EC-1057
Three way catalyst precautions	GI-5
Throttle control motor	EC-1084, EC-1097, EC-1437, EC-1450
Throttle control motor relay	EC-293, EC-640, EC-1084, EC-1091, EC-1437, EC-1444
Throttle position sensor (TPS)	EC-168, EC-232, EC-356, EC-358, EC-398, EC-565, EC-593, EC-673, EC-675, EC-714, EC-952, EC-1026, EC-1150, EC-1152, EC-1191, EC-1371, EC-1399, EC-1473, EC-1475, EC-1513
Throttle valve closed position learning	EC-49, EC-479, EC-858, EC-1284
Tie-rod	PS-9
Tie-rod ball joints	PS-9
Tightening torque of standard bolts	GI-43
Timing belt	EM-273
Timing chain	EM-143
Tire size	GI-50
Torque converter installation	AT-359, AT-466
Tow truck towing	GI-41
TPS1 - Wiring diagram	EC-234, EC-595, EC-1028, EC-1401
TPS2 - Wiring diagram	EC-170, EC-567, EC-954, EC-1373
TPS3 - Wiring diagram	EC-400, EC-716, EC-1193, EC-1515
Tread-FR&RR (Dimensions)	GI-50
Trouble diagnoses	GI-10
Trunk lid	BL-251
Turbocharger	EM-258
Turbocharger precautions	GI-6
TURN - Wiring diagram	LT-157
Turn signal lamp	LT-141, LT-208
Two trip detection logic	EC-54, EC-484, EC-832, EC-1269
Two-pole lift	GI-39
V	
Vacuum hose (brake system)	BR-19
Vacuum hose drawing (Engine control)	EC-32, EC-463, EC-881, EC-1306
Vacuum pump	EM-269
Valve clearance	EM-167, EM-295, EM-327
Valve guide	EM-181, EM-325
Valve lifter	EM-161
Valve seat	EM-183, EM-325
Valve spring	EM-184, EM-327
VDC -Wiring diagram	BRC-66
Vehicle identification number	GI-47
Vehicle recovery (freeing a stuck vehicle)	GI-42
Vehicle speed sensor (VSS)	EC-271, EC-776, EC-1070, EC-1598
Viscosity number (SAE)	MA-36

ALPHABETICAL INDEX

W

WARN - Wiring diagram	DI-63 , DI-69
Warning chime	DI-78
Warning lamps	DI-62
Water pump	CO-23 , CO-48 , CO-69
Wheel alignment (front)	FSU-6
Wheel alignment (rear)	RSU-6
Wheel bearing (front)	FAX-6
Wheel bearing (rear)	RAX-5
Wheel hub (front)	FAX-6
Wheel hub (rear)	RAX-5
Wheel sensor (VDC)	BRC-101
Wheel sensors (ABS)	BRC-45
Wheel size	GI-50
Wheelbase (Dimensions)	GI-50
Width (Dimensions)	GI-50
WINDOW - Wiring diagram ..	GW-54 , GW-56 , GW-145
Window antenna	AV-18
Window, back	GW-12
Window, back door	GW-12
Window, door	GW-74 , GW-77 , GW-170
Window, rear side	GW-10 , GW-174
Window, side - See Rear side window	GW-10 , GW-174
Windshield	GW-6 , GW-88
WIP/R - Wiring diagram	WW-98 , WW-101
WIPER - Wiring diagram	WW-27
Wiring Diagram (Cell code) list	PG-111
Wiring diagrams	GI-15
Wrist pin - See Piston pin inspection	EM-206