

SECTION **IDX**  
ALPHABETICAL INDEX

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L

IDX

# ALPHABETICAL INDEX

## A

A/C - Wiring diagram ..... [MTC-24](#), [MTC-26](#)  
 A/C component layout ..... [MTC-62](#)  
 A/C compressor clutch removal and installation .....  
[MTC-64](#)  
 A/C compressor precaution ..... [ATC-6](#), [MTC-6](#)  
 A/C compressor special service tool ..... [MTC-10](#)  
 A/C HFC134a (R134a) system precaution ..... [ATC-3](#),  
[MTC-3](#)  
 A/C HFC134a (R134a) system service tools .. [MTC-10](#)  
 A/C HFC134a system service equipment precaution ...  
[ATC-6](#), [MTC-6](#)  
 A/C lubricant (R134a) ..... [MTC-79](#)  
 A/C service data specification ..... [MTC-79](#)  
 A/C trouble diagnoses (manual A/C) ..... [MTC-17](#)  
 A/C, M - Wiring diagram ..... [MTC-24](#), [MTC-26](#)  
 A/T fluid checking ..... [AT-12](#), [MA-37](#)  
 A/T fluid replacement ..... [AT-12](#), [MA-37](#)  
 A/T fluid temperature sensor ..... [AT-125](#)  
 A/T shift lock system ..... [AT-418](#)  
 A/T shift lock system - Wiring diagram ..... [AT-419](#)  
 A/T trouble diagnoses ..... [AT-54](#), [AT-262](#)  
 A/T Wiring diagram AT - 1ST ..... [AT-138](#)  
 A/T Wiring diagram AT - 2ND ..... [AT-144](#)  
 A/T Wiring diagram AT - 3RD ..... [AT-150](#)  
 A/T Wiring diagram AT - 4TH ..... [AT-156](#)  
 A/T Wiring diagram AT - BA/FTS ..... [AT-198](#), [AT-397](#)  
 A/T Wiring diagram AT - CAN ..... [AT-413](#)  
 A/T Wiring diagram AT - ENG SS ..... [AT-132](#), [AT-402](#)  
 A/T Wiring diagram AT - FTS ..... [AT-122](#)  
 A/T Wiring diagram AT - LPSV ..... [AT-168](#), [AT-407](#)  
 A/T Wiring diagram AT - MAIN ..... [AT-415](#)  
 A/T Wiring diagram AT - OVRCSV .... [AT-190](#), [AT-387](#)  
 A/T Wiring diagram AT - PNP/SW ..... [AT-116](#)  
 A/T Wiring diagram AT - SSV/A ..... [AT-175](#), [AT-378](#)  
 A/T Wiring diagram AT - SSV/B ..... [AT-180](#), [AT-383](#)  
 A/T Wiring diagram AT - TCV ..... [AT-163](#), [AT-392](#)  
 A/T Wiring diagram AT - TPS ..... [AT-185](#), [AT-373](#)  
 A/T Wiring diagram AT - VSS A/T .... [AT-128](#), [AT-364](#)  
 A/T Wiring diagram AT - VSSMTR .... [AT-204](#), [AT-369](#)  
 A/WIP - Wiring diagram ..... [WW-68](#)  
 ABS - Wiring diagram ..... [BRC-13](#), [BRC-16](#)  
 ABS input/output signal inspection ..... [BRC-19](#)  
 ABS sensor rotor ..... [RAX-5](#)  
 Accelerator pedal position (APP) sensor ..... [EC-233](#),  
[EC-242](#), [EC-376](#), [EC-402](#), [EC-411](#), [EC-426](#), [EC-621](#),  
[EC-630](#), [EC-713](#), [EC-733](#), [EC-742](#), [EC-757](#)  
 Accelerator pedal released position learning .... [EC-42](#),  
[EC-503](#)  
 Air bag .... [SRS-3](#), [SRS-36](#), [SRS-40](#), [SRS-41](#), [SRS-43](#)  
 Air bag disposal ..... [SRS-49](#)  
 Air bleeding (hydraulic clutch) ..... [CL-7](#)  
 Air bleeding for brake system ..... [BR-10](#)  
 Air cleaner and air duct ..... [EM-123](#)  
 Air cleaner filter ..... [EM-124](#)  
 Air cleaner filter replacement ..... [MA-33](#)  
 Air conditioner - Wiring diagram ..... [MTC-24](#), [MTC-26](#)  
 Air conditioner cut control ..... [EC-27](#), [EC-487](#)

Air mix door control linkage adjustment ..... [MTC-55](#)  
 Alternator ..... [SC-15](#)  
 Angular tightening application ..... [EM-105](#)  
 Antenna ..... [AV-15](#)  
 AP/SEN - Wiring diagram .. [EC-149](#), [EC-347](#), [EC-576](#),  
[EC-684](#)  
 APPS1 - Wiring diagram .... [EC-244](#), [EC-404](#), [EC-632](#),  
[EC-735](#)  
 APPS2 - Wiring diagram .... [EC-378](#), [EC-413](#), [EC-715](#),  
[EC-744](#)  
 APPS3 - Wiring diagram .... [EC-235](#), [EC-428](#), [EC-623](#),  
[EC-759](#)  
 Audio ..... [AV-3](#)  
 AUDIO - Wiring diagram ..... [AV-4](#)  
 Auto wiper ..... [WW-48](#)  
 Automatic transaxle number ..... [GI-48](#)  
 Automatic transmission fluid replacement ..... [MA-37](#)  
 Axle ..... [MA-40](#)

## B

Back door trim ..... [EI-18](#)  
 Back door window ..... [GW-10](#)  
 Back window ..... [GW-10](#)  
 BACK/L - Wiring diagram ..... [LT-183](#)  
 Back-up lamp ..... [LT-183](#), [LT-186](#)  
 Basic inspection ..... [EC-77](#), [EC-522](#)  
 Battery ..... [SC-5](#)  
 BCM (Body control module) ..... [BCS-3](#)  
 Blower motor ..... [MTC-29](#), [MTC-50](#)  
 Blower resistor ..... [MTC-51](#)  
 Board computer ..... [DI-37](#)  
 Board-on lift ..... [GI-40](#)  
 Bose speaker amp. .... [AV-3](#)  
 Brake booster ..... [BR-17](#)  
 Brake fluid change ..... [BR-9](#)  
 Brake fluid level ..... [MA-38](#)  
 Brake fluid level and line check ..... [BR-9](#)  
 Brake hydraulic line ..... [BR-11](#)  
 Brake inspection ..... [MA-39](#)  
 Brake lines and cables inspection ..... [MA-38](#)  
 Brake master cylinder ..... [BR-14](#)  
 Brake pedal ..... [BR-6](#)  
 Brake switch ..... [EC-395](#), [EC-726](#)  
 BRK/SW - Wiring diagram ..... [EC-397](#), [EC-728](#)  
 Bulb specifications ..... [LT-255](#)  
 Bumper, front ..... [EI-4](#)  
 Bumper, rear ..... [EI-6](#)

## C

Camshaft inspection ..... [EM-195](#)  
 Camshaft position sensor (PHASE) .. [EC-267](#), [EC-650](#)  
 CAN - Wiring diagram ..... [EC-131](#), [EC-573](#), [LAN-21](#),  
[LAN-53](#), [LAN-83](#), [LAN-113](#), [LAN-141](#), [LAN-173](#),  
[LAN-203](#), [LAN-233](#), [LAN-261](#), [LAN-291](#)  
 CAN (Controller Area Network) ..... [BRC-54](#), [LAN-6](#),  
[LAN-20](#), [LAN-52](#), [LAN-82](#), [LAN-112](#), [LAN-140](#),  
[LAN-172](#), [LAN-202](#), [LAN-232](#), [LAN-260](#), [LAN-290](#)

# ALPHABETICAL INDEX

CAN communication [EC-29](#), [EC-130](#), [EC-489](#), [EC-572](#),  
[AT-107](#), [AT-314](#), [AT-412](#), [BRC-54](#), [LAN-6](#), [LAN-20](#),  
[LAN-52](#), [LAN-82](#), [LAN-112](#), [LAN-140](#), [LAN-172](#),  
[LAN-202](#), [LAN-232](#), [LAN-260](#), [LAN-290](#)  
Canister-See EVAP canister ..... [EC-467](#), [EC-843](#)  
CD/CHG - Wiring diagram ..... [AV-4](#)  
CHARGE - Wiring diagram ..... [SC-16](#), [SC-17](#)  
Charging system ..... [SC-15](#)  
Chassis and body maintenance ..... [MA-36](#)  
CIGAR - Wiring diagram ..... [WW-116](#)  
Circuit breaker ..... [PG-17](#)  
Closed loop control ..... [EC-25](#), [EC-485](#)  
Clutch cover ..... [CL-10](#), [CL-12](#)  
Clutch disc ..... [CL-10](#)  
Clutch master cylinder ..... [CL-8](#)  
Clutch pedal ..... [CL-5](#)  
Coil spring (front) ..... [FSU-8](#)  
Coil spring (rear) ..... [RSU-8](#)  
Collision diagnosis ..... [SRS-56](#)  
Combination meter ..... [DI-5](#)  
Combination switch ..... [LT-187](#)  
COMBSW - Wiring diagram ..... [LT-192](#)  
COMM - Wiring diagram ..... [DI-57](#)  
Component Location (manual A/C) ..... [MTC-20](#)  
Compressor clutch removal and installation ... [MTC-64](#)  
Compressor precaution ..... [ATC-6](#), [MTC-6](#)  
Compressor special service tool ..... [MTC-10](#)  
Condenser ..... [MTC-71](#), [MTC-72](#)  
Connecting rod ..... [EM-197](#)  
CONSULT for ABS ..... [BRC-20](#)  
CONSULT for engine ..... [EC-101](#), [EC-546](#)  
CONSULT for VDC ..... [BRC-74](#)  
CONSULT general information ..... [GI-34](#)  
Control unit ..... [MTC-43](#)  
Control units (terminal arrangement) ..... [PG-102](#)  
Controller Area Network (CAN) ..... [BRC-54](#), [LAN-6](#),  
[LAN-20](#), [LAN-52](#), [LAN-82](#), [LAN-112](#), [LAN-140](#),  
[LAN-172](#), [LAN-202](#), [LAN-232](#), [LAN-260](#), [LAN-290](#)  
Converter housing installation ..... [AT-431](#), [AT-527](#)  
COOL/F - Wiring diagram ..... [EC-356](#), [EC-693](#)  
Coolant mixture ratio ..... [MA-20](#)  
Coolant replacement ..... [MA-30](#)  
Cooling circuit (engine)(QG) ..... [CO-7](#)  
Cooling fan ..... [CO-36](#)  
Cooling fan motor ..... [EC-365](#), [EC-702](#)  
Cowl top ..... [EI-10](#)  
Crankcase ventilation system - See Positive crankcase  
ventilation ..... [EC-468](#), [EC-844](#)  
Crankshaft ..... [EM-198](#)  
Crankshaft position sensor (POS) ..... [EC-261](#), [EC-643](#)  
Cylinder block ..... [EM-199](#)  
Cylinder head ..... [EM-144](#)  
Cylinder head bolt tightening ..... [EM-145](#), [EM-191](#)

## D

Data link connector ..... [EC-462](#), [EC-838](#)  
Data link connector for Consult ..... [EC-104](#), [EC-548](#)  
Daytime light system ..... [LT-42](#)

Diagnosis sensor unit ..... [SRS-48](#)  
Diagnostic trouble code (DTC) for OBD system [EC-11](#),  
[EC-50](#), [EC-472](#), [EC-508](#)  
Diagnostic trouble code (DTC) inspection priority chart  
[EC-73](#), [EC-519](#)  
Dimensions ..... [GI-48](#)  
Door glass ..... [GW-4](#), [GW-69](#), [GW-72](#)  
Door mirror ..... [GW-75](#)  
Door trim ..... [EI-16](#)  
Drive belt ..... [EM-121](#)  
Drive belt inspection ..... [MA-30](#)  
Drive computer ..... [DI-36](#), [DI-57](#)  
Drive shaft (front) ..... [FAX-10](#)  
Driver air bag ..... [SRS-36](#)  
Dropping resistor (A/T) ..... [AT-172](#), [AT-411](#)  
DTC work support ..... [EC-110](#)  
DTRL - Wiring diagram ..... [LT-59](#)  
Duct and grilles ..... [MTC-57](#)

## E

ECM input/output signal ..... [EC-94](#), [EC-539](#)  
ECM power supply [EC-125](#), [EC-289](#), [EC-567](#), [EC-660](#)  
ECM/PW - Wiring diagram ..... [EC-290](#), [EC-661](#)  
ECTS - Wiring diagram ..... [EC-160](#), [EC-582](#)  
Electric throttle control actuator ..... [EC-297](#), [EC-299](#),  
[EC-310](#), [EC-664](#), [EC-667](#), [EC-678](#)  
Electrical diagnoses ..... [GI-10](#)  
Electrical load signal circuit ..... [EC-460](#), [EC-836](#)  
Electrical unit ..... [PG-102](#)  
Electrical units location ..... [PG-95](#)  
Electronic ignition (EI) system ..... [EC-26](#), [EC-486](#)  
Engine control circuit diagram ..... [EC-92](#), [EC-537](#)  
Engine control component parts location ..... [EC-87](#),  
[EC-532](#)  
Engine control module (ECM) ..... [EC-286](#), [EC-657](#)  
Engine control system diagram and chart ..... [EC-22](#),  
[EC-482](#)  
Engine coolant ..... [CO-31](#)  
Engine coolant temperature sensor (ECTS) ... [EC-158](#),  
[EC-580](#)  
Engine fail-safe system ..... [EC-75](#), [EC-520](#)  
Engine oil ..... [LU-12](#)  
Engine oil filter replacement ..... [MA-35](#)  
Engine oil precautions ..... [GI-7](#)  
Engine oil replacement ..... [MA-34](#)  
Engine removal ..... [EM-147](#)  
Engine room cover ..... [EM-119](#)  
Engine serial number ..... [GI-47](#)  
ETC1 - Wiring diagram ..... [EC-300](#), [EC-668](#)  
ETC2 - Wiring diagram ..... [EC-307](#), [EC-675](#)  
ETC3 - Wiring diagram ..... [EC-311](#), [EC-679](#)  
EVAP canister ..... [EC-467](#), [EC-843](#)  
EVAP canister purge volume control solenoid valve ....  
[EC-278](#), [EC-464](#), [EC-801](#), [EC-840](#)  
EVAP vapor lines inspection(QG) ..... [MA-29](#)  
EVAP vapor lines inspection(QR) ..... [MA-29](#)  
Evaporative emission (EVAP) system [EC-464](#), [EC-840](#)  
Evaporator ..... [MTC-74](#)

# ALPHABETICAL INDEX

Exhaust manifold ..... [EM-129](#)  
 Exhaust system inspection ..... [EX-3](#), [MA-36](#)  
 Expansion valve ..... [MTC-75](#)

## F

F/FOG - Wiring diagram ..... [LT-89](#)  
 F/PUMP - Wiring diagram ..... [EC-451](#), [EC-827](#)  
 Floor trim ..... [EI-22](#)  
 Flow charts ..... [GI-24](#)  
 Fluid temperature sensor (A/T) ..... [AT-125](#)  
 Fluids ..... [MA-18](#)  
 Fluorescent leak detector ..... [MTC-76](#)  
 Flywheel (clutch) ..... [CL-12](#)  
 Freeze frame data ..... [EC-51](#), [EC-509](#)  
 FRO2 - Wiring diagram ..... [EC-767](#), [EC-781](#)  
 Front axle ..... [FAX-6](#)  
 Front bumper ..... [EI-4](#)  
 Front disc brake ..... [BR-21](#)  
 Front fog lamp ..... [LT-74](#)  
 Front passenger air bag ..... [SRS-40](#)  
 Front seat ..... [SE-7](#)  
 Front seat belt ..... [SB-3](#)  
 Front seat belt pre-tensioner ..... [SB-2](#), [SB-3](#), [SRS-3](#)  
 Front side air bag ..... [SRS-41](#)  
 Front suspension ..... [FSU-5](#)  
 Front washer ..... [WW-5](#), [WW-48](#)  
 Front wiper ..... [WW-5](#), [WW-48](#)  
 FUEL - Wiring diagram ..... [EC-210](#), [EC-217](#)  
 Fuel check valve ..... [EC-464](#), [EC-840](#)  
 Fuel cut control (at no load high engine speed) [EC-28](#),  
[EC-488](#)  
 Fuel filter replacement ..... [FL-14](#)  
 Fuel gauge ..... [FL-17](#), [DI-5](#)  
 Fuel injection system ..... [EC-208](#), [EC-215](#)  
 Fuel line inspection ..... [FL-3](#), [MA-33](#)  
 Fuel line inspection(QG) ..... [MA-26](#)  
 Fuel line inspection(QR) ..... [MA-26](#)  
 Fuel precautions ..... [GI-5](#)  
 Fuel pressure check ..... [EC-44](#), [EC-505](#)  
 Fuel pressure release ..... [EC-44](#), [EC-505](#)  
 Fuel pump ..... [EC-450](#), [EC-826](#)  
 Fuel system ..... [FL-13](#)  
 Fuel tank ..... [FL-19](#)  
 Fuse ..... [PG-17](#)  
 Fuse and fusible link box ..... [PG-107](#)  
 Fusible link ..... [PG-17](#)

## G

Garage jack and safety stand ..... [GI-38](#)  
 Generator ..... [SC-15](#)  
 Generator - See Alternator ..... [SC-15](#)  
 Generic scan tool (GST) ..... [EC-112](#)  
 Glow plug ..... [EM-136](#)  
 Grease ..... [MA-18](#)  
 Grille - See Exterior ..... [EI-8](#)  
 Ground distribution ..... [PG-54](#)

## H

H/AIM - Wiring diagram ..... [LT-71](#)  
 H/LAMP - Wiring diagram ..... [LT-22](#)  
 Harness connector ..... [PG-99](#)  
 Harness layout ..... [PG-67](#)  
 Hazard warning lamp ..... [LT-121](#), [LT-188](#)  
 Headlamp ..... [LT-6](#)  
 Headlamp aiming control ..... [LT-71](#)  
 Headlamp washer ..... [WW-110](#)  
 Headlining - See Roof trim ..... [EI-24](#)  
 Heated oxygen sensor 1 .... [EC-169](#), [EC-175](#), [EC-185](#),  
[EC-315](#), [EC-321](#), [EC-591](#), [EC-597](#), [EC-780](#)  
 Heated oxygen sensor 1 heater ..... [EC-136](#), [EC-766](#)  
 Heated oxygen sensor 2 .... [EC-192](#), [EC-199](#), [EC-327](#),  
[EC-337](#), [EC-603](#), [EC-786](#)  
 Heated oxygen sensor 2 heater ..... [EC-142](#), [EC-771](#)  
 Heated seat ..... [SE-4](#)  
 HEATER - Wiring diagram ..... [MTC-22](#)  
 Heater system - Wiring diagram ..... [MTC-22](#)  
 Heater unit (heater core) ..... [MTC-49](#)  
 Height (Dimensions) ..... [GI-48](#)  
 HFC134a (R134a) system precaution . [ATC-3](#), [MTC-3](#)  
 HFC134a (R134a) system service procedure . [MTC-61](#)  
 HFC134a (R134a) system service tools ..... [MTC-10](#)  
 HFC134a system service equipment precaution .....  
[ATC-6](#), [MTC-6](#)  
 HLC - Wiring diagram ..... [WW-111](#), [WW-114](#)  
 HO2S1 - Wiring diagram ..... [EC-171](#), [EC-178](#), [EC-188](#),  
[EC-593](#), [EC-599](#)  
 HO2S1H - Wiring diagram ..... [EC-138](#)  
 HO2S2 - Wiring diagram .... [EC-194](#), [EC-202](#), [EC-331](#),  
[EC-340](#), [EC-605](#)  
 HO2S2H - Wiring diagram ..... [EC-144](#)  
 Horn ..... [WW-114](#)  
 HORN - Wiring diagram ..... [WW-114](#)  
 How to erase DTC for OBD system .... [EC-59](#), [EC-510](#)  
 HSEAT - Wiring diagram ..... [SE-5](#)

## I

IATS - Wiring diagram ..... [EC-155](#)  
 IATSEN - Wiring diagram ..... [EC-777](#)  
 Identification ..... [ATC-9](#), [MTC-9](#)  
 Identification plate ..... [GI-47](#)  
 Idle air volume learning ..... [EC-42](#), [EC-503](#)  
 Idle speed ..... [EC-77](#), [EC-522](#)  
 Ignition coil ..... [EC-435](#), [EC-792](#)  
 Ignition control system ..... [EC-435](#), [EC-792](#)  
 Ignition timing ..... [EC-77](#), [EC-522](#)  
 IGNSYS - Wiring diagram ..... [EC-436](#), [EC-793](#)  
 ILL - Wiring diagram ..... [LT-247](#)  
 Illumination ..... [LT-230](#)  
 INJECT - Wiring diagram ..... [EC-445](#), [EC-821](#)  
 Injector ..... [EC-444](#), [EC-820](#)  
 Instrument panel ..... [IP-4](#)  
 INT/L - Wiring diagram ..... [LT-217](#)  
 Intake air system ..... [EC-346](#), [EC-683](#)  
 Intake air temperature sensor ..... [EC-153](#), [EC-776](#)

# ALPHABETICAL INDEX

Intake door control linkage adjustment ..... [MTC-53](#)  
 Intake valve timing control ..... [EC-133](#), [EC-809](#)  
 Intake valve timing control solenoid valve ..... [EC-293](#),  
[EC-809](#)  
 Interior lamp ..... [LT-200](#)  
 IPDM (Intelligent power distribution module engine  
 room) ..... [PG-18](#)  
 ISO 15031-2 Terminology ..... [GI-49](#)  
 ISO 15031-5 Mode 1 - 9 ..... [EC-47](#)  
 IVC - Wiring diagram ..... [EC-294](#)  
 IVC/V - Wiring diagram ..... [EC-811](#)

## K

Keyless entry system - See Multi-remote control system  
[BL-131](#)  
 Knock sensor (KS) ..... [EC-257](#), [EC-639](#)  
 Knuckle spindle ..... [FAX-6](#)  
 KS - Wiring diagram ..... [EC-258](#), [EC-640](#)

## L

Length (Dimensions) ..... [GI-48](#)  
 License lamp ..... [LT-152](#)  
 Line pressure solenoid valve ..... [AT-160](#)  
 Line pressure test (A/T) ..... [AT-65](#), [AT-272](#)  
 Liquid gasket application ..... [EM-106](#)  
 Location of electrical units ..... [PG-95](#)  
 Lubricant (R134a) A/C ..... [ATC-4](#), [MTC-4](#), [MTC-15](#),  
[MTC-79](#)  
 Lubricants ..... [MA-18](#)  
 Lubrication circuit (engine)(QG) ..... [LU-3](#)  
 Lubrication oil A/C ..... [MTC-79](#)  
 Lubrication-locks, hinges and hood latches ..... [MA-41](#)  
 Luggage compartment trim ..... [EI-26](#)

## M

Magnet clutch ..... [MTC-31](#)  
 MAIN - Wiring diagram ..... [EC-125](#), [EC-567](#)  
 Malfunction indicator (MI) ..... [EC-60](#), [EC-511](#)  
 Manifold absolute pressure (MAP) sensor ..... [EC-148](#),  
[EC-575](#)  
 Manual air conditioner - Wiring diagram ..... [MTC-24](#),  
[MTC-26](#)  
 Master cylinder (brake) ..... [BR-14](#)  
 Meter ..... [DI-5](#)  
 MIL/DL - Wiring diagram ..... [EC-462](#), [EC-838](#)  
 Mirror, door ..... [GW-75](#)  
 Mirror, out side ..... [GW-75](#)  
 Misfire ..... [EC-251](#)  
 Mode door control linkage adjustment ..... [MTC-54](#)  
 Model variation ..... [GI-44](#)  
 Molding - See Exterior ..... [EI-12](#), [EI-13](#), [EI-15](#)  
 Multiport fuel injection (MFI) system .... [EC-24](#), [EC-484](#)  
 Multiport fuel injection precautions ..... [GI-6](#)  
 Multi-remote control system ..... [BL-131](#)

## N

NATS - Wiring diagram ..... [BL-226](#)  
 NATS (Nissan anti-theft system) precautions ..... [GI-3](#)  
 NAVI - Wiring diagram ..... [AV-18](#)  
 Navigation system ..... [AV-17](#)  
 NVH troubleshooting (BR) ..... [BR-5](#), [PB-2](#)  
 NVH troubleshooting (RSU) ..... [RSU-3](#)  
 NVH troubleshooting (ST) ..... [PS-4](#)

## O

Oil cooler (engine) ..... [LU-16](#)  
 Oil filter ..... [LU-14](#)  
 Oil pan (engine) ..... [EM-133](#)  
 Oil pressure (engine) ..... [LU-12](#)  
 Oil pump (engine) ..... [LU-15](#)  
 On board diagnostic system ..... [EC-47](#), [EC-508](#)  
 Out side mirror ..... [GW-75](#)  
 Overdrive control switch ..... [AT-250](#), [AT-361](#)  
 Overheat ..... [EC-352](#), [EC-689](#)

## P

Park/Neutral position switch ..... [EC-389](#), [EC-815](#)  
 Park/neutral position switch (A/T) ..... [AT-114](#)  
 Parking brake control ..... [PB-3](#)  
 Parking lamp ..... [LT-152](#)  
 PCV (positive crankcase ventilation) . [EC-468](#), [EC-844](#)  
 PGC/V - Wiring diagram ..... [EC-280](#)  
 PHASE - Wiring diagram ..... [EC-268](#), [EC-652](#)  
 Piston assembly ..... [EM-196](#)  
 Piston pin inspection ..... [EM-196](#)  
 Piston ring inspection ..... [EM-197](#)  
 PNP/SW - Wiring diagram ..... [EC-391](#)  
 PNPSW1 - Wiring diagram ..... [EC-816](#)  
 POS - Wiring diagram ..... [EC-262](#), [EC-645](#)  
 POWER - Wiring diagram ..... [PG-5](#)  
 Power door lock ..... [BL-15](#)  
 Power socket ..... [WW-116](#)  
 Power steering gear ..... [PS-9](#)  
 Power supply routing ..... [PG-4](#)  
 Power window ..... [GW-52](#), [GW-69](#), [GW-72](#)  
 Precations for Leak detection dye ..... [ATC-9](#), [MTC-9](#)  
 Precations (General) ..... [GI-4](#)  
 PRGVLV - Wiring diagram ..... [EC-802](#)

## R

R/FOG - Wiring diagram ..... [LT-115](#)  
 Radiator ..... [CO-34](#)  
 Radiator fan - See Cooling fan ..... [CO-36](#)  
 Radiator(QG) ..... [CO-17](#)  
 Radio - See Audio ..... [AV-3](#)  
 Rain sensor ..... [WW-48](#)  
 Rear axle ..... [RAX-5](#)  
 Rear bumper ..... [EI-6](#)  
 Rear drum brake ..... [BR-27](#)  
 Rear fog lamp ..... [LT-100](#), [LT-186](#)



# ALPHABETICAL INDEX

Rear seat ..... [SE-11](#)  
 Rear seat belt ..... [SB-4](#)  
 Rear side window ..... [GW-8](#)  
 Rear suspension ..... [RSU-4](#)  
 Rear washer ..... [WW-82](#)  
 Rear window defogger ..... [GW-14](#)  
 Rear wiper ..... [WW-82](#)  
 Refrigerant connection precaution ..... [ATC-4](#), [MTC-4](#)  
 Refrigerant general precaution ..... [ATC-3](#), [MTC-3](#)  
 Refrigerant lines ..... [MTC-61](#)  
 Refrigerant pressure sensor [EC-455](#), [EC-831](#), [MTC-14](#),  
[MTC-71](#)  
 Refrigeration cycle ..... [MTC-14](#)  
 Removal and installation (A/T) ..... [AT-430](#)  
 Road wheel size ..... [GI-48](#)  
 Rocker cover ..... [EM-138](#)  
 Roof trim ..... [EI-24](#)  
 RP/SEN - Wiring diagram ..... [EC-456](#), [EC-832](#)  
 RRO2 - Wiring diagram ..... [EC-772](#), [EC-787](#)

## S

S/LOCK - Wiring diagram [BL-33](#), [BL-39](#), [BL-87](#), [BL-94](#)  
 Seat belt inspection ..... [SB-4](#), [MA-41](#)  
 Seat belt pre-tensioner ..... [SB-3](#)  
 Seat belt pre-tensioner disposal ..... [SRS-49](#)  
 Seat belt, front ..... [SB-3](#)  
 Seat belt, rear ..... [SB-4](#)  
 Seat, front ..... [SE-7](#)  
 Seat, rear ..... [SE-11](#)  
 SEN/PW - Wiring diagram ..... [EC-386](#), [EC-723](#)  
 Sheft warning system ..... [BL-222](#)  
 SHIFT - Wiring diagram ..... [AT-419](#)  
 Shift lock system ..... [AT-418](#)  
 Shift schedule ..... [AT-534](#)  
 Shift solenoid valve A (A/T) .. [AT-135](#), [AT-140](#), [AT-152](#)  
 Shift solenoid valve B (A/T) ..... [AT-135](#), [AT-140](#)  
 Shock absorber (front) ..... [FSU-8](#)  
 Shock absorber (rear) ..... [RSU-6](#)  
 Side air bag ..... [SRS-41](#), [SRS-43](#)  
 Side air bag (satellite) sensor ..... [SRS-46](#)  
 Side curtain air bag ..... [SRS-43](#)  
 Side trim ..... [EI-19](#)  
 Side window - See Rear side window ..... [GW-8](#)  
 SMJ (super multiple junction) ..... [PG-103](#)  
 Spare tire size ..... [GI-48](#)  
 Specification value ..... [EC-119](#), [EC-561](#)  
 Speedometer ..... [DI-5](#)  
 Spiral cable ..... [SRS-38](#)  
 SROOF - Wiring diagram ..... [RF-4](#)  
 SRS - See Supplemental Restraint System ..... [SRS-6](#)  
 SRS - Wiring diagram ..... [SRS-11](#), [SRS-12](#)  
 SRS Trouble diagnoses ..... [SRS-8](#)  
 Stabilizer bar (front) ..... [FSU-11](#)  
 Stall test (A/T) ..... [AT-62](#), [AT-269](#)  
 Standardized relay ..... [PG-104](#)  
 START - Wiring diagram ..... [SC-40](#), [SC-42](#)  
 Starter ..... [SC-39](#)  
 Starting system ..... [SC-39](#)

Steering gear and linkage inspection ..... [MA-40](#)  
 Steering linkage ..... [PS-9](#)  
 Steering wheel and column ..... [PS-5](#), [PS-7](#)  
 Steering wheel play ..... [PS-5](#)  
 Steering wheel turning force ..... [PS-5](#)  
 Stop lamp ..... [LT-181](#), [LT-186](#)  
 Stop lamp switch ..... [EC-395](#), [EC-726](#)  
 STOP/L - Wiring diagram ..... [LT-181](#)  
 Sunroof ..... [RF-2](#)  
 Super lock ..... [BL-70](#)  
 Supplemental Restraint System ..... [SRS-6](#)  
 Supplemental restraint system - Wiring diagram .....  
[SRS-11](#), [SRS-12](#)  
 Suspension ..... [MA-40](#)  
 Symbols and abbreviations ..... [GI-10](#), [GI-22](#)  
 Symptom matrix chart ..... [EC-82](#), [EC-527](#)  
 SYSTEM ..... [BRC-6](#)  
 System readiness test (SRT) code ..... [EC-51](#)

## T

Tachometer ..... [DI-5](#)  
 Tail lamp ..... [LT-152](#), [LT-186](#)  
 TAIL/L - Wiring diagram ..... [LT-169](#)  
 TCM circuit diagram ..... [AT-14](#)  
 TCM inspection table ..... [AT-104](#), [AT-311](#)  
 THEFT - Wiring diagram ..... [BL-222](#)  
 Thermo control amp ..... [MTC-56](#)  
 Three way catalyst function ..... [EC-273](#)  
 Three way catalyst precautions ..... [GI-5](#)  
 Throttle control motor relay ..... [EC-305](#), [EC-673](#)  
 Throttle position sensor (TPS) ..... [EC-163](#), [EC-221](#),  
[EC-227](#), [EC-366](#), [EC-372](#), [EC-374](#), [EC-420](#), [EC-585](#),  
[EC-609](#), [EC-615](#), [EC-703](#), [EC-709](#), [EC-711](#), [EC-751](#)  
 Throttle valve closed position learning [EC-42](#), [EC-503](#)  
 Tie-rod ..... [PS-9](#)  
 Tie-rod ball joints ..... [PS-9](#)  
 Tightening torque of standard bolts ..... [GI-43](#)  
 Timing belt ..... [EM-140](#)  
 Tire size ..... [GI-48](#)  
 Torque converter installation ..... [AT-431](#), [AT-527](#)  
 Tow truck towing ..... [GI-41](#)  
 TPS1 - Wiring diagram ..... [EC-229](#), [EC-617](#)  
 TPS2 - Wiring diagram ..... [EC-165](#), [EC-368](#), [EC-587](#),  
[EC-705](#)  
 TPS3 - Wiring diagram ..... [EC-223](#), [EC-422](#), [EC-611](#),  
[EC-753](#)  
 Tread-FR&RR (Dimensions) ..... [GI-48](#)  
 Trouble diagnoses ..... [GI-10](#)  
 Turbocharger ..... [EM-129](#)  
 Turbocharger precautions ..... [GI-6](#)  
 TURN - Wiring diagram ..... [LT-138](#)  
 Turn signal lamp ..... [LT-121](#), [LT-186](#)  
 Two trip detection logic ..... [EC-47](#), [EC-508](#)  
 Two-pole lift ..... [GI-39](#)

## V

Vacuum hose (brake system) ..... [BR-19](#)

## ALPHABETICAL INDEX

Vacuum hose drawing (Engine control) [EC-23](#), [EC-483](#)  
Vacuum pump ..... [EM-137](#)  
Valve clearance ..... [EM-161](#), [EM-194](#)  
Valve guide ..... [EM-192](#)  
Valve seat ..... [EM-192](#)  
Valve spring ..... [EM-194](#)  
VDC -Wiring diagram ..... [BRC-66](#)  
Vehicle identification number ..... [GI-46](#)  
Vehicle recovery (freeing a stuck vehicle) ..... [GI-42](#)  
Vehicle speed sensor (VSS) ..... [EC-284](#), [EC-808](#)  
Viscosity number (SAE) ..... [MA-19](#)

### W

WARN - Wiring diagram ..... [DI-66](#), [DI-71](#)  
Warning chime ..... [DI-81](#)  
Warning lamps ..... [DI-65](#)  
Water pump ..... [CO-39](#)  
Water temperature (High) warning lamp ..... [DI-5](#)  
Water temperature (Low) indicator lamp ..... [DI-5](#)  
Wheel alignment (front) ..... [FSU-6](#)  
Wheel alignment (rear) ..... [RSU-5](#)  
Wheel bearing (front) ..... [FAX-6](#)  
Wheel bearing (rear) ..... [RAX-5](#)  
Wheel hub (front) ..... [FAX-6](#)  
Wheel hub (rear) ..... [RAX-5](#)  
Wheel sensor (VDC) ..... [BRC-101](#)  
Wheel sensors (ABS) ..... [BRC-44](#)  
Wheel size ..... [GI-48](#)  
Wheelbase (Dimensions) ..... [GI-48](#)  
Width (Dimensions) ..... [GI-48](#)  
WINDOW - Wiring diagram ..... [GW-55](#)  
Window antenna ..... [AV-15](#)  
Window, back ..... [GW-10](#)  
Window, back door ..... [GW-10](#)  
Window, door ..... [GW-69](#), [GW-72](#)  
Window, rear side ..... [GW-8](#)  
Window, side - See Rear side window ..... [GW-8](#)  
Windshield ..... [GW-4](#)  
WIP/R - Wiring diagram ..... [WW-100](#)  
WIPER - Wiring diagram ..... [WW-25](#)  
Wiring Diagram (Cell code) list ..... [PG-92](#)  
Wiring diagrams ..... [GI-14](#)

A

B

C

D

E

F

G

H

I

J

K

L

IDX