



Wiring Diagram — INT/L —






LT-INT/L-01



(M1) -SUPER MULTIPLE
JUNCTION (SMJ)
(M16) -FUSE BLOCK-
JUNCTION BOX (J/B)
(M79) , (M82)
-JOINT CONNECTOR (J/C)

INTERIOR ROOM LAMP

LT-INT/L-02




MKWA0832E

INTERIOR ROOM LAMP

LT-INT/L-03

◻ : LHD MODELS

◻ : RHD MODELS



1	2	3	4	5	6	7	8	9	10	11	12
13	14	15	16	17	18	19	20	21	22	23	24

(M9) W

20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

(M48) W

65	66	67	68	69	70	71	72	73
74	75	76	77	78	79			

(M50) B

H.S.

1	2	3	4
5	6	7	8

(M54) W

1	1	1	2	2	2	3	3	3
4	4	4	4	4	4	5	5	5

(M79) W

1	2	3	4
---	---	---	---

(B40) B

2

(B41) B

1	2	3	4
---	---	---	---

(B55) W

1	2	3	4	5	6
---	---	---	---	---	---

(R2) W

MKWA3085E

INTERIOR ROOM LAMP

Room Lamp Does Not Operate

1. CHECK SWITCH SIGNAL

To ESM

Select BCM on CONSULT-II. Check following item in "DATA MONITOR" mode with CONSULT-II.

Monitor item	Condition	
IGN ON SW	Ignition switch is in ON position	ON
	Ignition switch is in other position	OFF
PUSH SW	Ignition knob is pushed	ON
	Ignition knob is released	OFF
KEY IN SW	Key is inserted	ON
	Key is removed	OFF
DOOR SW-DR	Front RH door is opened	ON
	Front RH door is closed	OFF
DOOR SW-AS	Front LH door is opened	ON
	Front LH door is closed	OFF
DOOR SW-RR	Rear RH door is opened	ON
	Rear RH door is closed	OFF
DOOR SW-RL	Rear LH door is opened	ON
	Rear LH door is closed	OFF
BACK DOOR SW	Back door is opened	ON
	Back door is closed	OFF
CDL LOCK SW	Lock/unlock switch lock position	ON
	Lock/unlock switch unlock position	OFF
CDL UNLOCK SW	Lock/unlock switch unlock position	ON
	Lock/unlock switch lock position	OFF
KEYLESS LOCK (*2)	Keyless lock/unlock switch lock position	ON
	Keyless lock/unlock switch unlock position	OFF
KEYLESS UNLOCK (*2)	Keyless lock/unlock switch unlock position	ON
	Keyless lock/unlock switch lock position	OFF
I-KEY LOCK (*1)	Intelligent Key lock/unlock switch lock position	ON
	Intelligent Key lock/unlock switch unlock position	OFF
I-KET UNLOCK (*1)	Intelligent Key lock/unlock switch unlock position	ON
	Intelligent Key lock/unlock switch lock position	OFF
I-KEY ALL UNL (*1)	Intelligent Key all door unlock switch unlock position	ON
	Intelligent Key all door unlock switch lock position	OFF

*1: Display for models with Intelligent Key system

*2: Displayed for models without Intelligent Key system

OK or NG

OK >> GO TO 2.

NG >> ● IGN ON SW: Refer to DI-110, "Ignition ON Signal Check" on ESM.

- PUSH SW (with Intelligent Key system): Refer to DI-107, "Key Switch Signal Check/With Intelligent Key System" on ESM.
- KEY IN SW (without Intelligent Key system): Refer to DI-105, "Key Switch Signal Check/Without Intelligent Key System" on ESM.
- OOR SW-DR: Refer to BL-58, "DRIVER SIDE" on ESM.
- DOOR SW-AS: Refer to BL-60, "PASSENGER SIDE" on ESM.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
PUSH SW	OFF
DOOR SW-DR	OFF
DOOR SW-AS	ON
DOOR SW-RR	ON
DOOR SW-RL	ON
BACK DOOR SW	ON
CDL LOCK SW	OFF
CDL UNLOCK SW	OFF
Page Down	
RECORD	
MODE	BACK LIGHT COPY

DATA MONITOR	
MONITOR	
DOOR SW-RL	ON
BACK DOOR SW	ON
CDL LOCK SW	OFF
CDL UNLOCK SW	OFF
KEYLESS LOCK	OFF
KEYLESS UNLOCK	OFF
I-KEY LOCK	OFF
I-KEY UNLOCK	OFF
I-KEY ALL UNL	OFF
Page Up	
RECORD	
MODE	BACK LIGHT COPY

MKIB0846E


INTERIOR ROOM LAMP

- DOOR SW-RR: Refer to BL-64, "REAR RH SIDE" on ESM.
- DOOR SW-RL: Refer to BL-62, "REAR LH SIDE" on ESM.
- BACK DOOR SW: Refer to BL-66, "Check External Back Door Release Switch" on ESM.
- CDL LOCK/UNLOCK SW: Refer to BL-50, "Check Door Lock / Unlock Switch" on ESM.
- KEYLESS LOCK/UNLOCK: Refer to BL-144, "Remote controller Check" on ESM.
- I-KEY LOCK/UNLOCK: Refer to BL-194, "Check Door Request Switch" on ESM.
- I-KEY ALL UNL: Refer to BL-194, "Check Door Request Switch" on ESM.

2. CHECK BCM OUTPUT SIGNAL

1. Interior room lamp switch is in DOOR position.
2. Check voltage between BCM and ground.

Terminal		Condition				Voltage (V)
(+)	(-)					
Con- nector	Termi- nal (Wire color)					
M50	73 (PU)	Ground	Ignition switch OFF	Key is inserted	ON (open)	Approx. 0
					OFF (closed)	Approx. 12
		—	Close all doors.	Key is removed after being fully inserted.		Approx. 0
				Turn ignition switch ON.		Approx. 12



OK or NG

- OK >> GO TO 3.
 NG >> Replace BCM.

3. CHECK INTERIOR ROOM LAMP INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and room lamp connector.
3. Check continuity between BCM harness connector M50 terminal 73(PU) and interior room lamp harness connector R2 terminal 4(PU).


Continuity should exist.

4. Check continuity between BCM connector M50 terminal 73 (PU) and ground.

Continuity should not exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair or replace harness or connector.



INTERIOR ROOM LAMP

4. CHECK INTERIOR ROOM LAMP GROUND CIRCUIT

1. Check continuity between BCM connector M48 terminal 21(Y) and interior room lamp connector R2 terminal 1 (Y).

Continuity should exist.


2. Check continuity between BCM connector M48 terminal 21 (Y) and ground.

Continuity should not exist.

OK or NG


OK >> GO TO 5.

NG >> Repair or replace harness or connector.



5. CHECK BCM OUTPUT SIGNAL

1. Interior room lamp switch is in DOOR position.
2. Connect BCM connector
3. Check voltage between BCM connector terminal and ground.



Terminal No.	Wire color	Signal designation	Measuring condition					Reference value (V)
			Ignition switch	Operation or condition				
21	Y	Logical lighting control	OFF	Room lamp switch: DOOR position	Key is inserted	Any door switch	ON (Open)	Approx. 0
							OFF (Close)	Approx. 12
					Close all doors	Key is removed from key cylinder		Approx. 0
						Turn ignition switch ON		Approx. 12
					Key is removed			Approx. 0
					Interior room lamp timer		OFF	Approx. 12
							ON	Approx. 0

OK or NG

OK >> Check condition of the harness and connector.

NG >> Replace BCM.

INTERIOR ROOM LAMP

Bulb Replacement

To ESM


1. Remove interior room lamp. Refer to LT-7,"REMOVAL" in this SMA file.
2. Remove bulbs.

Interior room lamp : 12V - 5W

Removal and Installation

REMOVAL

1. Without damaging the headliner, insert a clip driver in the interior room lamp right side edge to disengage tab(2).
2. Disengage tab(2) of left side, and then disconnect connector.
3. Remove interior room lamp(1).



INSTALLATION

Install in the reverse order of removal.

BULB SPECIFICATIONS

BULB SPECIFICATIONS

To ESM

Interior Lamp/Illumination

Item	Wattage (W)
Interior room lamp	5
Luggage room lamp	10