

SECTION

ACC

ACC

ACCELERATOR CONTROL SYSTEM

CONTENTS

<b>ACCELERATOR CONTROL SYSTEM</b> .....	2	<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	3
Removal and Installation .....	2	Tightening Torque .....	3
REMOVAL .....	2		
INSTALLATION .....	2		
INSPECTION AFTER INSTALLATION .....	2		

# ACCELERATOR CONTROL SYSTEM


## ACCELERATOR CONTROL SYSTEM

PFP:18005

### Removal and Installation

EBS000JF

#### SEC. 180



PBIC1506E

1. Accelerator pedal assembly
2. Accelerator pedal stopper (Underfloor carpet)

### REMOVAL

1. Remove harness connector.
2. Remove mounting bolts, and remove accelerator assembly.

#### CAUTION:

- Do not disassemble accelerator pedal assembly and remove sensors.
  - Handle them carefully without subjecting them to impacts such as dropping.
  - Be careful not to get it wet.
3. Fold the floor carpet and remove accelerator pedal stopper.
    - Remove pedal stopper by turning it counterclockwise with fingers.

### INSTALLATION

Install in the reverse order of removal. be careful of the following:

- Insert locating pin into vehicle side to position accelerator pedal assembly. Install mounting bolt to accelerator pedal assembly.
- Align the stud bolt on the floor with the thread hole to insert accelerator pedal stopper until it contacts the face.

### INSPECTION AFTER INSTALLATION

- Check that the accelerator pedal moves smoothly within the whole operation range.
- Check that the accelerator pedal securely returns to the original position.
- For the electrical inspection of the accelerator pedal assembly, refer to [EC-233, "DTC P0226 APP SENSOR"](#) (CR WITH EURO-OBD), [EC-621, "DTC P0226 APP SENSOR"](#) (CR WITHOUT EURO-OBD) or "Interpretation", "DIESEL INJECTION" in EC section(K9K).
- When accelerator electrical connector is disconnected, perform [EC-42, "Accelerator Pedal Released Position Learning"](#) (WITH EURO-OBD), [EC-503, "Accelerator Pedal Released Position Learning"](#) (WITHOUT EURO-OBD).

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)		PFP:00030
Tightening Torque		EBS000JG
		Unit: N·m (kg-m, in-lb)
Accelerator pedal assembly	4.3 - 5.9 (0.44 - 0.60, 38 - 52)	

- ACC
- A
- C
- D
- E
- F
- G
- H
- I
- J
- K
- L
- M

## SERVICE DATA AND SPECIFICATIONS (SDS)

---