





# TROUBLE DIAGNOSIS

## TROUBLE DIAGNOSIS


### Wiring Diagram —A/C— CR Engine Models

ATC-A/C-01






REFER TO THE FOLLOWING.

(M16) -FUSE BLOCK-  
JUNCTION BOX (J/B)



ATC-A/C-02






REFER TO THE FOLLOWING.

**(M1), (F1) -SUPER**

**MULTIPLE JUNCTION (SMJ)**

(E49), (F2) -ELECTRICAL UNITS





REFER TO THE FOLLOWING.  
**M16** -FUSE BLOCK-  
JUNCTION BOX (J/B)

# TROUBLE DIAGNOSIS

ATC-A/C-04

— : DATA LINE

REFER TO PG-POWER.



REFER TO THE FOLLOWING.

- (M1), (F1) -SUPER
- MULTIPLE JUNCTION (SMJ)
- (M48), (M49)
- ELECTRICAL UNITS

## Blower Motor System

Symptom: Operation malfunction of blower motor

To ESM

ATC-4

## TROUBLE DIAGNOSIS

### 1. CHECK POWER SUPPLY CIRCUIT (BLOWER MOTOR)

Turn ignition switch ON, and check voltage between blower motor terminal 1 and ground.


| Connector terminal |        | Voltage         |
|--------------------|--------|-----------------|
| Blower motor       | Ground | Battery voltage |
| 1                  |        |                 |

OK or NG

OK >> GO TO 2.

NG >> Check power supply circuit and 15A fuses [Nos. 9 and 10, located in the fuse block (J/B)]. Refer to PG-4, "POWER SUPPLY ROUTING" on ESM.

- If OK, check for open circuit in wiring harness. Repair or replace as necessary.
- If NG, replace fuse and check wiring harness for short circuit. Repair or replace as necessary.



### 2. CHECK POWER SUPPLY CIRCUIT (A/C AUTO AMP.)


1. Disconnect A/C auto amp. connector.
2. Turn ignition switch ON, and check voltage between A/C auto amp. terminal 8 and ground.

| Connector terminal |        | Voltage         |
|--------------------|--------|-----------------|
| A/C auto amp.      | Ground | Battery voltage |
| 8                  |        |                 |

OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.



### 3. CHECK POWER SUPPLY CIRCUIT (FAN CONTROL AMP.)

1. Disconnect the fan control amp. connector.
2. Turn ignition switch ON, and check voltage between fan control amp. terminal 1, 5 and ground.


| Connector terminal |        | Voltage         |
|--------------------|--------|-----------------|
| Fan control amp.   | Ground | Battery voltage |
| 1                  |        |                 |
| 5                  |        |                 |

OK or NG

OK >> GO TO 4.

NG >> ● Between terminal 1 and ground: Repair the harness or connector.

- Between terminal 5 and ground: GO TO 7.



## TROUBLE DIAGNOSIS


### 4. CHECK BLOWER MOTOR FEEDBACK SIGNAL

Turn ignition switch ON, and check voltage between A/C auto amp. terminal 9 and ground.

| Connector terminal |        | Voltage     |
|--------------------|--------|-------------|
| A/C auto amp.      | Ground | Approx. 12V |
| 9                  |        |             |

OK or NG

OK >> GO TO 5.  
NG >> GO TO 9.




### 5. CHECK GROUND CIRCUIT

Check continuity between fan control amp. terminal 2 and ground.

| Connector terminal |        | Continuity |
|--------------------|--------|------------|
| Fan control amp.   | Ground | Yes        |
| 2                  |        |            |

Does continuity exist?

YES >> GO TO 6.  
NO >> Repair harness or connector.



### 6. CHECK 1: FAN CONTROL AMP. CONTROL SIGNAL

Check waveform between fan control amp. terminal 3 and ground.

| Fan speed                    | First                   | Second                  | Third                   | Fourth                  |
|------------------------------|-------------------------|-------------------------|-------------------------|-------------------------|
| Terminal 3<br>(Oscilloscope) |                         |                         |                         |                         |
|                              | T1: Approx. 0.37 ms     | T2: Approx. 0.29 ms     | T3: Approx. 0.19 ms     | T4: Approx. 0.04 ms     |
|                              | Duty ratio: Approx. 27% | Duty ratio: Approx. 42% | Duty ratio: Approx. 62% | Duty ratio: Approx. 92% |
|                              |                         |                         |                         |                         |

$$\text{NOTE: Duty ratio} = \frac{\text{Approx. 0.5 ms} - T_x}{\text{Approx. 0.5 ms}} \times 100 (\%)$$

MJIA0103E

OK or NG

OK >> Replace the fan control amp.  
NG >> ● Fan speed is stuck at speed 4: GO TO 11.  
          ● Fan speed is stuck at speed 1: GO TO 12.

# TROUBLE DIAGNOSIS

## 7. CHECK BLOWER MOTOR


1. Remove the blower motor.
2. Check continuity between blower motor terminal 1 and terminal 2.

| Connector terminal |   | Continuity |
|--------------------|---|------------|
| Blower motor       |   | Yes        |
| 1                  | 2 |            |

Does continuity exist?

YES >> GO TO 8.

NO >> Replace the blower motor.



## 8. CHECK CIRCUIT CONTINUITY


1. Disconnect the blower motor and fan control amp. connectors.
2. Check continuity between the blower motor terminal 2 and fan control amp. terminal 5.

| Connector terminal |                  | Continuity |
|--------------------|------------------|------------|
| Blower motor       | Fan control amp. |            |
| 2                  | 5                | Yes        |

Does continuity exist?

YES >> End of trouble diagnosis

NO >> Repair harness or connector.



## 9. CHECK CIRCUIT CONTINUITY


1. Disconnect the fan control amp. and A/C auto amp. connectors.
2. Check continuity between fan control amp. terminal 4 and A/C auto amp. terminal 9.

| Connector terminal |               | Continuity |
|--------------------|---------------|------------|
| Fan control amp.   | A/C auto amp. |            |
| 4                  | 9             | Yes        |

Does continuity exist?

YES >> GO TO 10.

NO >> Repair harness or connector.



## 10. CHECK FAN CONTROL AMP.


Check continuity between fan control amp. terminals 4 and 5.

| Connector terminal |   | Continuity |
|--------------------|---|------------|
| Fan control amp.   |   |            |
| 4                  | 5 | Yes        |

Does continuity exist?

YES >> End of trouble diagnosis

NO >> Replace the fan control amp.



# TROUBLE DIAGNOSIS


## 11. CHECK CIRCUIT CONTINUITY

1. Disconnect the fan control amp. and A/C auto amp. connectors.
2. Check continuity between fan control amp. terminal 3 and A/C auto amp. terminal 10.

| Connector terminal |               | Continuity |
|--------------------|---------------|------------|
| Fan control amp.   | A/C auto amp. |            |
| 3                  | 10            | Yes        |

Does continuity exist?

- YES >> Replace the fan control amp.  
 NO >> Repair harness or connector.



## 12. CHECK 2: FAN CONTROL AMP. CONTROL SIGNAL

1. Disconnect the A/C auto amp. connector.
2. Turn ignition switch ON, and check voltage between A/C auto amp. terminal 10 and ground.

| Connector terminal |        | Condition                           | Voltage         |
|--------------------|--------|-------------------------------------|-----------------|
| A/C auto amp.      | Ground | Fan speed : Speed 1 through Speed 3 | Battery voltage |
| 10                 |        |                                     |                 |

OK or NG

- OK >> Replace A/C auto amp.  
 NG >> Replace the fan control amp.

