



## USER GUIDE

Welcome to the Wall-E inspired Touchless Trash Can!

Simply hold your hand in front of the Can within 4 cm. An LED indicator will light purple when an object is detected near the Trash Can. When within 4 cm, an object will trigger the Can to open, and the light will turn green. The light will turn blue if the device is put into Bluetooth Mode.

When you open the trash can and place your trash in, the Can will wait for three seconds after detecting no triggering object to close, or it will close at the timeout time of 30 seconds.

Just before closing, the Can will check if the sensor at the top can still see light, which would indicate the trash can is not yet full. Note that the Can will only sense fullness after you have opened the can. Fullness is based on if light can be seen from within the can when the lid is open.

Press either the physical button or the virtual button to switch between Sensing Mode (automatic opening) or secured Bluetooth remote control. In your home you would want to use the Sensing Mode. Bluetooth Mode is ideal for driving your trash can to the curb for pickup or navigating the trash can to your bedside.

<https://5df002e7829bcb0006626eca.onlosant.com/>

<https://5df002e7829bcb0006626eca.onlosant.com/trashcan>

Log in with these credentials:

**Email:** test.user.c1juzyak9w@example.com

**Password:** c1juzyak9w

