

Applicable Version: 10.00 onwards

Overview

Cyberoam Captive Portal authenticates users for Internet access. When users attempt to access the internet, a default Captive Portal is presented to authenticate the users. The default Captive Portal display can be customized in terms of organization name, logo, page - title, header, footer, background and font colours or links. Additionally, the default Captive Portal Settings can be changed as per the requirement.

Scenario

Customize the default Captive Portal display and other settings in Cyberoam.

Configuration

You must be logged on to the Web Admin Console as an administrator with Read-Write permission for relevant feature(s).

Customize Captive Portal Display

a. Change Text, Captions, Logo

Go to **System > Configuration > Captive Portal** to Customize the Captive Portal display. Refer the sample custom configuration shown in the table below.

Parameters	Value	Description
Logo	Custom	Select Custom and click Browse to select your custom Logo. The image size should not exceed 125 X 70 pixels.
Logo URL	http://kb.cyberoam.com	Specify a URL to be redirected to on clicking the Logo.
Page Title	Internet Access Portal	Specify the page title.
Login Page Header	Please provide your credentials to access the Internet	Specify the page header to be displayed at the top of the page.
Login Page Footer	For Login Errors, please contact your System Administrator	Specify the page footer to be displayed at the bottom of the page.
Username Caption	Enter Your Username	Specify label for the username textbox.
Password Caption	Enter Your Password	Specify label for the password textbox.
Login Button Caption	Login	Specify label for the Login button.
Logout Button Caption	Logout	Specify label for the Logout button.

Time	Notification	Messages	Web Proxy	Parent Proxy	Captive Portal	Theme
General Settings						
Logo <input type="radio"/> Default <input checked="" type="radio"/> Custom <input type="button" value="Browse..."/> No file selected. Size 125x70 pixels						
Logo URL * <input type="text" value="http://kb.cyberoam.com"/>						
Page Title * <input type="text" value="Internet Access Portal"/>						
Login Page Header <input type="text" value="Please provide your credentials to access the Internet"/> HTML Input						
Login Page Footer <input type="text" value="For login errors, please contact your System Administrator"/> HTML Input						
Username Caption * <input type="text" value="Enter Your Username"/> HTML Input						
Password Caption * <input type="text" value="Enter Your Password"/> HTML Input						
Login Button Caption * <input type="text" value="Login"/>						
Logout Button Caption * <input type="text" value="Logout"/>						
Color Scheme						
Background Color <input type="text" value="FFFFFF"/> <input type="checkbox"/> Header, Footer Font Color <input type="text" value="FF351F"/> <input type="checkbox"/>						
Page Title Background Color <input type="text" value="FFFFFF"/> <input type="checkbox"/> Page Title Font Color <input type="text" value="1D68B3"/> <input type="checkbox"/>						
Caption Font Color <input type="text" value="565656"/> <input type="checkbox"/>						
<input type="button" value="Apply"/> <input type="button" value="Preview >>"/> <input type="button" value="Reset To Default"/>						

b. Change Color Scheme

You can customize the colour scheme of the Captive portal as per your preference. Specify the colour code or click the square box against page item to pick the colour.

The image shows the 'Color Scheme' configuration window. The 'Background Color' field is selected, and a color picker is displayed. The color picker shows a rainbow spectrum with a black slider on the right. The 'Background Color' field is highlighted with a red square, indicating it is the active selection.

Click **Apply** to apply the configuration. You can also preview the configuration by clicking **Preview**.

Please provide your credentials to access the Internet

Internet Access Portal

Knowledge Base

Enter Your Username

Enter Your Password

Login

For Login Errors, please contact your System Administrator

c. Captive Portal Settings

The default settings of Captive Portal can be changed to further customize the Captive Portal. Go to **Identity > Authentication > Firewall** and under the **Captive Portal Settings**, set the following options as per the requirement.

Captive Portal Settings

Unauthenticated users redirection	<input checked="" type="radio"/> Yes <input type="radio"/> No (Access Denied)	
Unauthenticated users settings	<input checked="" type="radio"/> Captive Portal <input type="radio"/> Custom Message	
HTTPS Redirection	<input type="checkbox"/> Enable	
My Account Link	<input type="checkbox"/> Enable	
URL Redirection after Login	<input type="checkbox"/> Enable	
URL to redirect	<input type="radio"/> User requested URL <input checked="" type="radio"/> Custom URL <input style="width: 150px;" type="text"/>	
Preserve captive portal after login	<input checked="" type="radio"/> Yes <input type="radio"/> No	
Keep Alive Request For Captive Portal	<input type="radio"/> Enable <input checked="" type="radio"/> Disable	
User Inactivity Timeout	<input checked="" type="checkbox"/> Unlimited <input style="width: 50px;" type="text"/> Minutes (Between 3-1440)	
Data Transfer Threshold	<input style="width: 50px;" type="text"/> Bytes	

Apply

Unauthenticated users redirection

Unauthenticated users redirection is used to configure the redirection of user access request to Captive portal page or Custom page.

Select **No** if you want to completely restrict Internet Access to the users. The user request will be dropped and the browser will display the default message for loss of Internet connectivity.

By default, **Unauthenticated users redirection** is set to **Yes** to redirect user access requests. The following options are applicable only if **Unauthenticated users redirection** is enabled.

1. Unauthenticated users settings

Unauthenticated users settings is used to redirect user requests to the Captive Portal or Custom Message page. By default, the Unauthenticated user settings is set to **Captive Portal**.

Select **Custom Message** to redirect unauthenticated user request to the Custom Message page. To configure the Custom Message Page, refer Articles, [Serve a Custom Page to unauthenticated users instead of Captive portal](#) and [Customize a Denied Message](#).

2. HTTPS Redirection

Check **Enable** to provide access of the Captive portal page through HTTPS or secure channel.

3. My Account Link

My Account Link provides user information like personal details, Internet usage or quarantined virus/spam mails. It is present on the Captive Portal by default. To disable My Account Link, check **Disable**.

4. URL Redirection after Login and URL to redirect

After successful authentication, the user requested URL opens, to change the URL redirection, refer article [Configure Captive Portal URL Redirection](#).

5. Preserve captive portal after login

Select **Yes** to preserve the Captive Portal page after successful logon, where the user-requested/custom URL opens in a new page.

If you don't want to preserve the Captive Portal page, select **No**, where the user-requested/custom URL opens in the same page as the Captive Portal page. If the Captive Portal is not preserved, the user will not be able to log out and his login session remains active until the user is idle. In this case, administrators can enable **Keep Alive Request for Captive Portal** or configure **User Inactivity Timeout** or **Data Transfer Threshold** to disconnect idle users.

6. Keep Alive Request For Captive Portal

Keep-Alive request is constantly exchanged between the appliance and the user to check whether user has logged out or idle. If the appliance does not receive the response, user is logged out automatically. To set keep-alive request active, select **Enable**.

Select **Disable** to configure **User Inactivity Timeout** or **Data Transfer Threshold** to logout the user.

User Inactivity Timeout

Specify the time after which the user will be logged off. Check **Unlimited** to allow permanent logon. To specify a finite duration, uncheck Unlimited and specify the duration in minutes. (3 to 1440)

Data Transfer Threshold

Specify threshold value for Data Transfer in Bytes. If the specified data is not transferred within the Inactivity Timeout period, the user will be marked as inactive and logged out.

Note:

Cyberoam Captive Portal can also be used to create Guest Users. To configure guest user creation through Captive portal, refer article [Guest User Creation using Captive Portal](#).

Document Version: 1.0 – 24 June, 2014