



Series 8K/9K Ingredient Change Process

Ingredients have two classifications, Pungent and Non-Pungent. Pungency type dictates ingredient change process. The following ingredients are classified as **Non-Pungent: Hi-C, Fanta, Dasani, Powerade, and Vitaminwater**. All other ingredients are classified as Pungent.

These procedures require the dispenser to be on 12.0 or newer version software.

Change from Non Pungent to Any Ingredient

Parts/Tools Required

- Flush Cartridge – CCP # 144395 - Qty 1 for each ingredient changed

Process Steps:

1. Scan flush cartridge
2. Take out cartridge that is being removed
3. Place flushing cartridge (CCP # 144395) into tray and insert into slot. **(Prime/Flush screen will auto populate when flushing cartridge is detected)**
 - a. Select > **Prime / Flush**
 - b. Remove Flushing Cartridge from slot when complete
4. Install new ingredient
 - a. Insert Cartridge
 - b. Select > **Prime / Purge**
5. Select > **Consumer View (if prompted, touch 'ok' to reboot unit)**

Change from Pungent to Any Ingredient:

Parts/Tools Required:

- QPM - CCP 130088
- Nozzle Assembly – CCP 144669 – Qty 1
- Elbow, outlet, BMD – CCP 122943 (Qty 1 for single cartridge / Qty 2 for double cartridges)
- Tubing, Elbow to Nozzle – CCP 122942 (Qty 1 for single cartridge / Qty 2 for double cartridges)

Process Steps:

1. Power down unit
2. Completely take out cartridge that is being removed and partially remove other cartridges using the same QPM
3. Replace QPM
4. Replace BMD outlet elbow(s)
5. Replace micro ingredient tubing(s)
 - a. Remove pungent micro ingredient tubing(s)
 - b. Install replacement micro ingredient tubing(s), connecting to the BMD elbow, fishing through the hydraulic sheath and to the nozzle assembly QTA (quad tube assembly)
 - c. Replace nozzle assembly
6. Reinsert all cartridges removed for QPM replacement (including new ingredient)
7. Power unit on, leaving lower door open
8. Select > **non-consumer view**
9. Log in as technician (tech access card or last 4 of SAP# + DDMM)
10. Close lower door
11. Select > **Service Menu > Cartridge/Package Replacement > Cartridge**
12. Select > **Prime > Purge/Prime all ingredients**
13. Select > **Consumer View (if prompted, touch 'ok' to reboot unit)**
14. Ensure Freestyle unit and new ingredient is 100% operational

Freestyle assistance is available 24 hours a day, 7 days a week at 800 817 2653 option 8