

Mobi TV

Personal TV Speaker



Model No.: iG 1025

Thank you for purchasing iGear
Mobi TV Bluetooth speaker. Please
read this user manual carefully before
operation & save it for future reference.

Specifications:

Output power (RMS) : 5W

BT Version : 5.0

Driver size : 57 mm

Speaker impedance : 3Ω

Frequency response : 20Hz-20kHz

S/N Ratio : ≥ 85 dB

Max. Supported USB/SD card : 64GB

Supported audio formats : MP3, WMA

Charging time : 3H

Playback time : 7 Hrs*

Product dimension : 174 x 80 x 153mm

Net. weight : 364

*at 50 Volume

Features:

Wireless BT

Supports USB and TF/SD card

Built-in FM Radio

Call Function

Media/Volume control

Built-in Rechargeable Battery

Support mobile upto 16.25cm

Adjustable FM Antenna

Note

- Avoid the use of this product at the high temperature and high humidity environment.
- Avoid self-disassembly of product, or it will result in the failure of warranty.
- Please charge the product with power adaptor output rated voltage DC5V.

Button Description:



M (Mode) Button: Press for changing the different input modes of the speaker.

◀ Button: Short press for Prev. track / FM channel. Long Press the button for decreasing volume.

⏸ Button: Short press for Play / Pause. Press once to attend / end a call.

▶ Button: Short press for Next track / FM channel. Long Press the button for increasing volume.

Charging the Speaker

1. Connect the micro USB charging cable to the DC 5V Charging port of the speaker and insert the other end (USB) into a DC 5V power source/adaptor.
2. Red LED glows indicating that the battery is being charged. The Red LED will turn off once it is fully charged.

Pairing your device with the Bluetooth Speaker




1. Power ON the speaker and you can hear the indication tone for Bluetooth mode.
2. Blue LED indicates that your speaker is now ON and is in pairing mode.
3. Switch ON BT on your phone or tablet and search for nearby BT devices.
4. Search for Bluetooth name "iGear-Mobi TV" and tap to connect it.

Micro SD / USB mode

Insert the Micro SD card / USB device to the respective ports of "iGear-Mobi TV" and the speaker will automatically start playing from the Micro SD card/USB device.

Once Connected change the speaker to AUX mode and thereafter audio can be streamed via the speaker from the connected source.

FM Radio mode

Switch the speaker to FM mode using the "M" button. Once the speaker is in FM mode, press the  button once to start scanning for FM channels. Once scanning is complete, press the  or  button to change the channels. For better signal reception, adjust the antenna length and position accordingly.

Name of Commodity: Mobi TV Bluetooth Speaker

Month and Year of Import: April, 2021

Net Weight: 346 gms

Net Quantity: 1 unit

Dimensions: 174mm X 80mm X 153mm

Voltage: DC 5V 1A

Wattage: 5W

Warranty Period: 1 Year

Imported and Marketed By:

IGear Tech Pvt. Ltd.

204, Sai Corporate Park,

Laxmi Nagar, Off Link Road,

Goregaon West, Mumbai - 400104.

In case of consumer complaints:

Toll free number - 1800 22 8495

Email: sales@igear.asia

(Between 10am to 5pm, Mon- Fri)