



Limo

Build Your Party



Model No.: iG-953

SPECIFICATIONS

Wireless version: 5.0

Speaker driver unit size: 4 INCH

Output power: 5W*2

Frequency response: 100Hz-20KHz

Signal to noise ratio: ≥ 85 dB

FM scan range: 87.5-108.0Mhz

Wireless range: 10 meter

Max memory USB/SD: 32GB

USB charging: DC 5V

Battery capacity: 2400mAh

Backup time via wireless mode: Approx 1.5-2 hours at max volume

Backup time via USB mode: Approx 1.5-2 hours at max volume

Charging via USB port (PC): 6-8 hours charging time

ACCESSORIES

Charging cable: 1 piece;


Audio cable: 1 piece;

CONNECT TO BLUETOOTH DEVICE

Turn on the unit and switch on your mobile Bluetooth, then search for the name 'iGear Limo' and pair the device.

Once device is paired, Bluetooth will automatically connect when unit is turned on subsequently.

1. POWER OFF/ON:
 2. Volume knob: To turn ON/OFF the speaker, and control the master volume.
 3. DC 5V: Plug the Micro USB cable to the speaker and connect other end USB port to the power source. (DC 5V)
 4. AUX: Aux-in jack
 5. USB slot: Used to read the Mp3 files in FAT32 format with maximum size of 32GB
 6. TF slot: Used to read the Mp3 files in FAT32 format with maximum size of 32GB
 7. MIC: 6.35MM mic-in jack
 8. Play/Pause: Under USB/TF/Bluetooth mode, short press for play and pause;
 9. M: To change mode during USB/TF, Bluetooth, FM and Aux-in mode.
 10. PREV: USB/TF/Bluetooth/FM mode: Press to move previous FM channel / track. long press to decrease the volume.
 11. NEXT: USB/TF/Bluetooth/FM mode: Press to move next FM channel / track. long press to increase the volume.
 12. MIC Button: to select KARAOKE mode.
 13. REPEAT: to select REPEAT mode.
- NOTE: If FM mode reception is not good, connect a Micro USB cable for better FM reception.



BLUETOOTH



Turn on the speaker, it come into the Bluetooth mode directly. After pairing, the device can play music. Short press to Play/Pause, Short press or to surf through Prev or Next track. Long press or to increase or decrease the volume.

TWS OPERATION:






1. Turn on both the speakers at the same time.
2. Choose one of them, on one of the speaker press and hold the "M" button for a few seconds, then a notification sound will indicate of pairing.

Note: TWS works in Bluetooth Mode only






AUX-IN

Insert the AUX cable into AUX jack, and press 'M' to switch to AUX-IN mode. Long press  or  to increase or decrease the volume. In AUX mode, track cannot be changed using the speaker buttons.

USB / TF CARD

Insert the USB / TF card into the USB / TF slot. It will read the MP3 format music automatically. Press  to Play/Pause. Short Press  or  to switch to Prev or Next Song. Long press  or  to increase or decrease the volume.

FM RADIO

Long press the Play/Pause  button, it will search for the available stations and save them automatically. Once the search is completed, Short press the  or  button to switch between the saved stations. Long press  or  to increase or decrease the volume. NOTE: AUX Port connection can receive FM signal clearly as it has the same function as the antenna.

CHARGING

Please use the original charging cable to charge. Red LED display when on charging.

Imported and Marketed By:
IGear Tech Pvt. Ltd.
204, Sai Corporate Park,
Laxmi Nagar, Off Link Road,
Goregaon West, Mumbai - 400104.
In case of consumer complaints:
Toll free number - 1800 22 8495
Email: sales@igear.asia
(Between 10am to 5pm, Mon- Fri)