



=====

**[Errno 98] Address already in use**

=====

Error occurred in line number 205

```
=====
##### SYSTEM LOGS #####
=====
```

```
Oct 29 23:13:42 mcb1 daemon.info netopeer2-server[980]: Trying to connect via IPv4 to 192.168.170.85:4334.
Oct 29 23:13:42 mcb1 daemon.info netopeer2-server[980]: getsockopt() error (Connection refused).
Oct 29 23:13:42 mcb1 user.notice SYNCMNGR[1310]: Received message from S-Plane
Oct 29 23:13:43 mcb1 daemon.info netopeer2-server[980]: Trying to connect via IPv4 to 192.168.170.85:4334.
Oct 29 23:13:43 mcb1 daemon.info netopeer2-server[980]: getsockopt() error (Connection refused).
Oct 29 23:13:43 mcb1 auth.info sshd[9092]: Accepted password for installer from 192.168.170.85 port 51666 ssh2
Oct 29 23:13:43 mcb1 authpriv.info sshd[9092]: pam_unix(sshd:session): session opened for user installer by (uid=0)
```

**Expected Result : The NETCONF server replies rejecting the protocol operation with an "access-denied" error.**

=====

\*\*\*\*\* **Actual Result** \*\*\*\*\*

=====

=====

\*\*\*\*\* **FAIL\_REASON** \*\*\*\*\*

=====

[Errno 98] Address already in use

=====

**Access Control NMS (negative case) = FAIL**

=====