

14-A-5 Diesel cycle heat addition

In a Diesel cycle, heat addition takes place at:

Constant pressure