

## 14-E-11 Cylinder position

The pressure in the cylinder is ..... the atmospheric value during exhaust stroke and ..... it during intake stroke.

above, below

This is done to ensure that all the exhaust gases are thrown out of the cylinder and enough intake mixture enters the cylinder. (Low pressure works like vacuum cleaner for the intake, therefore it will create suction of the combustible)