

Коды неисправностей системы управления пневмоподвески от блока ECAS.

SID(dec)	SPN	Описание SPN	FMI(dec)	Описание FMI
34	274210	Power supply for solenoid valves (Central valverelay)	3	Voltage above or shorted high
34	274210	Power supply for solenoid valves (Central valverelay)	5	Current below normal or open circuit
34	274210	Power supply for solenoid valves (Central valverelay)	6	Current above normal or grounded circuit
34	274210	Power supply for solenoid valves (Central valverelay)	11	Failure mode not identifiable
1	274177	2/2 solenoid valve front axle right	3	Voltage above or shorted high
1	274177	2/2 solenoid valve front axle right	5	Current below normal or open circuit
1	274177	2/2 solenoid valve front axle right	6	Current above normal or grounded circuit
3	274179	2/2 solenoid valve drive axle right	3	Voltage above or shorted high
3	274179	2/2 solenoid valve drive axle right	5	Current below normal or open circuit
3	274179	2/2 solenoid valve drive axle right	6	Current above normal or grounded circuit
4	274180	2/2 solenoid valve drive axle left	3	Voltage above or shorted high
4	274180	2/2 solenoid valve drive axle left	5	Current below normal or open circuit
4	274180	2/2 solenoid valve drive axle left	6	Current above normal or grounded circuit
5	274181	2/2 solenoid valve axle 3 right	3	Voltage above or shorted high
5	274181	2/2 solenoid valve axle 3 right	5	Current below normal or open circuit
5	274181	2/2 solenoid valve axle 3 right	6	Current above normal or grounded circuit
6	274182	2/2 solenoid valve axle 3 left	3	Voltage above or shorted high
6	274182	2/2 solenoid valve axle 3 left	5	Current below normal or open circuit
6	274182	2/2 solenoid valve axle 3 left	6	Current above normal or grounded circuit
7	274183	Central 3/2 solenoid valve drive axle	3	Voltage above or shorted high
7	274183	Central 3/2 solenoid valve drive axle	5	Current below normal or open circuit
7	274183	Central 3/2 solenoid valve drive axle	6	Current above normal or grounded circuit
8	274184	3/3 solenoid valve axle 3 lifting	3	Voltage above or shorted high
8	274184	3/3 solenoid valve axle 3 lifting	5	Current below normal or open circuit
8	274184	3/3 solenoid valve axle 3 lifting	6	Current above normal or grounded circuit
9	274185	3/3 solenoid valve axle 3 lowering	3	Voltage above or shorted high
9	274185	3/3 solenoid valve axle 3 lowering	5	Current below normal or open circuit
9	274185	3/3 solenoid valve axle 3 lowering	6	Current above normal or grounded circuit
10	274186	2/2 solenoid valve axle 3 lift bellows	3	Voltage above or shorted high

10	274186	2/2 solenoid valve axle 3 lift bellows	5	Current below normal or open circuit
10	274186	2/2 solenoid valve axle 3 lift bellows	6	Current above normal or grounded circuit
105	274281	2/2 solenoid valve connection drive axle / axle 3	3	Voltage above or shorted high
105	274281	2/2 solenoid valve connection drive axle / axle 3	5	Current below normal or open circuit
105	274281	2/2 solenoid valve connection drive axle / axle 3	6	Current above normal or grounded circuit
16	274192	Distance sensor front axle right	2	Data erratic, intermittent, or incorrect
16	274192	Distance sensor front axle right	3	Voltage above or shorted high
16	274192	Distance sensor front axle right	5	Current below normal or open circuit
16	274192	Distance sensor front axle right	6	Current above normal or grounded circuit
18	274194	Distance sensor drive axle right	2	Data erratic, intermittent, or incorrect
18	274194	Distance sensor drive axle right	3	Voltage above or shorted high
18	274194	Distance sensor drive axle right	5	Current below normal or open circuit
18	274194	Distance sensor drive axle right	6	Current above normal or grounded circuit
19	274195	Distance sensor drive axle left	2	Data erratic, intermittent, or incorrect
19	274195	Distance sensor drive axle left	3	Voltage above or shorted high
19	274195	Distance sensor drive axle left	5	Current below normal or open circuit
19	274195	Distance sensor drive axle left	6	Current above normal or grounded circuit
22	274198	Pressure sensor front axle right	3	Voltage above or shorted high
22	274198	Pressure sensor front axle right	5	Current below normal or open circuit
22	274198	Pressure sensor front axle right	6	Current above normal or grounded circuit
24	274200	Pressure sensor drive axle right	3	Voltage above or shorted high
24	274200	Pressure sensor drive axle right	5	Current below normal or open circuit
24	274200	Pressure sensor drive axle right	6	Current above normal or grounded circuit
25	274201	Pressure sensor drive axle left	3	Voltage above or shorted high
25	274201	Pressure sensor drive axle left	5	Current below normal or open circuit
25	274201	Pressure sensor drive axle left	6	Current above normal or grounded circuit
26	274202	Pressure sensor axle 3 right	3	Voltage above or shorted high
26	274202	Pressure sensor axle 3 right	5	Current below normal or open circuit
26	274202	Pressure sensor axle 3 right	6	Current above normal or grounded circuit
27	274203	Pressure sensor axle 3 left	3	Voltage above or shorted high
27	274203	Pressure sensor axle 3 left	5	Current below normal or open circuit
27	274203	Pressure sensor axle 3 left	6	Current above normal or grounded circuit

28	274204	Pressure sensor lift bellows	3	Voltage above or shorted high
28	274204	Pressure sensor lift bellows	5	Current below normal or open circuit
28	274204	Pressure sensor lift bellows	6	Current above normal or grounded circuit
46	274222	Power supply for pressure sensors	3	Voltage above or shorted high
46	274222	Power supply for pressure sensors	6	Current above normal or grounded circuit
47	274223	Power supply for ECAS remote controls	3	Voltage above or shorted high
47	274223	Power supply for ECAS remote controls	6	Current above normal or grounded circuit
48	274224	Remote control unit 1 data line	3	Voltage above or shorted high
48	274224	Remote control unit 1 data line	6	Current above normal or grounded circuit
49	274225	Remote control unit 1 clock line	3	Voltage above or shorted high
49	274225	Remote control unit 1 clock line	6	Current above normal or grounded circuit
33	274209	Remote control unit 1	11	Failure mode not identifiable
231	274407	CAN bus off (SAE J 1939 Data link)	9	Abnormal update rate
60	274236	CAN communication error	9	Abnormal update rate
61	274237	CAN message CCVS	9	Abnormal update rate
62	274238	CAN message EEC1	9	Abnormal update rate
65	274241	CAN message AIR1 (ECAM)	9	Abnormal update rate
68	274244	CAN message TCO1	9	Abnormal update rate
74	274250	CAN message EAC1	9	Abnormal update rate
75	274251	CAN message ASC2_A	9	Abnormal update rate
77	274253	CAN message ASC6_A	9	Abnormal update rate
104	274280	CAN message ETC2	9	Abnormal update rate
254	274430	Control unit (internal fault)	2	Data erratic, intermittent, or incorrect
254	274430	Control unit (internal fault)	11	Failure mode not identifiable
254	274430	Control unit (internal fault)	12	Bad intelligent device or component
38	274214	Checksum ECU specific data	2	Data erratic, intermittent, or incorrect
39	274215	Checksum parameter data	2	Data erratic, intermittent, or incorrect
39	274215	Checksum parameter data	13	Out of calibration
40	274216	Checksum calibration data distance sensors	2	Data erratic, intermittent, or incorrect
40	274216	Checksum calibration data distance sensors	13	Out of calibration
41	274217	Checksum calibration data pressure sensors	2	Data erratic, intermittent, or incorrect
42	274218	Checksum max. axle load data	2	Data erratic, intermittent, or incorrect
42	274218	Checksum max. axle load data	11	Failure mode not identifiable
42	274218	Checksum max. axle load data	12	Bad intelligent device or component
92	274268	Checksum configuration CAN-data	2	Data erratic, intermittent, or incorrect
98	274274	Parameter Check / Component Check	2	Data erratic, intermittent, or incorrect

98	274274	Parameter Check / Component Check	11	Failure mode not identifiable
----	--------	--------------------------------------	----	-------------------------------